

FLIGHT MANUAL

USAF SERIES

C-7A

AIRCRAFT

HUGH WILSON

537 TAS

1966 - 1967

F09603-72-D-1406-0001



THIS MANUAL IS INCOMPLETE
WITHOUT T.O. 1C-7A-1-1

SEE INDEX T.O. 0-1-1-3 FOR CUR-
RENT STATUS OF FLIGHT MANUAL,
SAFETY SUPPLEMENTS, OPERA-
TIONAL SUPPLEMENTS AND FLIGHT
CREW CHECKLIST.

COMMANDERS ARE RESPONSIBLE
FOR BRINGING THIS PUBLICATION
TO THE ATTENTION OF ALL AIR
FORCE PERSONNEL CLEARED FOR
OPERATION OF SUBJECT AIRCRAFT.

Published under authority of the Secretary of the Air Force

1 OCTOBER 1970

CHANGE 7 - 10 OCTOBER 1974

LIST OF EFFECTIVE PAGES

Insert latest changed pages; dispose of superseded pages in accordance with applicable regulations.

NOTE: On a changed page, the portion of the text affected by the latest change is indicated by a vertical line, or other change symbol, in the outer margin of the page. Changes to illustrations are indicated by miniature pointing hands. Changes to wiring diagrams are indicated by shaded areas.

Total number of pages in this manual is 272 consisting of the following:

Page No.	# Change No.	Page No.	# Change No.	Page No.	# Change No.
Title	7	2-11	2	3-31	3
A - B.	7	2-12 - 2-16	0	3-32	1
C Blank.	7	2-17 - 2-18	6	3-32A	1
i - ii	7	2-19 - 2-20	0	3-32B Blank	1
iii	0	2-21	2	3-33	1
iv Blank	0	2-22	1	3-34	0
1-1	0	2-22A	1	3-35 - 3-36A	4
1-2	3	2-22B Blank	1	3-36B Blank	4
1-3 - 1-7	0	2-23 - 2-24	6	3-37	4
1-8	2	2-24A	5	3-38	0
1-9 - 1-10	0	2-24B Blank	5	3-39	4
1-11	4	2-25 - 2-32	0	3-40	0
1-12 - 1-19	0	2-33	5	4-1 - 4-10	0
1-20	3	2-34 - 2-35	0	4-11 - 4-12	2
1-21	0	2-36	5	4-13 - 4-20	0
1-22	3	2-37	6	4-21	2
1-23	0	2-38	0	4-22 - 4-23	0
1-24	7	2-39 - 2-40	3	4-24	1
1-25	0	2-41 - 2-43	0	4-25 - 4-30	0
1-26	7	2-44	3	4-30A - 4-30C	2
1-26A Deleted	7	2-45	4	4-30D - 4-30H	6
1-26B Blank		2-46	2	4-31	2
Deleted	7	2-46A	2	4-32 - 4-37	0
1-27	7	2-46B Blank	2	4-38	2
1-28 - 1-35	0	2-47	0	4-39 - 4-40	0
1-36	2	2-48	3	4-40A - 4-40B	2
1-36A	2	2-49	0	4-41	4
1-36B Blank	2	2-50 Blank	0	4-42 - 4-48	0
1-37	0	3-1	0	4-49	2
1-38	2	3-2 - 3-3	7	4-50	0
1-39 - 1-43	0	3-4	0	5-1 - 5-2	0
1-44	7	3-5	3	5-3	1
1-45	0	3-6	0	5-4	2
1-46 Blank	0	3-7 - 3-9	7	5-4A	2
2-1	7	3-10 - 3-12	0	5-4B Blank	2
2-2	3	3-13 - 3-14	7	5-5	2
2-3	2	3-15	0	5-6	6
2-4	0	3-16	7	5-6A	2
2-5 - 2-6	3	3-17 - 3-25	0	5-6B Blank	2
2-7 - 2-9	4	3-26	1	5-7	2
2-10	0	3-27 - 3-29	0	5-8 - 5-9	0
2-10A	2	3-30	2	5-10	1
2-10B Blank	2			5-11 - 5-12	0
				6-1 - 6-2	5

Zero in this column indicates an original page.

LIST OF EFFECTIVE PAGES (CONTINUED)

Page No.	# Change No.	Page No.	# Change No.	Page No.	# Change No.
6-3	3				
6-4	5				
7-1 — 7-2	0				
7-3	4				
7-4 — 7-10	0				
7-11	3				
7-12	0				
8-1	0				
8-2	3				
8-3 — 8-6	0				
9-1 — 9-14	0				
X-1	6				
X-2	2				
X-2A	2				
X-2B Blank	2				
X-3	6				
X-4	7				
X-5	0				
X-6	7				
X-7 — X-8	2				
X-9	6				
X-10	2				
X-11	4				
X-12 Blank	4				

TABLE OF CONTENTS

SECTION I	DESCRIPTION	1-1
SECTION II	NORMAL PROCEDURES	2-1
SECTION III	EMERGENCY PROCEDURES	3-1
SECTION IV	AUXILIARY EQUIPMENT	4-1
SECTION V	OPERATING LIMITATIONS	5-1
SECTION VI	FLIGHT CHARACTERISTICS	6-1
SECTION VII	SYSTEMS OPERATION	7-1
SECTION VIII	CREW DUTIES	8-1
SECTION IX	ALL WEATHER OPERATION	9-1

IN ORDER THAT YOU WILL GAIN THE MAXIMUM BENEFITS FROM THIS MANUAL, IT IS IMPORTANT THAT YOU READ THIS INTRODUCTION CAREFULLY.

SCOPE

This manual contains the necessary information for safe and efficient operation of the C-7A aircraft. These instructions provide you with a general knowledge of the aircraft, its characteristics, and specific normal and emergency operating procedures. Your flying experience is recognized, and therefore, basic flight principles are avoided. This manual provides the best possible operating instructions under most circumstances; however, multiple emergencies, adverse weather, terrain, etc, may require modification of the procedures.

PERMISSIBLE OPERATIONS

The Flight Manual takes a positive approach and normally states only what you can do. Unusual operations or configurations (such as asymmetrical loading) are prohibited unless specifically covered herein. Clearance must be obtained from Warner Robins ALC, MMEAP before any questionable operation is attempted which is not specifically permitted in this manual.

SAFETY AND OPERATIONAL SUPPLEMENTS

Information involving safety will be promptly forwarded to you by Safety Supplements. TWX-type Safety Supplements covering loss of life (called Interim Safety Supplements), will get to you in 48 hours; those concerning serious damage to equipment within 10 days by mail (in a formal printed form). Operational information not involving safety but of an urgent nature will be forwarded to you by Operational Supplements. These will be forwarded by TWX (interim) or by mail (formal), depending upon the urgency of the information. Interim supplements are normally replaced by formal printed supplements at an early date. Formal printed supplements are identified by red letters "SS" for safety supplements and black letters

"OS" for operational supplements printed around the borders of the pages. The currency of Safety Supplements and Operational Supplements affecting your aircraft and Flight Manual can be determined by referring to the Weekly Index of Safety Supplements (T.O. 0-1-1-3). The title block of each supplement and the title page of this manual should also be checked to determine the effect they may have on existing supplements. You must remain constantly aware of the status of all supplements — current supplements must be complied with, but there is no point in restricting your operation by complying with a replaced or rescinded supplement. As a further aid, supplement records for both Safety Supplements and Operational Supplements are included in this manual following the A page; however, these records can be only as current as this manual.

CHECKLISTS.

The Flight Manual contains the normal and emergency procedures. The checklists have been issued as separate technical orders. Line items in the Flight Manual and checklists are identical as pertains to arrangement and item number. The checklists are designed for use with binders having plastic envelopes into which the individual pages are placed. For T.O. number and date of the checklist applicable to this manual refer to T.O. 0-1-1-3. Order the checklist as you would any technical order.

WARNINGS, CAUTIONS, AND NOTES

The following definitions apply to WARNINGS, CAUTIONS, and NOTES found throughout this manual.

WARNING

Operating procedures, techniques, etc, which will result in personal injury or loss of life if not carefully followed.

CAUTION



Operating procedures, techniques, etc, which will result in damage to equipment if not carefully followed.

NOTE An operating procedure, technique, etc, which is considered essential to emphasize.

YOUR RESPONSIBILITY — TO LET US KNOW.

Every effort is made to keep the Flight Manual current. Review conferences with operating personnel and a constant review of accident and flight test reports assure inclusion of the latest data in the manual. However, we cannot correct an error unless we know of its existence. In this regard, it is essential that you do your part. Comments, corrections, and questions regarding this manual or any phase of the Flight Manual program are welcomed. These should be forwarded on AF Form 847 through your Command Headquarters to Warner Robins Air Logistics Center, ATTN: MMEAP, Robins Air Force Base, Georgia 31098.

the aircraft



SECTION I DESCRIPTION

TABLE OF CONTENTS

THE AIRCRAFT	1-1	LANDING GEAR	1-27
ENGINES.....	1-2	NOSEWHEEL STEERING	1-30
PROPELLERS	1-8	WHEEL BRAKES SYSTEM	1-31
OIL SYSTEM.....	1-11	INSTRUMENTS.....	1-32
FUEL SYSTEM.....	1-11	EMERGENCY EQUIPMENT	1-38
ELECTRICAL POWER SUPPLY SYSTEM.....	1-14	MISCELLANEOUS EQUIPMENT.....	1-42
HYDRAULIC POWER SUPPLY SYSTEMS....	1-20	ENTRANCE DOORS	1-42
FLIGHT CONTROLS	1-24	SEATS	1-42
WING FLAPS.....	1-26	AUXILIARY EQUIPMENT	1-43

THE AIRCRAFT.

The de Havilland C-7A is an all metal, high wing, land based monoplane powered by two reciprocating engines with full feathering, hydromatic propellers. Reverse thrust is available for aerodynamic braking on the ground. The aircraft has a fully retractable tricycle landing gear and an electrically operated cargo door and ramp located on the aft end of the fuselage. The C-7A can land and take-off on short runways and semi-prepared strips.

INTERIOR.

The fuselage is divided into the cargo compartment and the flight compartment. A sliding door separates the two compartments. The cargo compartment capacity in addition to the flight mechanic is 31 passengers or 25 paratroops and equipment. The capacity of the NATO configuration for aeromedical evacuation is 20 litters with one attendant. The AD205

configuration is 14 litters with 11 seats available for ambulatory patients and medical attendants.

AIRCRAFT DIMENSIONS.

The principal dimensions of the aircraft are:

Wing Span	95 ft. 8 in.
Length	74 ft. 0 in.
Height	31 ft. 9 in.
Tread of outer landing gear wheels	25 ft. 8 1/2 in.
Cargo Compartment	
Length	345 in.
Width	
(without buffer boards)	73 1/2 in.
Height	
(without center anchor line cable)	75 in.

AIRCRAFT WEIGHT.

The maximum gross weight for normal operations is 28,500 pounds. For detailed weight and loading information refer to Sections V and VII.

CREW.

Crew normally consists of pilot, copilot, and flight mechanic. The pilot and copilot are seated on left and right sides, respectively, of the sliding radio console. The flight mechanic must be seated in the cargo compartment during take-off and landing.

ENGINES.

The aircraft is powered by two Pratt and Whitney Twin Wasp R-2000-7M2, fourteen cylinder, double-row radial engines. Each engine incorporates an engine-driven, single-speed supercharger. Two augmentors, which are large tubes that extend aft from the firewall to the wing trailing edge, are installed in each nacelle. Exhaust stacks carry exhaust gases from the cylinders to the forward ends of the augmentors. Open space remains around the stacks where they terminate at the augmentors. The augmentors function as ejection pumps to draw cooling air across the engine, and use the heat energy in the exhaust gas and engine cooling air for additional thrust. Engine fire detectors and extinguishing system are provided. At take-off, each engine will produce 1450 bhp at 2700 rpm, under standard day conditions at sea level.

ENGINE CONTROLS.**Throttle Levers.**

Two throttle levers, one for each engine, are located on the overhead console (figure 1-3), and move in a quadrant marked REVERSE PITCH and THROTTLE CLOSED at the aft end, and OPEN at the forward end. The throttles are connected to their respective engine throttle valves by individual mechanical linkage. When both throttles are retarded below a setting of approximately 15 inches Hg. a micro-switch is actuated to energize the landing gear warning circuit. A friction lever on the left side of the console increases the friction of both throttles when rotated clockwise. Propeller reversing is effected electrically by moving the throttle levers approximately one inch upward in the idle or closed position. When the levers are raised, micro-switches are contacted, and hydraulic pressure moves the propeller blades to the

reverse pitch stops. The propeller feathering buttons will illuminate, indicating operation of the auxiliary pumps followed by illumination of the propeller reverse blue lights. Reverse power is increased by moving the throttle levers aft.

Mixture Levers.

Two mixture levers, one for each engine, are mounted on the overhead console, (figure 1-3), and move in a quadrant marked IDLE CUT-OFF, AUTO LEAN, and AUTO RICH. The mixture levers are connected to their respective carburetors by mechanical linkage. A friction lever on the right side of the console increases the friction of both mixture levers when rotated clockwise. Mixture levers have a detent at the AUTO LEAN setting to minimize the possibility of inadvertent movement to the IDLE CUT-OFF position.

Carburetor Hot-Air Levers.

Two carburetor hot-air levers marked CARB HEAT, LH and RH are located on the overhead console, (figure 1-3), and move in quadrants marked HOT and COLD.

Each lever is mechanically linked to interconnected hot and cold air valves in the related carburetor intake duct. With the lever in COLD the hot air valve is closed and the cold air valve is open to admit ram air, filtered air, or alternate air, whichever is selected on the carburetor air induction switches. With the lever in HOT, the cold air valve is closed and, downstream, the hot air valve is open to admit exhaust heated air. Intermediate positions of the levers may be selected to give varying degrees of carburetor heat.

Carburetor Air Induction System.

Two carburetor air induction switches, one for each engine, are located on the overhead console. Both switches are located outboard of the right-hand carburetor hot-air lever. The switches are marked CARB AIR, L and R with positions ALTERNATE, FILTER, and RAM. When RAM is selected, the ram air valve at the entry of the duct is open and passes unfiltered air direct to the carburetor. When FILTER is selected, the ram air valve is closed and filtered air enters the duct. When ALTERNATE is selected, the ram air valve is closed and an alternate air valve is open to admit cylinder-heated unfiltered air into the duct. Irrespective of the switch selection, normal

general arrangement




Figure 1-1

flight compartment





Figure 1-2 (Sheet 1 of 2)

flight compartment



- | | |
|---|---|
| 1. CIRCUIT BREAKER AND FUSE PANELS | 11. MAP AND DATA CASE |
| 2. OVERHEAD CONSOLE | 12. HYDRAULIC FLUID RESERVOIR AND SIGHT GAGE |
| 3. MAIN GEAR EMERGENCY EXTENSION HANDLE | 13. H.F. LOAD UNIT DC CONTROL CIRCUIT BREAKER |
| 4. ROOF HATCH | 14. RADIO EQUIPMENT RACKS |
| 5. EMERGENCY SLIDE | 15. ACCESS LADDER |
| 6. HEATING CONTROL PANELS | 16. FLOOR DOOR |
| 7. TACAN/RADAR ALTIMETER C.B. PANEL | 17. WEIGHT AND BALANCE COMPUTER |
| 8. IGNITION ANALYZER RECEPTACLE | 18. SPARE LAMPS AND FUSES STOWAGE |
| 9. HYDRAULIC PRESSURE SHUT-OFF VALVE HANDLE | 19. CARGO DOOR AND RAMP FORWARD SWITCH PANEL |
| 10. FIRST AID KIT STOWAGE | 20. WEATHER RADAR C.B. PANEL |

Figure 1-2 (Sheet 2 of 2)

overhead console-typical




Figure 1-3

induction air is excluded when the carburetor hot-air lever is at HOT position. Power is supplied from the emergency bus through two 5-ampere circuit breakers on the main circuit breaker panel.

NOTE

The valve actuator motors are of the reversible type. Should electrical failure deenergize the system, the valves will remain in the position at which the failure occurred.

Accessory Compartment Cooling System Selector Switch.

A two-position toggle switch on the engine switch panel (figure 1-9) is marked VENT DOORS with positions AUTO-OPEN and CLOSE-MAN. In the AUTO-OPEN position the actuators are automatically controlled by the weight switch on the nose gear. In the CLOSE-MAN. position the weight switch is overridden and the doors will remain in the closed position. Power is supplied from the main bus through a 5-ampere circuit breaker on the main circuit breaker panel.

IGNITION SYSTEM.

The engine ignition system is a dual magneto type, both magnetos serving each cylinder. The left magneto fires the rear spark plugs, the right magneto fires the front spark plugs, thereby providing two independent sources of ignition.

Ignition Switches.

Two ignition switches are located on the overhead console (figure 1-3), and are marked IGNITION, each having positions marked OFF, R, L, and BOTH. The switches control the supply of electrical energy from the magnetos to the spark plugs. When in the OFF position the switches ground the circuit of both magnetos.

Induction Vibrator Switch.

An induction vibrator, three-position toggle switch, marked VIB, L, and R is located on the engine switch panel (figure 1-9) and is spring-loaded to the center (off) position. When in either L or R position, power from the main bus is directed through the STARTING circuit breaker to the respective engine induction vibrator and from there to the right-hand magneto, providing a boosted spark for engine starting.

ENGINE PRIMING.

The engine priming system provides for atomized fuel to be injected into the supercharger throat preparatory to starting the engine.

Primer Switch.

The primer three-position toggle switch is located on the engine switch panel (figure 1-9) and is spring-loaded to the center (off) position, and is marked PRIME, L, and R. When held in either the L or R position, the circuit to the respective primer valve is energized from the main bus through the 10-ampere circuit breaker, thus opening the valve and, with the booster pump operating, fuel is injected into the supercharger throat through the priming jets.

STARTER.

The starter system for each engine consists of a direct-cranking starter and a starter relay. Electrical power for the starter is taken from the main bus through the 10-ampere starting circuit breaker.

Starter Switch.

The starter three-position toggle switch is located on the engine switch panel (figure 1-9) and is marked START, L, and R for the left and right engines respectively, and is spring-loaded to the center (off) position. When the switch is operated, power is supplied through the 10-ampere STARTING circuit breaker to the starter relay, which closes to complete the circuit to the starter motor.

ENGINE INSTRUMENTS.

The engine instruments, (figure 1-4) one complete set for each engine, are mounted on the engine instrument panel and the center portion of the electrical switch panel immediately below. A manifold pressure gage and a tachometer are each dual instruments, combining readings from both engines on a single dial. See figure 5-1 for the operating ranges and limitation markings.

Manifold Pressure Gage.

The manifold pressure gage is an electrically-operated autosyn type and registers the intake manifold pressures of both engines. The instrument has a single dial with dual pointers rotating about a common axis. The pointers are

marked L and R to indicate left and right engine readings respectively. AC power is supplied by the operating inverter through the 26-volt, 400-cycle ac bus through a 1-ampere fuse.

Tachometer.

The tachometer is a dual instrument and is powered by an engine-driven tachometer generator on each engine; it indicates the speed of each engine in rpm. Dual pointers rotating about a common axis register on a single dial, the pointers being marked L and R for the left and right engines respectively.

Carburetor Air Temperature Gage.

The carburetor air temperature gage is an electrically-operated resistance type and is connected to a resistance bulb located at the carburetor air intake of the engine. Power is supplied from the emergency bus through the 5-ampere engine and instrument circuit breakers.

Cylinder Head Temperature Gage.

The cylinder head temperature gage is an electrically-operated resistance type connected to a resistance bulb in No. 2 cylinder of the engine. Power is supplied from the emergency bus through the 5-ampere engine instrument circuit breakers.

Fuel Pressure Gage.

The fuel pressure gage is an electrically-operated autosyn gage which registers fuel pressure at the carburetor inlet. Power is supplied by the inverter through the 26-volt, 400-cycle ac bus through the 1-ampere engine instrument fuses.

Oil Pressure Gage.

The oil pressure gage is an electrically-operated autosyn gage which registers oil pressure at the engine rear case. Power is supplied by the inverter through the 26-volt, 400-cycle ac bus through the 1-ampere engine instrument fuses.

Oil Temperature Gage.

The oil temperature gage is an electrically-operated resistance type and registers oil inlet temperature. Power is supplied from the emergency bus through the 5-ampere engine and instrument circuit breakers.

Oil Low Pressure Warning Light.

An amber press-to-test warning light (figure 1-4) marked LOW OIL PRESS is provided for each engine and are located on the engine instrument panel. The light will illuminate when the respective engine oil pressure drops below 45 ± 2 psi. Power is supplied from the emergency bus and the circuit is protected by the 5-ampere circuit breaker marked PRESS WARN, FUEL & OIL.

Low Oil Level Warning Light.

An amber press-to-test warning light (figure 1-4) marked LOW OIL LEVEL is provided for each engine oil tank, and they are located on the engine instrument panel. The main purpose of the lights is to indicate when oil transfer should take place if long range ferry fuel and oil tanks are installed. (Refer to Section VII for ferry tanks installation.) The lights however, will provide an indication of low oil level at all times, and will illuminate when approximately 9 gallons of oil have been used (approximately 11.4 usable gallons remaining) in the respective tank. Power is supplied from the emergency bus and the circuit is protected by the 5-ampere circuit breaker marked PRESS WARN, FUEL & OIL.

Fuel Low Pressure Warning Light.

A red press-to-test warning light (figure 1-6) is provided for each engine. The lights are marked LH and RH ENGINE LOW PRESSURE, for the left and right engines respectively. A light will illuminate when fuel pressure at the carburetor inlet on the engine drops below 12 psi. Power is supplied from the emergency bus and the circuit is protected by the 5-ampere circuit breaker marked PRESS WARN, FUEL & OIL.

PROPELLERS.

The aircraft is equipped with three-bladed, full feathering reversible pitch Hamilton Standard hydromatic propellers. Governor settings are controlled from the flight compartment by means of the propeller lever for the respective engine. Automatic and manual feathering controls are provided, auto-feathering being provided for use during take-off only. Propeller reversing is effected electrically by moving the throttle levers approximately one inch upwards in the idling or closed position. Engine power is increased by moving the throttle levers further aft. Propeller

instrument panel (engine)-typical






Figure 1-4

governing does not take place in reverse pitch, the propeller acting as a fixed-pitch unit of minus 8 degrees. Engine speed must not be allowed to exceed 2700 rpm. The propeller control unit contains the propeller system fluid supply, which is independent of the engine oil supply, and which is pressurized by a main pump geared to the engine shaft. An auxiliary pump and electrical motor provide pressurized fluid when needed to assist or take the place of the main pump. A governor in the unit controls the constant speed operation. The propeller electrical system is powered from the main bus through circuit breakers on the ENGINE circuit breaker panel. The propeller manual feathering circuits are protected by the 10-ampere LEFT and RIGHT circuit breakers, and the auto-feathering switch circuit by the 5-ampere AUTOM. SW. circuit breaker. The propeller reverse circuit is protected by the 10-ampere PROP REV circuit breaker.

PROPELLER LEVERS.

Two propeller levers are located on the overhead console (figure 1-3) and move in a quadrant marked PROP. INCREASE, and DECREASE. A friction lever marked PROP, on the left side of the overhead console, increases the friction of both propeller levers when rotated clockwise.

PROPELLER FEATHERING BUTTONS.

Two guarded propeller feathering buttons are on the emergency panel (figure 1-18). Each button is marked FEATHER-PUSH, UNFEATHER-PULL. The action of depressing a button operates the auxiliary pump to supply hydraulic pressure to feather the propeller. During the feathering operation a red light in the button remains illuminated. When the feathering cycle is completed the button is automatically released to the neutral position. After feathering has started the feathering cycle can be stopped by pulling the button out to the neutral position. If this is done before engine speed has dropped below approximately 500 rpm, the blades will return to the pitch corresponding to the rpm setting of the governor. If engine speed has dropped below 500 rpm, the normal unfeathering procedure should be observed. After a propeller has been completely feathered, unfeathering is accomplished by pulling out the button until propeller rotation begins (500-600 rpm) and then releasing it to the neutral position. During the unfeathering operation the

light in the button will illuminate, and will go out when the button is released. Once the propeller is rotating, the blades will return to the pitch setting of the governor.

AUTOFEATHERING SWITCH.

A two-position toggle switch at the left of the emergency panel (figure 1-18) is marked AUTO FEATHERING, ON and OFF. The switch electrically arms the automatic feathering circuit from the main bus through the 5-ampere propeller feather automatic switch circuit breaker. Once the system is armed operation is automatic. Any variation in thrust in excess of $45 \pm 2 \frac{1}{2}\%$ between the two engines will result in automatic feathering of the propeller on the engine developing the lower thrust. When a propeller has been automatically or manually feathered, a blocking relay in the circuit prevents the other propeller from feathering automatically. The auto-feathering system will operate with either or both manual feathering circuit breakers pulled.

NOTE

With thrust indicating system selector in the EMERG OFF position, the thrust indicators are inoperative. However, the autofeather system will operate because the differential pressure switch is connected directly to the thrust indicator pitot heads.

AUTOFEATHERING INDICATOR LIGHT.

A green, press-to-test, indicator light (figure 1-18) adjacent to the autofeathering switch, is powered from the main bus through the 5-ampere propeller feather automatic switch circuit breaker and will illuminate when the autofeathering switch is selected ON, and will go out when the switch is selected OFF. It will also go out if either propeller is feathered while the automatic feathering switch is ON.

PROPELLER FLUID LOW LEVEL LIGHTS.

Two amber lights (figure 1-18), one for each propeller hydraulic system, are located adjacent to the respective feathering button, and are marked PROP OIL. Power is supplied from the main dc bus through the 10-ampere propeller reverse circuit

breaker. A light will illuminate if the oil level in the respective propeller integral oil control drops approximately 3.3 quarts below the fully serviced level of 13.3 quarts.

PROPELLER REVERSE INDICATOR LIGHT.

Two blue lights (figure 1-18), one for each propeller, are mounted on the side panel to the left of the emergency panel, and marked PROP REVERSE. The lights are actuated by the propeller No. 1 blade micro-switch when the blades reach approximately 4 degrees reverse pitch. The power for the system is from the main dc bus through the propeller reverse 10-ampere circuit breaker.

OIL SYSTEM.

Each engine has a separate oil system. Each system consists primarily of an oil tank, an oil cooler, an engine-driven oil pump, and oil emergency shutoff valve, an oil dilution valve, piping and controls for engine lubrication, and oil dilution. The oil tank has a total volume of 29.7 gallons, consisting of 22.2 gallons of oil, 20.4 gallons of which is usable oil, and 7.5 gallons airspace. A flap, adjustable on the ground, is incorporated in the oil cooler air exit duct and is normally set in the down (closed) position except in extreme hot weather conditions. For oil specification and grade, and oil quantity data, see figure 1-19.

OIL EMERGENCY SHUTOFF SWITCHES.

Two guarded oil emergency shutoff switches, one for each engine, are on the emergency panel, (figure 1-18), and each is marked OIL SHUTOFF with the guard marked HYD & ENG. Each switch is electrically connected to the fuel, hydraulic, and oil emergency shutoff valves of its respective engine and, in addition, the respective propeller deicing circuits are routed through the switch. When the switch is selected to the up position, the emergency shutoff valves of that engine are simultaneously closed by power from the emergency bus, through the 7-ampere fuel and oil valve circuit breaker and propeller deicing is rendered inoperative on that side.

OIL DILUTION SWITCHES.

Two oil dilution switches, marked OIL DILUTION, L, R, and OFF and ON, are located at

the extreme left side of the engine switch panel (figure 1-9). They are two-position, momentary-contact, toggle switches spring-loaded to the OFF position. When the switches are held to the ON position the oil dilution valves in the fuel and oil systems are opened by power from the main bus through the 10-ampere starter circuit breaker to allow fuel to be metered into the oil system.

FUEL SYSTEM.

Fuel is carried in two main tanks (figure 1-5) which have a total capacity of 4968 pounds (828 gallons). One tank is located in each outer wing and consists of ten rubber cells interconnected by a manifold which drains into the inboard (No. 1) cell. On some aircraft, the inboard five cells in each wing are of self-sealing construction, with No. 1 cell having an armor plated cell access panel. The total capacity of the two main tanks which incorporate self-sealing cells is 4836 pounds (806 gallons). Fuel is drawn from the inboard cell by an engine-driven fuel pump through a fuel tank selector valve, strainer, and fuel emergency shutoff valve to the engine on the same side as the tank. An electrically driven fuel boost pump in the inboard cell is provided to: (1) augment the engine-driven fuel pump; (2) provide fuel pressure in the event of failure of the engine-driven fuel pump; and (3) provide fuel pressure for crossfeed operation. A crossfeed line and a fuel tank crossfeed valve enable fuel from either tank to be supplied to the engine on the opposite side. Each tank has a filler neck in No. 7 cell, and is vented to the wing undersurface. For fuel specification see figure 1-19. A fuel panel (figure 1-6) in front of the pilot and to the left of the engine instrument panel incorporates the fuel tank selector switch, boost pump switches, fuel quantity indicators, fuel low level warning lights, fuel quantity test switches, and fuel low pressure warning lights. (For long range ferry fuel system refer to Section VII.)

NOTE

On aircraft with T.O. 1C-7A-589 incorporated, polyurethane foam baffles have been added to the fuel tanks to act as an explosion suppressant. This reduces the total capacity of each tank approximately 5 per cent.




Figure 1-5

FUEL TANK SELECTOR SWITCH.

The rotary type fuel-tank selector switch located on the fuel panel (figure 1-6), on some aircraft, has four positions marked, in sequence from the left, OFF, BOTH ON R.H. TANK, NORMAL, and BOTH ON L.H. TANK. On some aircraft the switch has four positions marked, in sequence from the left, OFF, BOTH ON L.H. TANK, NORM, and BOTH ON R.H. TANK. On all Model C-7A aircraft, when the switch is OFF the fuel supply to both engines is shut off; at BOTH ON R.H. TANK fuel is pumped from the right tank to both engines; at NORMAL the crossfeed valve is closed and fuel is fed from each tank to its respective engine; at BOTH ON L.H. TANK fuel is fed from the left tank to both engines. The switch is connected electrically to two motor-driven selector valves and a motor-driven crossfeed valve in the fuel supply lines. Power is supplied from the emergency bus through the 7-ampere fuel and oil valve circuit breaker. A spring-loaded button, to the right of the selector, must be depressed before the switch can be moved to the OFF position. A line schematic of the fuel system is marked on the fuel panel and indicates the fuel flow to the engines both in the normal and crossfeed positions of the switch.

FUEL BOOST PUMP SWITCHES.

Two three-position toggle switches on the fuel panel (figure 1-6) are marked BOOST PUMP; the three positions are marked NORM, OFF, and HIGH. The switch should be in the NORM position for take-off, climb, and landing to insure an adequate fuel supply at normal pressure in the event of failure of the engine-driven fuel pump. For cruising, the switch should normally be in the OFF position. In the HIGH position, sufficient pressure is available, should an engine-driven fuel pump fail, for the normal operation of both engines from one tank. The switches electrically control the actuation of the related fuel boost pumps and are powered from the main bus through the 20-ampere boost pump circuit breakers.

FUEL QUANTITY GAGES.

Two fuel quantity gages are located on the fuel panel (figure 1-6). They are marked USEABLE FUEL and are calibrated from 0 to 3000 pounds in 100 pound increments. The gages are used with electrical capacitance type probes to indicate the amount of usable fuel in the related tanks. Power is

fuel panel - typical




Figure 1-6

supplied by A-phase, 115-volt, 400-cycle ac from the inverter through the 1-ampere fuel quantity fuses.

FUEL QUANTITY INDICATING SYSTEM TEST SWITCHES.

Two button-type test switches (figure 1-6) on the fuel panel, immediately above the fuel quantity gages, are marked SYSTEM TEST and LEFT and RIGHT respectively. When the switches are pressed, the pointers in the related fuel quantity gages should fall to zero.

FUEL LOW LEVEL WARNING LIGHTS.

Two amber press-to-test fuel low level warning lights, one for each tank, are located on the fuel panel (figure 1-6) and marked LOW LEVEL. The warning lights are set to illuminate when the fuel in the relevant tank drops below 110 pounds (100 pounds when self-sealing tanks are installed). Power is supplied from the emergency bus through the 5-ampere engine instrument circuit breakers.

FUEL EMERGENCY SHUTOFF SWITCHES.

Two guarded emergency switches marked FUEL SHUT OFF are located on the emergency panel (figure 1-18). Each switch is connected to a shutoff valve in the fuel supply line to its respective engine. When selected up, the respective shutoff valve is closed. Power is supplied from the emergency bus through the 7-ampere fuel and oil valves circuit breaker.

ELECTRICAL POWER SUPPLY SYSTEM.

The electrical power supply system is primarily a 28-volt direct current installation. It is supplemented by a 115-volt, 400-cycle alternating current installation, powered by the dc system through an inverter.

DIRECT CURRENT POWER SUPPLY SYSTEM.

The dc system is a 28-volt, single conductor system grounded to the aircraft structure. Power is supplied by two engine-driven, 300-ampere, 30-volt generators regulated to a nominal 28 volts, with a 24-volt, 34-ampere-hour battery as a standby source; and through an external power supply for ground operations. Power is distributed through a multiple bus network consisting of a main, secondary, emergency and battery bus (figure 1-7).

Generator Switches.

Two generator switches are located on the D.C. electrical power panel (figure 1-11) in front of the copilot's position and are marked L.H. GEN and R.H. GEN respectively with positions marked ON, OFF and RESET. With the switch at ON the respective generator will be connected to the main bus, provided the generator output is 0.35 to 0.70-volt greater than the main bus voltage. The RESET position of the switch activates the tickler to restore the generator field circuit if the generator field relay trips "due to excessive voltage" (32-34) in the system. When the generator drops off the line due to an undervoltage condition, it will automatically return to the line when the proper voltage is restored.

Generator Warning Lights.

Two generator press-to-test red warning lights marked GEN WARN, are located adjacent to their respective generator switches on the D.C. electrical power panel (figure 1-11). The appropriate light will illuminate if the output of the respective generator does not exceed the main bus output by 0.35 to 0.70-volt. The lights intensity can be controlled by the warning lights intensity switch. The generator warning lights circuit is protected by the 5-ampere circuit breaker marked GEN WARN LIGHTS on the D.C. POWER section of the circuit breaker panel. (See figure 1-10.)

Voltmeters.

Two voltmeters marked DC, one for each generator, are located above the D.C. electrical power panel (figure 1-11), and indicate the main bus voltage and the amperage (or load) on the respective generator. Each indicator has two scales, one marked VOLTS and the other AMPS. Red and black colored test jacks, marked VOLTmeter, LH AMMETER and RH AMMETER, are located adjacent to the flight compartment heating control panel.

Battery.

A 24-volt, 34-ampere-hour nickel cadmium battery and a sump jar, are located below the flight compartment floor. (See figure 1-1.) Access is gained through a hatch in the flight compartment floor hatch well.

Battery Master Switch.

The guarded battery master switch is located on the engine switch panel, (figure 1-9), and is marked BATTERY MASTER and OFF at the up and down positions respectively. With the switch in the BATTERY MASTER position, the battery energizes the main bus if generator output voltage is less than battery voltage. With the switch in the OFF position the battery supplies power to the battery bus only. With the battery master switch OFF and the EMERG BUS SW. (figure 1-10) at EMERG., the battery is directly connected to the emergency bus.

Main Bus.

The main bus distributes power necessary for normal flight operation, and is energized by one or both generators when the appropriate generator switches are ON and a generator voltage output is 0.35 to 0.70-volt greater than the main bus voltage output, or output provided by external power. When the generator output is less than stipulated (e.g. two generator failure) the main bus will be energized by the battery, provided the battery master switch is at BATTERY MASTER.

Secondary Bus.

The secondary bus (figure 1-7) distributes power to electrical equipment considered of secondary importance to flight safety. The secondary bus is energized from the main bus through the secondary bus relay and two bus control relays. Each generator energizes its own bus control relay; should one generator fail, the secondary bus will be deenergized. However, should certain items of electrical equipment supplied by the secondary bus be required for flight, the secondary bus may be supplied from the remaining generator by selecting ON the SEC BUS RESET switch to override the secondary bus relay.

Secondary Bus Reset Switch.

The secondary bus reset switch is located on the circuit breaker panel (figure 1-10) and is marked SEC. BUS RESET. The switch is guarded and when the guard is down the switch is OFF. If a generator fails, the guard and switch may be selected up to override the secondary bus relay and allow the selection of services normally powered from the secondary bus.

Emergency Bus.

The emergency bus distributes power to items of electrical equipment considered essential to flight safety, and is normally powered from the main bus. Should failure of both generators cause main bus power to fail, then the battery will automatically supply the main bus, and thus the emergency bus also. Under these conditions battery power should be conserved by switching the EMERG BUS SW. to EMERG. and the BATTERY MASTER switch to OFF. This will deenergize the main bus and allow the emergency bus to be supplied directly from the battery.

Emergency Bus Switch.

The emergency bus switch is located on the circuit breaker panel (figure 1-10) and is marked EMERG BUS SW. with positions EMERG. and NORMAL. In the NORMAL positions, the main bus supplies the emergency bus; in the EMERG. position the emergency bus is connected directly to battery power.

Battery Bus.

The battery bus (figure 1-7) is energized from the battery and supplies power to the flight compartment dome and the utility light on the overhead console.

Circuit Breakers.

The main circuit breaker panels are located on the forward face of the flight compartment rear bulkhead aft of the pilots position. Radar circuit breakers are located in the top right corner of the same bulkhead. Heater circuit breakers are located on the heater control panel on the left top side of the same bulkhead. An HF power control circuit breaker is located on the left radio shelf under the hydraulic reservoir. The cargo compartment utility and static line retriever circuit breaker is located on the left side of the cargo compartment at the extreme forward end. The cargo door and ramp door circuit breakers are located in the ceiling at the aft end of the cargo compartment on the ramp and door control panel. All circuit breakers are of the thermal, push-to-reset type.

External Power Receptacle.

The external power receptacle (figure 1-20) is located on the left side of the fuselage adjacent to

dc electrical system- schematic-typical




Figure 1-7 (Sheet 1 of 2)

dc electrical system-schematic-typical



Figure 1-7 (Sheet 2 of 2)

ac electrical system-schematic-typical




Figure 1-8

the main gear. An access door protects the receptacle when not in use. When an external power source is connected to the receptacle the main, secondary, and emergency dc buses are energized.

DC Utility Receptacle.

Four covered dc utility receptacles are provided in the aircraft, one in the flight compartment on the right side near the floor doors, one on the left forward side of the cargo compartment under the static line retriever storage mounts, one on the interior lights panel facing the left passenger door, and one in the tail section aft of the cargo door opening. The flight compartment receptacle is powered from the main bus and is protected by the 10-ampere circuit breaker marked FRONT; the two rear receptacles are powered from the secondary bus and are protected by the 20-ampere circuit breaker marked REAR. The forward fuselage receptacle is powered from the main bus and protected by a 50-ampere circuit breaker marked UTILITY RETRIEVER.

ALTERNATING CURRENT POWER SUPPLY SYSTEM.

The ac power supply system consists of three 115-volt, 400-cycle, 3 phase inverters and one single phase 400-cycle inverter, which converts 28-volt dc to 115-volts ac power.

MAIN/STANDBY INVERTER.

The main/standby inverters provide power to the ac instrument buses (figure 1-8). The main and standby inverters are powered from the emergency bus. With these two buses energized, automatic changeover from the main to standby inverter takes place if the main inverter fails, or if the external power source is disconnected from the aircraft when the engines are inoperative and the inverter switch and battery master switch are at MAIN and BATTERY MASTER. On some aircraft the main and standby inverters are powered by the emergency bus. Automatic changeover on these aircraft only occurs when the main inverter fails. The circuits are protected by 25-ampere circuit breakers labeled INVERTER POWER MAIN and STANDBY.

WEATHER RADAR INVERTER.

The weather radar inverter, 115-volt, 400-cycle, 3 phase, is powered by the main dc bus and provides ac power to operate the weather radar system.

TACAN/RADAR ALTIMETER INVERTER.

The tacan/radar altimeter inverter, 115-volt, 400-cycle, single phase, is powered by the main dc bus and provides power to operate the tacan/radar altimeter system.

electrical switch panels-typical






Figure 1-9

Inverter Switches.

The main/standby inverter switch is a three-position toggle switch located on the A.C. electrical power panel (figure 1-11) in front of the copilot's position. The switch is marked A.C. INVERTER with positions marked MAIN, OFF, and STBY. When selected to MAIN or STBY the inverter energizes the ac instrument buses. When the switch is selected to OFF, both inverter circuits are deenergized. The tacan/radar altimeter inverter switch is located on a panel below the main standby inverter switch (figure 1-11) and is marked A.C. 750VA INVERTER. The weather radar inverter is controlled by either the RADAR MASTER switch or the RADAR INVERTER switch, either of which is located on the sliding radio console (figure 4-9).

AC Failure Light.

In conjunction with the main/standby inverters an ac failure warning light marked FAILURE is located on the A.C. power panel (figure 1-11). The light will illuminate if the inverter switch is at OFF, if the inverter switch is at STBY and the standby inverter fails, or if the inverter switch is at MAIN and both inverters fail. The light circuit is protected by the 3-ampere circuit breaker marked FAILURE LIGHT on the INVERTERS section of the circuit breaker panel.

AC Standby Inverter Light.

An ac standby light marked STANDBY is located on the A.C. electrical power panel (figure 1-11). The light will illuminate when the main inverter fails and the standby inverter comes into operation, and also when the inverter switch is in the STBY position. The light circuit is protected by the 5-ampere circuit breaker marked RELAYS STANDBY on the INVERTERS section of the circuit breaker panel.

Tacan/Radar Altimeter Inverter AC Failure Light.

An ac failure warning light marked FAILURE is located on the tacan/radar altimeter control panel (figure 1-11) marked A.C. 750VA INVERTER. The light will illuminate if the inverter switch is ON, but the output of the inverter is not within normal voltage limits.

Alternating Current Instrument Transformers.

Two 115/26 volt ac instrument transformers, main and standby, reduce the 115-volt ac supply from the inverter to provide 26-volt ac for the flight and engine instruments. Two one-ampere fuses, MAIN and STBY, protect the circuits to each transformer against overload.

Instrument Transformer Selector Switch.

An instrument transformer switch on the ac fuse panel (figure 1-10) is marked INST. XFMR., with positions MAIN and STBY. Malfunction of the main instrument transformer will be indicated by illumination of the 26 V.A.C. failure light. Positioning of the selector switch to STBY. will allow the instruments to be powered through the standby instrument transformer.

Instrument Transformer Failure Light.

An instrument transformer failure light on the copilot's flight instrument panel (figure 1-16), is marked 26 V.A.C. The light will illuminate if the 26-volt ac power from the selected instrument transformer fails.

HYDRAULIC POWER SUPPLY SYSTEMS.

The normal hydraulic system (figure 1-12) is primarily powered by two engine-driven hydraulic pumps, one on each engine, which supply fluid at pressure from the hydraulic reservoir to operate the landing gear, wing flaps, wheel brakes, and nose wheel steering circuits. In the event of a malfunction of the engine-driven pumps, or when they are inoperative, power can be supplied for operation of all the circuits of the normal hydraulic systems by means of a manually-actuated hydraulic handpump in the flight compartment, provided the handpump selector (figure 1-14) is positioned at NORMAL SYSTEM. In the event of low fluid level in the hydraulic reservoir, or malfunctioning of the system, the handpump can be used to supply power for the emergency system, provided the handpump selector is positioned at EMERGENCY SYSTEM. In this condition the handpump draws fluid from the emergency reserve level of the hydraulic reservoir to replenish the wheel brakes hydraulic accumulator and to extend the nose gear, provided the brake accumulator handpump charging and nose gear down handpump selectors are at ON.

circuit breaker and fuse panels -typical




Figure 1-10

NORMAL HYDRAULIC SYSTEM.

The normal hydraulic system consists of the engine-driven hydraulic pumps, hydraulic reservoir, filters, check valves, thermal relief valves, a hydraulic system pressure gage, pressure switches, low pressure warning lights, a pressure shutoff valve, and the handpump. Fluid drawn from the reservoir by the engine-driven pumps is supplied at a regulated nominal pressure of 3000 psi to the actuating cylinders of the various hydraulic circuits, through a series of filters, selector valves, check valves, and restrictors. The handpump is used to supply power in the event of malfunctioning of the engine-driven pumps, or when they are inoperative.

Hydraulic Reservoir And Sight Gage.

The hydraulic reservoir is installed forward of the bulkhead behind the pilot's seat. A sight gage on the reservoir is marked at the full and refill points. The total capacity is 1.8 gallons with 0.28 gallon expansion space. The normal system has 1.17 gallon usable, with 0.35 gallon reserved by a standpipe for emergency use.

Hydraulic Pressure Shutoff Valve Lever.

CAUTION

The hydraulic pressure shutoff valve lever must not be left in an intermediate position. A closed or partially closed valve will cause excessive heating of the hydraulic fluid due to restriction of flow and resultant damage to hydraulic system seals.

The hydraulic pressure shutoff lever is immediately forward of the cabin and flight compartment heating control panels, on the bulkhead behind the pilot's seat. The lever is marked HYDRAULIC PRESSURE SHUT-OFF VALVE with positions marked ON and OFF, the forward position of the lever being ON and the aft position OFF. In the event of a serious loss of fluid in flight, selection of the lever to OFF shuts off the hydraulic fluid supply to all circuits. The fluid in the wheel brake system, however, will permit the brakes to be operated enough times for a normal landing, provided the brake hydraulic pressure gage is registering near normal pressure before applying the brakes.

ac-dc power panels




Figure 1-11

Hydraulic System Pressure Gage.

The hydraulic system pressure gage mounted on the pilot's pedestal (figure 1-13), is remotely operated by an electro-hydraulic pressure transmitter connected to the pressure line of the normal hydraulic system. Power is taken from the 26-volt, 400-cycle, ac bus, protected by a 1-ampere fuse labeled ENG. INST. RIGHT. The gage is marked SYSTEM HYDRAULIC PRESSURE and is calibrated from 0 to 4000 psi.

hydraulic system-schematic




Figure 1-12

Hydraulic Low Pressure Warning Lights.

Two hydraulic low pressure amber warning lights are mounted above the hydraulic pressure gage on the pilot's pedestal (figure 1-13) and are marked HYDRAULIC PUMPS, LOW PRESSURE, and LEFT and RIGHT respectively. The press-to-test lights are powered from the main bus and will go out when the pressure in their respective systems reaches 1500 psi, and will illuminate when the pressure drops to 1100 psi. The lights are protected by a 5-ampere circuit breaker labeled PRESS WARN HYD OIL. Malfunctioning of one pump does not appreciably affect the system except for a slight increase in retraction time of the landing gear and does not, therefore, constitute an emergency. The low pressure warning lights are provided to give an indication that a pump is defective.

NOTE

The low pressure warning lights may flicker during gear extension under certain conditions, but a momentary flicker does not indicate a fault in the system.

EMERGENCY HYDRAULIC SYSTEM.

The emergency hydraulic system consists of the hydraulic handpump and four selector valves (figure 1-14). The four selector valves are for nosewheel down, brake accumulator charging, landing gear emergency down, and system selection. The system is used, in the event of low fluid level in the hydraulic reservoir or malfunctioning of the normal hydraulic system, to supply fluid at pressure from the emergency reserve level of the reservoir to replenish the wheel brakes hydraulic accumulator and to extend the nose gear. Before the system can be used, the handpump selector must be positioned at EMERGENCY SYSTEM and each of the other three selectors at ON as desired.

Hydraulic Handpump And Handle.

The hydraulic handpump is beneath an access door in the flight compartment floor at the forward left side of the sliding console (figure 1-14). The removable handpump handle is stowed in clips on the back of the copilot's seat and, when inserted into the handpump socket, can be actuated with a fore-and-aft motion to supply pressure to the hydraulic system.

Hydraulic Handpump Selector.

The hydraulic handpump selector on the hydraulic emergency selector panel (figure 1-14) is marked HAND PUMP SELECTOR, with positions NORMAL SYSTEM and EMERGENCY SYSTEM. When positioned at NORMAL SYSTEM, the hydraulic handpump can be actuated to supply pressure to the normal hydraulic system in the event of malfunction of the engine-driven pumps or when they are inoperative. When positioned at EMERGENCY SYSTEM, the handpump can only be used to replenish the wheel brakes hydraulic accumulator and to extend the nose gear, provided their selectors are at ON. When the panel cover is raised, an internal microswitch activates two lights powered from the emergency bus through a 5-ampere circuit breaker labeled UTILITY.

NOTE

The emergency hydraulic system does not extend the main gear. The main gear emergency extension is mechanically actuated.

FLIGHT CONTROLS.

The primary flight control surfaces consist of ailerons, elevators, and rudder. They are actuated mechanically from either the pilot's or copilot's position by interconnected and convention wheel-type control columns and rudder pedals. The range of aileron movement, however, varies in accordance with the position of the wing flaps. Trim tabs, operated from the flight compartment, are located on the right outboard aileron, the elevators, and on the rudder. An artificial stall warning system is incorporated.

CONTROL COLUMN.

A control column with a W-type control wheel (figure 1-2, sheet 1) is provided at both the pilot's and copilot's positions. Movement of the control column fore or aft mechanically actuates the elevators and controls the aircraft in the pitching plane. Rotation of the control wheel mechanically actuates the ailerons and provides lateral control of the aircraft. A momentary contact aileron trim tab switch, a microphone switch, and space provision for an automatic pilot release button are provided on the outboard handgrip of each control wheel.

pilot and copilot pedestals




Figure 1-13

AILERON TRIM SWITCH.

The momentary contact aileron trim tab switch on the control wheel (figure 1-2, sheet 1) is marked L/W DWN and R/W DWN with arrows indicating the direction of movement. The switch electrically operates the trim tab, hinged to the right outboard aileron, through an actuator in the aileron powered from the secondary bus, protected by a 5-ampere circuit breaker labeled AILERON TRIM TAB. The deflection of the trim tab is shown on the aileron trim tab position indicator.

AILERON TRIM TAB POSITION INDICATOR.

The aileron trim tab position indicator is located on the overhead console (figure 1-3). The indicator is operated electrically, and is powered from the secondary bus through the aileron trim tab circuit breaker. The pointer moves over a scale graduated in increments of 3.75° and shows the deflection of the trim tab. The extremities of the scale are marked L and R. Tab travel is: UP $15^\circ \pm 1^\circ$, DOWN $15^\circ \pm 1^\circ$.

ELEVATOR TRIM TAB HANDWHEEL.

The elevator trim tab handwheel is mounted on a pedestal at the right of the pilot's seat (figure 1-2, sheet 1). Rotation of the handwheel mechanically actuates the elevator trim tabs. The position of the elevator trim tabs is indicated by a pointer in a window at the top of the pedestal which is marked NOSE DOWN (forward), TAKE-OFF RANGE, and NOSE UP (aft). Each indicator graduation represents 5° of tab travel. Tab travel is: UP $10^\circ \pm 1^\circ$, DOWN $20^\circ \pm 1^\circ$.

RUDDER PEDALS.

Rudder pedals (figure 1-2, sheet 1), which mechanically operate the rudder, are provided at both the pilot's and copilot's positions. Toe brake pedals, which are an integral part of the rudder pedals, are located immediately above them. Each rudder bar can be adjusted for reach by a handle marked RUDDER PEDAL ADJUSTER, on the pedestals in front of the pilot's and copilot's positions.

RUDDER TRIM TAB HANDWHEEL.

The rudder trim tab handwheel on the overhead console (figure 1-3) is marked RUDDER TRIM. Rotation of the handwheel mechanically actuates

the rudder trim tab. The position of the trim tab is indicated by a pointer moving over a scale adjacent to the handwheel. The scale is graduated in increments of 7.5° of tab travel, and is marked LH at one end and RH at the other. Tab travel is: LEFT $15^\circ +2^\circ -1^\circ$, RIGHT $15^\circ +2^\circ -1^\circ$.

CONTROLS GUST LOCK HANDLE.

The gust lock handle is located immediately forward of the throttles on the overhead console (figure 1-3). The handle is marked CONTROLS LOCK, with two positions marked UNLOCKED forward and LOCKED aft. When in the LOCKED position with the aileron and rudder controls neutral and the control column forward, the controls will mechanically lock. The gust lock handle prevents the throttles being advanced beyond a position allowing approximately 1600 rpm. A trigger on the gust lock handle must be pulled down before the handle can be released from the locked or unlocked positions.

WING FLAPS.

A double-slotted full-span type wing flap system is actuated by pressure supplied from the normal hydraulic system (figure 1-12) to a wing flap actuator in the cargo compartment roof; movement is then transmitted from the actuator through mechanical linkage to the flaps. Operation of the wing flaps is controlled by the wing flap selector lever in the flight compartment, through an internal follow-up valve which allows the flaps to be positioned at any point within flap range. Movement of the flaps is indicated on the wing flap position indicator in the flap compartment. Since the ailerons droop with the lowering of the flaps, the range of aileron movement varies in accordance with the position of the flaps. Movement of the flaps is also mechanically transferred to the horizontal stabilizer so that it trims automatically throughout the full flap range. Wing flaps are held mechanically in the UP position, and hydraulically in all other positions.

WING FLAP SELECTOR LEVER.

The wing flap selector lever is located in the overhead console (figure 1-3). A spring-loaded button is inset in the lever handle. The lever is marked FLAPS and has the normal operating settings marked 15° to 40° in 5° increments. Detents are provided at the 15° and 20° positions. Operation of the lever actuates the wing flaps

through hydraulic and mechanical linkage, and the movement of the flaps is recorded on the wing flap position indicators. The spring-loaded button in the lever handle must be depressed before the lever can be moved from one position to another.

WING FLAP POSITION INDICATOR.

The wing flap position indicators are on the left side of the pilot's and copilot's flight instrument panels (figures 1-15 and 1-16) adjacent to the airspeed indicator. Each indicator is marked FLAP POSITION and is graduated in 5° increments from 0° to 40°, with numerals at the 10° marks. The indicators are mechanically operated and indicate wing flap position.

STALL WARNING SYSTEM. (Aircraft Not Modified by T.O. 1C-7A-606)

An artificial two-stage, stall warning stick shaker system is incorporated into the flight control

system. Low and high intensity stick shakers are mounted on each control column and are automatically energized during flight as follows; the low intensity shakers at approximately 8 knots above the stall speed, and the high intensity shakers at approximately 4 knots above the stall speed. This warns the pilot and copilot of the approach to the stall by vibration of both control columns. The stick shakers can be energized for test purposes, when the aircraft is on the ground, by means of a test switch. Electrical power for the lift transducers and lift computers is supplied from the 115-volt, 400-cycle, ac-bus, protected by two 1-ampere fuses. High and low stick shaker motors, energized by the lift computers, receive operating power from the dc emergency bus through three 3-ampere circuit breakers labeled STALL WARNING L. LOW, R. HIGH, and LEFT HIGH, and a 5-ampere circuit breaker labeled STALL WARNING HIGH SHAKERS.

through hydraulic and mechanical linkage, and the movement of the flaps is recorded on the wing flap position indicators. The spring-loaded button in the lever handle must be depressed before the lever can be moved from one position to another.

WING FLAP POSITION INDICATOR.

The wing flap position indicators are on the left side of the pilot's and copilot's flight instrument panels (figures 1-15 and 1-16) adjacent to the airspeed indicator. Each indicator is marked FLAP POSITION and is graduated in 5° increments from 0° to 40°, with numerals at the 10° marks. The indicators are mechanically operated and indicate wing flap position.

STALL WARNING SYSTEM.

An artificial, stall warning stick shaker system is incorporated into the flight control system. Stick shakers are mounted on each control column and are automatically energized at approximately 8 knots above the stall speed. This warns the pilot and copilot of the approach to the stall by vibration of both control columns. The stick shakers can be energized for test purposes, when the aircraft is on the ground, by means of a test switch. Electrical power for the lift transducers and lift computers is supplied from the 115-volt, 400 cycle, ac-bus, protected by two 1-ampere fuses. The stick shaker motors, energized by the lift computers, receive operating power from the dc emergency bus through two 5-ampere circuit breakers labeled STALL WARNING L, and R.

The system consists of a two lift transducer, two flap position potentiometers, two lift computer, two stick shakers, and a test switch. The vane of the lift transducers will respond to movement of

the stagnation point as the stall is approached, and change the voltage to the lift computers. The lift computers compensate this voltage for flap position, detected by the flap position potentiometers, and operates the stick shakers to provide a mild vibration of both control columns at approximately 8 knots above the stalling speed. The stick shakers are operative through all flap and power settings.

Stall Warning Test Switch.

A three-position toggle switch on the copilot's instrument panel is marked STALL WARN. TEST. The center (off) position is unmarked, and the other positions are marked LEFT and RIGHT respectively. Selection of LEFT or RIGHT enables a circuit continuity check of the stick shakers to be carried out. The tests also insure that both ac and dc power are available to the systems.

LANDING GEAR.

The landing gear is a tricycle type installation consisting of two main gear units and a steerable nose gear unit. All units are fully retractable and are operated hydraulically (figure 1-12). Each main gear unit consists of a pneumatic shock strut, a drag strut, an up-lock and a down-lock, and a hydraulic retraction actuator that retracts the unit into the engine nacelle. The nacelle doors are mechanically connected to the main gear unit so that on extension and retraction of the gear unit the doors are opened and closed accordingly. Each main gear unit has two 11.00 x 12 wheels, one on each side of the shock strut, equipped with disc type brake units. The nose gear unit consists of a pneumatic shock strut and a hydraulic retraction

actuator that also serves as a drag strut. The actuator retracts the gear unit into a well in the fuselage nose. The doors are opened and closed by a mechanical linkage connected to the shock strut in such a way that the aft doors are closed and the forward fairing remains open when the gear unit is down. The steerable nose gear unit adjusts automatically in the fore-and-aft direction when the nosewheel tires are off the ground. The nose gear unit has two 7.50 x 10 wheels, one on each side of the shock strut. When the landing gear is fully retracted, all units are covered by their respective doors. Selection of the landing gear to either the up or down position is controlled by the landing gear selector lever on the overhead console. The landing gear selector valve, electrically operated by the lever from the emergency bus, is also electrically connected to a weight switch on each gear unit which prevents retraction of the landing gear when the shock struts are compressed. When all units are up and locked, the selector valve is arranged to automatically relieve the hydraulic pressure in the landing gear system. Should a system malfunction occur, the landing gear may be lowered by means of the controls provided for this emergency. These controls include the hydraulic emergency selector panel, the hydraulic handpump and handle, and the main gear emergency extension handle. Refer to Section III for the procedure to be followed for emergency lowering of the landing gear.

LANDING GEAR SELECTOR LEVER.

The landing gear selector lever, on the left side of the overhead console (figure 1-3), is marked LANDING GEAR with positions UP and DOWN, and is electrically connected to the landing gear selector valve through a two-position switch. The selector lever, recognized by its wheel-shaped handle, has a trigger which must be depressed to release the lever locking pawl before the lever can be moved from one position to another. The wheel-shaped handle contains a red warning light. Power for the selector valve and warning light are supplied from the emergency bus through 5-ampere circuit breakers labeled UNDERCARRIAGE HYDR and UNDERCARRIAGE WARN.

LANDING GEAR INDICATOR LIGHTS.

Three green, press-to-test indicator lights are on the electrical switch panel (figure 1-9) and are marked LANDING GEAR and LOCKED DOWN. The

lights are individually marked LEFT, NOSE, and RIGHT and each will come on when its respective gear unit is locked down. The intensity of the lights is controlled by the warning lights intensity switch at the right side of the electrical switch panel. Power is supplied from the main bus through a 5-ampere UNDERCARRIAGE IND. circuit breaker.

LANDING GEAR INDEX MARKS.

A white and red index mark is painted on the inboard side of each main gear locking mechanism, and are visible from the cargo compartment. Alignment of the marks on the individual gear indicates a locked down condition.

LANDING GEAR WARNING HORN AND WARNING LIGHT.

The landing gear warning horn in the flight compartment is powered from the emergency bus and protected by a 5-ampere circuit breaker labeled UNDERCARRIAGE WARN. The horn will sound and the red warning light in the landing gear selector lever handle will illuminate if both throttles are closed to approximately 15 in. Hg, and the landing gear is not locked down.

LANDING GEAR WARNING HORN AND WARNING LIGHT TEST SWITCH.

A two-position toggle switch, spring loaded to OFF, is located on the electrical switch panel (figure 1-9), and is marked HORN TEST. The switch is used for ground testing the operation of the warning horn. If the throttle levers are closed, a test of the warning light in the landing gear selector lever can be made.

NOTE

The tests only check the operation of the horn and light and do not constitute a continuity check of the electrical system.

EMERGENCY LANDING GEAR DOWN SELECTOR HANDLE.

A handle on the emergency hydraulic selector panel (figure 1-14) is marked EMERGENCY LANDING GEAR DOWN SELECTOR with positions OFF and ON. The handle, when moved

emergency hydraulic selector panel




Figure 1-14

to ON, operates a valve which allows hydraulic return fluid from the up side of the landing gear actuators to bypass the landing gear selector valve and enter the common return line to the reservoir. This bypass action allows for any electrical or other malfunction of the landing gear selector valve, which might cause it to remain in the 'up' position. Therefore, for any emergency operation of the main gear or nose gear, the handle must be selected ON. As an additional safeguard this handle overrides the nose gear emergency extension handle, which cannot be pulled until the EMERGENCY LANDING GEAR DOWN SELECTOR is moved to ON.

NOTE

If the EMERGENCY LANDING GEAR DOWN SELECTOR handle is moved slightly out of the OFF position, the landing gear will fail to retract when the landing gear selector lever is placed in the UP position.

MAIN GEAR EMERGENCY EXTENSION HANDLE.

A main gear emergency extension handle, on the bulkhead behind the pilot's seat (figure 1-2, sheet 2) is marked EMERGENCY MAIN GEAR LOWERING PULL TO RELEASE. Pulling the handle mechanically releases each main gear up lock and allows the gear to extend and lock down by gravitational force and slipstream pressure.

NOSE GEAR DOWN HANDPUMP SELECTOR.

A nose gear down handpump selector on the hydraulic emergency selector panel (figure 1-14) is marked NOSEWHEEL DOWN HAND PUMP SELECTOR with positions OFF and ON. When the selector is at ON, the nose gear may be pumped down by actuation of the hydraulic handpump, provided the HAND PUMP SELECTOR is at EMERGENCY SYSTEM, and the EMERGENCY LANDING GEAR DOWN SELECTOR is at ON.

NOSE GEAR EMERGENCY EXTENSION HANDLE.

The nose gear emergency extension handle on the hydraulic emergency selector panel (figure 1-14) is marked NOSEWHEEL EMERGENCY DOWN (AIR) PULL & HOLD UNTIL LOCKED. Before pulling the handle, insure that the EMERGENCY

LANDING GEAR DOWN SELECTOR is at ON. When the handle is pulled, it releases a compressed air charge from an air bottle to force the nose gear down. The handle must be held extended until the nose gear is locked down.

NOTE

The compressed air charge in the air bottle can only be used once in flight. It should be used only as a last resort if the gear unit cannot be extended by the emergency hydraulic system.

NOSE GEAR OBSERVATION WINDOW.

On some aircraft an observation window at the left of the step in the flight compartment permits visual in-flight inspection of the nose gear by a crew member should doubt exist regarding nose gear condition.

NOSEWHEEL STEERING.

CAUTION

Do not attempt to restrain or operate the steering wheel when the steering switch is at OFF. Manual control of the steering wheel in this condition would cause fluid to be emptied from the nose gear shimmy damper during ground maneuvering. Inflight the nosewheel steering system is automatically turned off by the weight switch. Therefore, manual control of the steering wheel will cause the fluid to be emptied from the shimmy damper resulting in a severe shimmy initially on landing.

Ground steering of the aircraft is controlled by a nosewheel steering wheel, through a 62° range of directional movement of the dual nosewheels, when the steering system is operative. The system consists of an electrical nosewheel steering switch, a hydraulic nosewheel steering valve, a hydraulic nosewheel steering actuator, and a nosewheel steering wheel that is connected mechanically to the steering actuator. Selection of the steering switch to ON actuates the steering valve, to allow pressure from the hydraulic system (figure 1-12) to pass to the steering actuator. Movement of the steering wheel mechanically selects the direction

and amount of travel of the actuator, which hydraulically positions the dual nosewheel to the required angle. The system is irreversible so that the dual nosewheels maintain the direction and angle of displacement selected by the steering wheel when the steering switch is at ON. When the nose gear shock strut is fully extended, a weight switch overrides the hydraulic actuator and the dual nosewheels are centered by self-centering cams. When the system is inoperative, steering can be accomplished by differential application of the brake pedals, but turns should be made slowly and at a large radius to preclude imposing excessive side loads on the nose gear unit. The nosewheel steering valve is powered from the emergency bus through a 5-ampere UNDERCARRIAGE HYDR. circuit breaker.

NOSEWHEEL STEERING WHEEL.

The nosewheel steering wheel is on the left side of the flight compartment (figure 1-2, sheet 1) and is marked NOSEWHEEL STEERING. The rim of the wheel has a radial line, denoting nose gear centered, with directional arrows marked LEFT and RIGHT. An indicator pointer attached to the axle of the wheel provides a fixed datum reference.

NOSEWHEEL STEERING SWITCH.

The nosewheel steering two-position switch is above and forward of the nosewheel steering wheel on the left side of the flight compartment (figure 1-2, sheet 1). The switch is marked NOSEWHEEL STEERING with positions marked ON and OFF.

EMERGENCY STEERING SWITCH (A/C MODIFIED BY T.O. 1C-7A-595).

An emergency override switch is installed at the forward end of J-2 Junction box to provide a means of bypassing the nose gear weight switch. This allows the pilot to manually steer the nosewheel in-flight if cocked off-center. The spring loaded toggle switch marked "EMER STEER" must be held in the ON position in conjunction with the nosewheel steering switch "ON" to provide circuit continuity and emergency steering.

WHEEL BRAKES SYSTEM.

The wheel brakes system is controlled from the pilot's and copilot's brake pedals which are connected mechanically and hydraulically to disc

type brakes in the main wheels. The brakes are operated by hydraulic fluid from the wheel brakes hydraulic accumulator, which is supplied with pressure from the hydraulic system (figure 1-12) and is fed through brake control valves and safety valves to the wheel brakes. A parking brake is incorporated in the system. An emergency air system, consisting of an air bottle and an air control valve and a wheel brakes emergency lever, is connected directly to the wheel brakes.


BRAKE PEDALS.

The pilot's and copilot's brake pedals are the upper portions of the rudder pedals in the flight compartment (figure 1-2, sheet 1). The brake pedals are connected mechanically to the wheel brake control valves, and must be depressed to transmit hydraulic pressure to the wheel brakes. The degree of braking action applied to the wheel brakes is dependent on the force exerted on the brake pedals.

PARKING BRAKE HANDLE.

The parking brake handle mounted on the pilot's pedestal (figure 1-13), is a push-pull, turn-to-lock type marked PARKING BRAKE. To apply the parking brakes, depress the brake pedals and pull the parking brake handle fully out, then turn it 90° clockwise to lock it in the extended position. To release the parking brake, the brake pedals should be depressed and, at the same time, the handle turned 90° counterclockwise and pushed fully in.

EMERGENCY WHEEL BRAKES LEVER.



The emergency wheel brakes lever must not be operated with a pumping action otherwise the compressed air supply will be depleted rapidly.

The emergency wheel brakes lever is mounted on the windshield center post (figure 1-2, sheet 1) and is marked EMERGENCY BRAKE. Pulling the handle mechanically operates a valve in the emergency brake air system and allows the compressed air from the air bottle to be applied progressively to the brake discs of the main wheels, in the event of hydraulic system malfunction.

BRAKE ACCUMULATOR HANDPUMP CHARGING SELECTOR.

The brake accumulator handpump charging selector on the emergency hydraulic selector panel (figure 1-14) beneath an access door in the flight compartment floor, is marked BRAKE ACCUM'R HAND PUMP CHARGING with positions OFF and ON. The selector should be positioned at ON and the hydraulic HAND PUMP SELECTOR at NORMAL SYSTEM, in the event of malfunctioning or failed engine driven pumps. The hydraulic HAND PUMP SELECTOR should be at EMERGENCY SYSTEM in the event of low fluid level. Actuation of the handpump will then replenish the brakes accumulator to a safe operating level.

BRAKE HYDRAULIC PRESSURE GAGE.

The brake hydraulic pressure gage mounted on the pilot's pedestal (figure 1-13), is remotely operated by an electro-hydraulic pressure transmitter connected to the pressure line of the brake system. Power is taken from the ac instrument bus through a 1-ampere fuse labeled ENG INST RIGHT. The gage is marked BRAKE HYDRAULIC PRESSURE and is calibrated from 0 to 4000 psi.

INSTRUMENTS.

The pilot and copilot are each provided with a set of flight instruments, each set grouped on a panel directly in front of the individual. One magnetic compass and two clocks are installed.

PITOT-STATIC SYSTEM.

There are two independent pitot static systems, one on each side of the fuselage (figure 1-17). Each system consists of an electrically heated pitot head and below it, two independent static ports. The left pitot head is connected to the pilot's airspeed indicator. The right pitot head is connected to the copilot's airspeed indicator, the two thrust indicators and the fan air pressure switch of the cabin heating and ventilating system. The lower static port of each system is connected to the pilot's airspeed indicator, altimeter and vertical velocity indicator. The upper static port of each system is connected to the copilot's airspeed indicator, altimeter and vertical velocity indicator. Power for pitot head heat is taken from the dc emergency bus through the 15-ampere PITOT INSTRUMENT LEFT and RIGHT circuit breakers and is controlled by the pitot heat switch on the de-icing panel. The lift transducer anti-icing system

is controlled through the pitot heat switch. Refer to Section IV.

NOTE

If a discrepancy occurs between the pilot's and copilot's airspeed indicators, a malfunction in the thrust indicating system or the fan air pressure switch should be suspected. If this occurs, the right pitot head can be isolated from the malfunction and routed only to the copilot's airspeed indicator by selecting the EMERG OFF position of the thrust indicator selector.

Thrust Indicators.**CAUTION**

With the thrust indicator selector in emergency position, the thrust indicators are unreliable.

A thrust indicator (figure 1-4) is installed for each engine. Each indicator is a direct reading type and registers the difference between the dynamic pressure in its respective propeller slipstream and the dynamic pressure in the free-air stream. In addition to the right fuselage pitot head, each instrument has two pitot heads mounted one on each side of its respective engine nacelle. A thrust marker operated by a set knob at the base of the instrument may be preset as desired to provide a reference for maintaining thrust settings. The electrical power for pitot head anti-icing is from the secondary bus, and is protected by 10-ampere circuit breakers labeled PITOTS ENGINE INNER and OUTER.

Thrust Indicating System Selector.**CAUTION**

If the thrust indicator selector is moved to EMERG OFF in flight the heating fan air pressure switch will be inoperative and the cabin heating system will revert to ground mode. In this event the combustion air fan circuit breaker on the CARGO COMPARTMENT HEAT & VENTILATION panel should be pulled to prevent damage to the combustion air fan. To insure that flight compartment heating system remains in flight mode, check that COCKPIT AIR SELECTOR is at FLIGHT position.

pilot's instrument panel-typical




Figure 1-15

copilots instrument panel - typical




Figure 1-16

pitot static system - schematic




Figure 1-17

A two-position thrust indicator selector on the copilot's flight instrument panel (figure 1-16) is marked THRUST IND. FREE STEAM PRESS. with positions NORMAL and EMERG OFF respectively. At NORMAL the free-air pressure at the pitot head on the right of the fuselage nose is fed to the thrust indicators (in addition to slipstream pressure), copilot's airspeed indicator and heating system fan air pressure switch. At EMERG OFF, the free-air pressure is fed only to the copilot's airspeed indicator. This position should be selected (counterclockwise 180°) if a malfunction occurs in the thrust indicating system.

NOTE

Should a discrepancy occur between the readings of the pilot's and copilot's airspeed indicators, a malfunction of the thrust indicators or fan air pressure switch should be suspected.

Airspeed Indicators.

Two sensitive maximum allowable airspeed indicators are installed. The indicated airspeed dial range is from 40 to 400 knots and is graduated in 5 knot increments. The indicated airspeed drum range is from 0 to 100 knots and is graduated in 2 knot increments. The red maximum speed indicating hand is set at 208 knots. When this airspeed indicator is installed, the color coded annular ring, that is mechanically connected to the flap indicator, has been removed.

Altimeters.

Three altimeters are installed, two barometric and one radar. The two barometric altimeters (figures 1-15 and 1-16) are the three-pointer type. The long pointer indicates 100's of feet, the small pointer indicates 1000's of feet and the triangular-tipped pointer indicates 10,000's of feet. A striped low altitude warning symbol is visible at altitudes below 16,000 feet. On altimeters with the low altitude warning symbol at the nine o'clock position, there is an additional 10,000-foot reference. This reference is a white stripe that follows the 10,000-foot pointer around the inner perimeter of the altitude scale. A barometric pressure set knob is located at the bottom left of the instrument and is used to set the barometric scale. The pilot's altimeter is connected in both

lower fuselage static ports while the copilot's is connected to both upper static ports.

WARNING

It is possible to set the altimeter 10,000 feet in error and have the correct setting on the barometric scale. This occurs when the barometric pressure set knob is continuously rotated until the barometric scale is out of view and the scale appears from opposite side. If the correct altimeter setting is then replaced on the barometric scale, the altimeter will be in error by approximately 10,000 feet. To avoid this, always check the ten thousand feet pointer for proper indication when setting the altimeter.

The radar altimeter is installed on the pilot's instrument panel (figure 1-15). Altitude is displayed by a single pointer and is reliable from 0-10,000 feet over land and 0-20,000 feet over water. Reliability is reduced in banks of 60° or more and climb or dives of 70° or more. A reliability circuit disables the indicator and masks the pointer when signals are unreliable.

Vertical Velocity Indicators.

Two vertical velocity indicators are installed (figures 1-15 and 1-16). Each instrument is graduated in hundreds of feet per minute for the first 1000 feet of climb or descent. Thereafter, the scale is graduated in 500-foot increments with the numerals 1, 2 and 3 to indicate thousands of feet per minute climb and descent. The pilot's indicator is connected to both lower fuselage static ports. The copilot's indicator is connected to both upper static ports.

Attitude Indicators.

WARNING

The attitude warning flag is an indication of insufficient electric power only. It does not appear with malfunctions of other components within the instrument. Instruments without an attitude warning flag should not be used for instrument flight until 15 minutes after electric power has been applied.

Two attitude indicators with self-contained gyros are installed, one on each pilot's flight instrument panel (figures 1-15 and 1-16). The pilot's instrument is limited to $\pm 27^\circ$ of pitch and is unlimited in bank. The copilot's instrument, which also supplies radar antenna stabilization signals, is limited to $\pm 70^\circ$ of pitch and 100° of bank. On some aircraft the instruments are automatically erected and erection times vary from 3 to 15

minutes. For instruments having a caging knob, the gyro may be manually erected. Some indicators have an attitude warning flag to indicate insufficient electric power to the instrument. Indicators not having an attitude warning flag can be distinguished by absence of the flag prior to application of power. The miniature aircraft may be adjusted relative to the horizon bar by use of the pitch trim knob. Three-phase, 115 volt, ac



power from the inverter drives each instrument gyro. Two one ampere fuses labeled HORIZON ϕA and ϕC protect each circuit.

Copilot's Attitude Indicator.

The copilot's attitude indicator, in addition to providing normal indications of aircraft attitude, is modified to provide roll and pitch signals for stabilization of the weather radar system antenna (radar on operate or contour modes). The instrument is installed on the copilot's flight instrument panel (figure 1-16) and provides a visual indication of the aircraft's attitude in relation to the horizon. A 115-volt, 400-cycle, three phase ac supply from the radar inverter (with the radar inverter operating) or aircraft inverter drives the instrument gyro. The circuit from the radar inverter is protected by a 2-ampere circuit breaker on the radar power panel, while two fuses on the ac fuse panel protect the aircraft inverter circuit. The miniature aircraft can be adjusted to compensate for pitch trim by means of a pitch trim knob at the lower edge of the instrument. The instrument is limited to indicate 70° in pitch and 100° in bank. The gyro should be caged prior to engine start and approximately one minute allowed after engine start (with inverter switch at MAIN) for the inverter to achieve full output, and for the gyro erection system to begin operation, before uncaging it. Several minutes are required for the gyro to completely erect to true vertical. Low power or power failure to the gyro is indicated by the appearance of a fluorescent disc in the gyro power failure indicator.

NOTE

The gyro should always be caged when inverter output is switched off.

TURN AND SLIP INDICATORS.

Two four-minute turn and slip indicators are installed (figures 1-15 and 1-16). A one-needle width deflection indicates the aircraft is turning one and one-half degrees per second while two needle widths indicate a turn of 3 degrees per second. The ball indicates "quality" of turn, i.e., coordinated, slipping or skidding. The instruments are powered from the 28-volt dc emergency bus.

RADAR GYRO POWER FAILURE INDICATOR.

The radar gyro power failure indicator is a rotating (cup-shaped) disc type indicator and is connected electrically to the input side of the gyro control. One half of the cup-shaped disc is painted black and the other is painted fluorescent. The normal presentation of the indicator is for the black painted surface to be visible to the operator, if however low input voltage or a failure in one or more phases of gyro input power occurs the fluorescent side of the disc will become visible. In the event of gyro power failure indication, the weather radar system should be switched off, automatically the gyro power transfer relay will be deenergized and the gyro will be powered from the aircraft instrument buses.

MAGNETIC COMPASS.

WARNING

When reference to the magnetic compass is necessary, the windshield heat switch must be OFF. With windshield heat ON, the cycling of electric power creates erratic magnetic deviation and causes unreliable magnetic compass indications.

The magnetic compass is mounted on the windshield center post, (figure 1-2, sheet 1) with its correction card immediately above it.

CLOCKS.

Two clocks of the elapsed time, eight-day type are each located on side panels (figure 1-18). A stopwatch knob and a winding/setting knob are at the top-right and bottom-left respectively of each instrument. On some aircraft Type A-13A clocks replace the stopwatch clocks. Each A-13A clock is an eight-day center-second movement, and incorporates an elapsed time, mechanism. An elapsed time, zero-reset flyback knob and a winding/setting knob are at the top-right and bottom-left respectively of each instrument.

OUTSIDE AIR TEMPERATURE GAGE.

A direct-reading outside air temperature gage is installed in the flight compartment roof (figure 1-2, sheet 1) above the pilot's seat and is graduated in degrees Fahrenheit and Centigrade.

SHORT-FIELD APPROACH SPEED INDICATOR.

A short-field approach speed indicator is located on the side panel above the pilot's flight instrument panel. The indicator is calibrated for the final approach phase of a short-field landing, flaps 40°. The instrument dial is marked SLOW and FAST on the left and right side respectively. Alignment of the pointer with the triangle during the final approach represents the optimum airspeed for an aircraft gross weight of 28,500 lb. A diamond shaped index mark on the SLOW side of the dial represents the optimum airspeed for all aircraft gross weights up to 26,000 lb. For gross weights between 28,500 lb and 26,000 lb, short-field approaches are made by positioning the pointer between the two index marks, the exact location being decided by interpolation, depending upon gross weight. For example, at a gross weight of 27,250 lb the optimum approach speed indication would be midway between the two index marks.

NOTE

The approach speeds appropriate to gross weight, as shown in Performance Data T.O. 1C-7A-1-1, may be maintained by use of the indicator.

With flaps at 30°, the approach speed indicator may be used in the same manner as for 40° flap setting. However, because pointer position is related to angle of attack, a specific pointer position at weights below 26,000 pounds will give slightly higher speed margins above the power-off stall at 30° flap than at 40° flap.

The optimum approach speed is determined by the computation of factors supplied by the right wing lift transducer, which compensates for variations in gross weight. Maintaining the pointer in the correct location for gross weight will hold a constant angle of attack. Any change in the angle of attack will affect the location of the airflow stagnation point at the wing leading edge and vary the load on the lift transducer, thus producing a deflection of the indicator pointer to a fast or slow value.

EMERGENCY EQUIPMENT.

Emergency equipment in the aircraft consists of fire detecting and extinguishing systems for the engines and combustion heaters, portable fire extinguishers, an alarm bell system, emergency exits, first aid kits and a crash axe.

FIRE DETECTING AND EXTINGUISHING SYSTEMS.

Fire detecting and extinguishing systems are provided to detect and combat fire in the engine and forward nacelle and the combustion heaters. The engine fire detecting system employs continuous wire-type elements to monitor the engine areas, while the heater fire detecting system employs a bimetal type element in each heater combustion chamber. Power for the detecting system is taken from the 115-volt, 400-cycle ac bus, while dc power is taken from the emergency bus for engine fire extinguishing and from the main bus for heater fire extinguishing. These circuits are protected by two 2-ampere fuses labeled ENG. FIRE DET., two 5-ampere circuit breakers labeled FIRE EXTINGUISHER LEFT and RIGHT, and two 5-ampere circuit breakers labeled FIRE EXTINGUISHER COCKPIT and CABIN.

Freon for the engines and carbon dioxide for the heaters is stored under pressure in containers and is discharged into the overhead area by the operation of the applicable control. All fire controls are grouped on the emergency panel in the flight compartment. Indicator discs are provided on the outside of the aircraft for ground checking of the container condition. A means of testing the warning lights and the engine fire detecting circuit is provided. For the purpose of engine fire detecting and extinguishing, each engine nacelle is divided into two zones; zone 2 is between the auxiliary and the main firewalls and forms the engine accessories compartment, while zone 3 extends from the main firewall aft to the front spar and includes the main gear well. The fire detecting element monitors only zones 2 and 3 and the extinguishing agent is available only to zones 2 and 3.

Engine Fire Extinguisher Handles.

Two engine fire extinguisher handles, one for each engine, are located on the emergency panel (figure 1-18) in the flight compartment. The handles are

emergency and side panels




Figure 1-18

marked FIRE-PULL and incorporate red warning lights. When either handle is pulled a cartridge is electrically detonated and a slug is fired into the appropriate extinguisher container, instantly releasing the extinguishing agent to blanket the fire area in zones 2 and 3 of the appropriate engine. If a second release of extinguishing agent is required, the handle is pushed in and turned 90° counterclockwise and pulled again. In this case the second container will be discharged.

NOTE

Each container can be discharged once only. Therefore, both containers can be discharged into one engine, or each can be discharged into its respective engine.

Engine Fire Warning Lights.

Two engine fire warning lights are incorporated in the engine fire extinguisher handles (figure 1-18), marked RIGHT ENGINE ZONES 2 AND 3 and LEFT ENGINE ZONES 2 AND 3 respectively.

NOTE

When a warning light illuminates to indicate an overheat condition it will go out when the condition no longer exists. The light will illuminate again if a further overheat condition occurs.

Engine Fire Detection Test Switch.

A toggle switch marked FIRE DETECTION, is located in the center of the emergency panel (figure 1-18). The switch is spring-loaded to the down (off) position. When held (up) in the TEST position all engine fire warning lights should illuminate. Failure of the lights to illuminate indicates a fault in the detecting circuit, control units, or individual lights.

NOTE

The test switch is not connected to the heater fire warning lights.

Engine Fire Extinguisher Indicating Discs.

A yellow and a red colored disc are located on the underside of each wing between the nacelle and the fuselage (figure 1-20). When a fire extinguisher

handle is pulled, a plunger operated by the pressure of the extinguishing agent punctures the yellow disc. Should either container reach an excessive temperature, a thermal plug in the container will melt and allow the extinguishing agent to blow out the red disc and exhaust to atmosphere.

HEATER FIRE DETECTING AND EXTINGUISHING SYSTEMS.

The combustion heaters of the flight and cargo compartment heating systems are each provided with a fire detecting circuit and an indicator light, a one-pound bottle of carbon dioxide (CO₂) fire extinguishing agent, and two indicating discs. Each heater fire detecting and extinguishing system is independent of the other, but both function in the same manner. When the temperature in a heater becomes excessive, it causes a bi-metal fire detecting element in the heater combustion chamber to complete an electrical circuit, powered from the main bus, and the appropriate heater fire warning light on the emergency panel in the flight compartment will come on. When the light comes on, the guarded extinguisher switch below the light should be selected to its up position to complete an electrical circuit from the main bus. This energizes a solenoid which actuates a rod on the bottle, mounted on the heater tray, containing the extinguishing agent. The rod unseats the check and main valves at the top of the bottle and the contents pass through piping to the heater combustion chamber, and to a spray ring around the heater inlet duct. At the same time the yellow indicating disc is punched out to show that the extinguishing system has been operated. If the pressure in the bottle reaches a dangerous level, usually due to excessive temperatures, a disc in the flood valve of the bottle will break and the extinguishing agent released will blow out the red indicating disc.

Heater Fire Extinguisher Switches.

CAUTION

The heater air control handles should be selected to close the air supply ducts when a heater fire is indicated.

Two guarded heater fire extinguisher switches are provided below their respective warning lights on the emergency panel (figure 1-18) in the flight

compartment. Selecting the appropriate switch operates a solenoid valve to release extinguishing agent in the heater combustion chamber and from a spray ring around the heater inlet duct.

Heater Fire Warning Lights.

Two press-to-test heater fire warning lights are mounted on the emergency panel (figure 1-18). The lights are marked FIRE CONTROL, COCKPIT HEATER FIRE WARN, and FIRE CONTROL, CABIN HEATER FIRE WARN respectively. The appropriate light will illuminate when an overheat condition exists in either the flight compartment or cargo compartment heater.

Heater Fire Extinguisher Indicating Discs.

A yellow and a red colored disc are provided for both the flight compartment and cargo compartment heater fire extinguishing systems. The two discs for the flight compartment are on the left side of the aircraft nose while those for the cargo compartment are on the right side of the fuselage, forward of the wing. The discs indicate in a similar manner to the engine fire extinguisher indicating discs.

PORTABLE FIRE EXTINGUISHERS.

Three Type CF3Br portable fire extinguishers are mounted in quick release clips, one below the pilot's seat, one on the aft face of the cargo compartment forward bulkhead, and one on the left cargo compartment wall immediately aft of the cargo compartment passenger door. The extinguishing agent is released when the hand-operated lever at the top of the extinguisher is depressed.

EMERGENCY EXITS.

Two emergency exits are provided in the flight compartment and four in the cargo compartment.

Flight Compartment.

The flight compartment exits consist of a hatch in the roof, immediately aft of the pilot's position, and a bottom hatch in the well behind the pilot's

and copilot's seats. Access to the bottom hatch is gained by opening the two doors in the flight compartment floor. The hatch may then be opened by pressing a button and turning a handle, marked EXIT RELEASE-PRESS BUTTON AND TURN HANDLE, located on the aft part of the hatch. The hatch may be jettisoned, if required, by operating a handle located in a recess in the bulkhead above the doors and marked BOTTOM HATCH JETTISON - OPEN INSIDE DOORS BEFORE PULLING HANDLE. The upper doors must be opened first as they would be difficult to open during flight with the lower hatch jettisoned. The roof hatch is opened by pressing a button adjacent to the handle and turning the handle, located on the roof at the hatch, marked EXIT RELEASE - PRESS BUTTON AND TURN HANDLE. The roof hatch is hinged on the right-hand side and is not jettisonable. A webbing strap marked EMERGENCY SLIDE is fitted below the roof hatch on the bulkhead and is provided to aid escape from the flight compartment. The flight compartment bottom hatch may be used for exit during flight but the roof hatch, due to its proximity to the propellers, is for use on the ground only with the engines stopped.

Cargo Compartment.

The cargo compartment emergency door, on the left side near the wing leading edge is jettisonable. The handle is marked EMERGENCY EXIT - LIFT GUARD AND TURN HANDLE TO OPEN. The right passenger door is jettisonable, and has a jettison lever handle above the door marked CABIN DOOR JETTISON - PULL LEVER DOWN. The cargo door may be opened but must not be jettisoned during flight. The left passenger door is not jettisonable. The cargo door may be jettisoned, on the ground to provide an additional emergency exit. The cargo door is jettisoned by pulling a handle, located on the left side of the cargo compartment aft of the passenger door, marked CARGO DOOR JETTISON - LIFT GUARD AND PULL HANDLE. When the cargo door is jettisoned, the draftproof door is automatically retracted. The cargo door may also be jettisoned from outside the aircraft by a handle, located on the right side of the fuselage aft of the passenger door, marked CARGO DOOR JETTISON - OPEN HATCH AND PULL HANDLE.

MISCELLANEOUS EQUIPMENT.

The following paragraphs describe the miscellaneous items of equipment in the aircraft.

First Aid Kits.

Four first aid kits are provided, one in the flight compartment and three in the cargo compartment. The flight compartment kit is in a stowage above the access ladder on the left side. The cargo compartment kits are in brackets attached to the cargo compartment walls, one on the left side aft of the emergency door, one on the left side forward of the passenger door, and one on the right side forward of the passenger door.

Crash Axe.

A crash axe for emergency use is mounted on the flight compartment bulkhead, in the cargo compartment to the left of the interconnecting door. The axe is strapped into position by Velcro tape which fastens around the handle, and is released by peeling one end of the tape off the other end.

ENTRANCE DOORS.

Entrance to the aircraft may be made through either of two passenger doors, a flight compartment bottom hatch, or by the cargo door and ramp.

PASSENGER DOORS.

Two passenger doors at the aft end of the cargo compartment, one on either side, are provided. Both doors are fitted with flush handles which spring out for grasping when a button next to the handle is pressed. Both doors are provided with door-stays to hold the doors open on the ground; the stays are stowed on the inside of each door at a position marked STOWAGE DOOR STAY.

FLIGHT COMPARTMENT BOTTOM HATCH.

Entrance may also be made to the flight compartment by means of the flight compartment bottom hatch. The hatch incorporates a handle similar in operation to the passenger doors. When the flight compartment bottom hatch is opened from the outside, the folding doors in the flight

compartment floor must be pushed upwards to gain access to the flight compartment.

CARGO COMPARTMENT/FLIGHT COMPARTMENT DOOR.

A sliding door separates the flight compartment from the cargo compartment. The door may be opened from either side by pressing down a spring-loaded knob marked OPEN. The door may be locked, from the flight compartment side only, by means of a slide catch marked LOCK ON-OFF. A label on the flight compartment side of the door reads THIS DOOR MUST REMAIN OPEN WHEN CARGO IS CARRIED. The door is held in the fully open position by a lever catch.

Draftproof Door.

A retractable draftproof, semiprigid door separates the cargo compartment from the tail compartment and the cargo door. A strap and a cable are provided as hand grips to be used for extending the door and for aiding spring assists in retracting the door. The door will automatically retract if the cargo door is jettisoned.

SEATS.

The pilot and copilot seats are identical and each is of tubular construction with fiberglass seat pan and cushioned seat. Each seat is adjustable horizontally and vertically and can be located at the required position by means of spring-loaded levers at the sides and front of the seat respectively; arm rests are also provided and are hinged to the side frames of the seat back in such a manner that they can be raised and moved back when not required. Each seat is equipped with a Type MB-2A shoulder harness attached to the Type MA-1 inertia reel or the Type MA-2 multidirectional harness reel. The reel is mounted behind the seat and is controlled by a lock lever at the left side of the seat pan. A Type MD-1 safety belt is attached to the bottom of the seat-back assembly. A hand-hold above each windshield is provided for use when vacating the seat.

HORIZONTAL ADJUSTMENT LEVERS.

The flight compartment seats can be individually adjusted horizontally through a range of four inches and locked at any one of five positions by means of two interconnected levers, one at each

side of the seat base. The levers are spring-loaded to the down position, and pulling either of them up mechanically withdraws two eyebolts from their engagement holes in each guide rail and allows the seat to be moved forward or aft to the desired position. Releasing the spring-loaded levers allows the eyebolts to engage with the holes nearest to that position when the seat is readjusted slightly forward or aft.

VERTICAL ADJUSTMENT LEVER.

The flight compartment seats can be individually adjusted vertically through a range of seven inches and locked at any one of seven positions by means of a lever pivoted at the left side under the front of the seat pan, and spring-loaded to the aft position. Pulling the lever forward from the right side mechanically withdraws two eyebolts from their engagement holes in the frame assembly bottom slides, and allows the seat to be moved upward under the influence of two springs, or downward under the influence of the occupant's weight, to the desired position. Releasing the spring-loaded lever when the desired height is reached allows the eyebolts to engage with the holes nearest to that position. Insure that eyebolts are securely engaged.

SHOULDER HARNESS REEL LOCK LEVER.

WARNING

When the shoulder harness reel lock lever is in the forward position at manual lock, leaning forward is restricted. Therefore, prior to an emergency landing, all the required switching operations should be carried out before selecting manual lock.

A two-position shoulder harness reel lock lever, with quadrant assembly, is attached to the left side of each pilot's seat pan. The lever is used to actuate the reel mechanism into the "manual lock" (lever forward), or the "automatic lock" (lever aft), position. In the manual lock position the seat occupant is restrained against any forward or sideways movement, and this position is used for crash landing or ditching. In the automatic lock position the seat occupant may lean forward 18 inches, if desired. In aircraft fitted with the Type MA-1 reel, should an inertia force of between 2 and 3g be subjected to the aircraft, the reel will lock and prevent the seat occupant from being thrown forward. It will also lock at increased 'g' increments, within a 120° forward arc. In aircraft fitted with the Type MA-2 reel, should an acceleration be imparted to the seat occupant, in any direction, of between 2 to 3g, the reel will lock and prevent the seat occupant from being thrown forward or sideways. In both types of reel, after being locked automatically, unlocking is carried out by moving the reel lock lever fully forward and then fully aft. This will return the reel to the automatic lock position.

AUXILIARY EQUIPMENT.

Equipment not directly contributing to the flight of the aircraft, but which enables the aircraft to perform certain specialized functions, is described in Section IV. The following systems and equipment are covered:

1. Heating and Ventilating Systems.
2. Deicing System.
3. Oxygen System.
4. Lighting Equipment.
5. Alarm Bell System.
6. Ignition Analyzer
7. Winterization Equipment.
8. Radios.
9. Navigation Equipment.
10. Radar.

servicing data

FUEL QUANTITY					
FUEL TANK (STANDARD OR SELF-SEALING)			FULLY SERVICED GAL	FUEL* POUNDS	USABLE IN LEVEL FLIGHT (APPROX) GAL
NORMAL	LEFT WING TANK	STANDARD	414	2484	414
		SELF-SEALING	403	2418	403
	RIGHT WING TANK	STANDARD	414	2484	414
		SELF-SEALING	403	2418	403
	TOTAL (NORMAL CONFIGURATION)	STANDARD	828	4968	828
		SELF-SEALING	806	4836	806
FERRY	FORWARD TANK		480	2880	480
	REAR TANK		480	2880	480
	TOTAL (MAXIMUM FOR FERRY)		1,788	10,728	1,788

NOTE

USABLE FUEL CAPACITY FOR LEFT AND RIGHT WING TANKS IS REDUCED APPROXIMATELY 5 PERCENT ON AIRCRAFT WITH T.O. 1C-7A-589 INCORPORATED.

*FUEL WEIGHT IS BASED ON 6.0 POUNDS PER GALLON UNDER STANDARD DAY CONDITIONS AT SEA LEVEL. TOTAL WEIGHT OF FUEL DEPENDS ON SPECIFIC GRAVITY AND THE TEMPERATURE. THE FUEL QUANTITY GAGES DO NOT HAVE THE NOTATION FULL, AND VARIATIONS IN GAGE READINGS SHOULD BE ANTICIPATED WHEN THE TANKS ARE FULL.

OIL QUANTITY			
EACH MAIN OIL TANK	GAL	AUXILIARY OIL TANK	GAL
USABLE OIL AIRSPACE	20.4 7.5	(USED WITH LONG RANGE FERRY TANKS)	
SUMP (TRAPPED TO ENGINE BUT DRAINABLE)	1.8	USABLE OIL	18.0
TOTAL TANK VOLUME	29.7		

NOTE


22.2 GAL OIL ARE REQUIRED TO REPLENISH A TANK AFTER A COMPLETE OIL CHANGE.

FLUID SPECIFICATIONS

FUEL:	MIL-G-5572, GRADE 115/145
ALTERNATE FUEL:	MIL-G-5572, GRADE 100/130
OIL:	MIL-L-22851, TYPE II, GRADE 1100
HYDRAULIC FLUID:	MIL-H-5606
DEICING FLUID:	TT-I-735
PROP DEICER FLUID:	TT-I-735
ENGINE FIRE EXTINGUISHER FLUID:	FREON 13B1 AND 13B2 (TROPICAL)

Figure 1-19

servicing diagram



1. FUEL TANK
2. FUEL TANK GROUNDING JACK
3. FUEL TANK FILLER NECK
4. PROPELLER DEICING SYSTEM RESERVOIR
5. FUEL TANK BOOSTER PUMP AND MANIFOLD WATER DRAINS
6. OIL TANK
7. OIL TANK DRAIN
8. FUEL SYSTEM FILTER DRAIN
9. ENGINE FIRE EXTINGUISHER INDICATING DISCS (ON WING LOWER SURFACE)
10. CABIN HEATER FIRE EXTINGUISHER CONTAINER
11. ENGINE FIRE EXTINGUISHER CONTAINER
12. EXTERNAL POWER RECEPTACLE (LH SIDE OF FUSELAGE)
13. EXTERNAL POWER CART
14. ENGINE DRAIN BOX
15. OIL PRESSURE TRANSMITTER (COLD WEATHER SERVICING POINT)
16. THRUST INDICATING SYSTEM MOISTURE TRAPS
17. HYDRAULIC SYSTEM RESERVOIR
18. BATTERY SUMP JAR

19. BATTERY
20. EMERGENCY OXYGEN CYLINDER AND GAGE
21. HYDRAULIC SYSTEM GROUND RIG CONNECTION POINTS
22. BRAKE ACCUMULATOR, EMERGENCY AIR BOTTLES CHARGING POINTS
23. NOSE GEAR DOWN EMERGENCY AIR BOTTLE
24. FLIGHT COMPARTMENT HEATER FIRE EXTINGUISHER INDICATING DISCS
25. FLIGHT COMPARTMENT HEATER FIRE EXTINGUISHER CONTAINER
26. PITOT STATIC SYSTEM MOISTURE TRAPS
27. OXYGEN CYLINDERS (2) AND GAGE (AIRCRAFT SERIAL NO. 62-4171 AND SUBSEQUENT). RH SIDE ACCESS DOOR.
28. OXYGEN CYLINDER (1) AND GAGE (AIRCRAFT PRIOR TO SERIAL NO. 62-4171)
29. CABIN HEATER FIRE EXTINGUISHER INDICATING DISCS (ON FUSELAGE SIDE)
30. HYDRAULIC FLUID SUMP FILLER PLUGS (NOT SHOWN) FOR REVERSIBLE PROPELLERS ARE LOCATED ON THE TOP LH SIDE OF EACH PROPELLER CONTROL UNIT.

Figure 1-20

SECTION II

NORMAL PROCEDURES

TABLE OF CONTENTS

PREPARATION FOR FLIGHT	2-1
PREFLIGHT CHECKS	2-2
BEFORE STARTING ENGINES	2-17
STARTING ENGINES	2-18
BEFORE TAXIING	2-21
TAXIING	2-25
ENGINE RUNUP	2-28
BEFORE TAKE-OFF	2-31
TAKE-OFF	2-33
AFTER TAKE-OFF/CLIMB	2-36

PREPARATION FOR FLIGHT.

OPERATING RESTRICTIONS.

For operating restrictions and limitation imposed on the aircraft, refer to Section V of this handbook.

FLIGHT PLANNING.

Determine the fuel quantity, power settings, airspeed etc, necessary for the successful completion of the proposed mission by using performance data contained in T.O. 1C-7A-1-1.

TAKE-OFF AND LANDING DATA CARD.

The Take-Off and Landing Data Card is included with the Pilots abbreviated Checklist, T.O. 1C-7A-1CL-1. Prior to each flight, a complete takeoff and landing data card must be completed for those flights departing airfields with less than 3000 feet of available runway, when the density or pressure altitude exceeds 4000 feet, or when gross weight exceeds 28,500 pounds. If these conditions are

CRUISE	2-37
DESCENT	2-38
BEFORE LANDING	2-40
LANDING	2-40
TOUCH AND GO/CLOSED TRAFFIC PATTERN	2-45
AFTER LANDING	2-46
POST FLIGHT ENGINE CHECKS	2-46A
ENGINE SHUTDOWN	2-47
BEFORE LEAVING THE AIRCRAFT	2-49

not present the pilot may elect to complete an abbreviated TOLD card with applicable performance data.

CHECKLISTS.

The Flight Manual contains the normal and emergency procedures. The checklists have been issued as a separate technical order, T.O. 1C-7A-1CL-1. For information pertaining to use of the checklist, refer to AFR 60-9.

The pilot is responsible for the proper use of the checklist. He will insure that it is used in direct reference during ground and flight operations except during take-off, landing, or critical emergencies. (In these instances flight crews will refer to the applicable checklist before performing the operation, or afterward to insure completion of all phases of the operation concerned.) The nomenclature P, CP, FM and LM used hereafter will refer to the pilot, copilot, flight mechanic and loadmaster respectively. The copilot will read the checklist and will not proceed past an item requiring a response until the designated crew

member has responded. If the action taken is to be reported to the person reading the checklist, the action shall be in quotation marks. Action taken that is not in quotation marks indicates that the crew member completes the action and remains silent. When more than one crew member has the same response to the same item, the crew members subsequent to the initial crew member responding need respond only with his crew position. Sequence of response will be in the order as shown on each checklist. There are two categories of checklists: Mandatory — These cover phases of action that shall be performed in conjunction with direct reference to the appropriate checklist. Non-mandatory — These cover phases of action which need not be performed with direct reference to a checklist. The flight crew is required to review these checklists before entering the indicated phase of action or to use them for clean-up purposes after an emergency procedure has been completed.

WEIGHT AND BALANCE

Check the aircraft weight and balance (refer to DD Form 365C in the weight and balance form binder of individual aircraft). Obtain take-off gross weight and loading data. From this and flight information, complete anticipated landing gross weight and MAC index. Weight limitations are covered in Section V. A weight and balance computer is provided with the aircraft. It is the responsibility of the pilot to ascertain that the aircraft has been properly loaded.

ENTRANCE.

The crew will normally enter the aircraft through either of the passenger doors, located in the aft left and right fuselage, or ramp at the rear of the aircraft. However, if necessary, entrance through the roof hatch or bottom hatch in cockpit floor area is permitted.

STANDARD TERMINOLOGY.

To assure complete understanding by all crew members, the following terminology and procedures will be used:

Standard Power Terminology.

1. Max Power
2. METO Power

3. Climb Power

4. Cruise Power

The checklist challenge will be standard terminology. During cruise power changes the pilot will control throttle movement and call for the proper rpm settings by stating desired rpm. Example: "RPM-twenty-one-fifty."

Flap Settings.

Flap settings will be requested in the following manner:

"Flaps thirty."

As Required Items.

Whenever a checklist item is affected by climatic conditions or hours of darkness, AS REQUIRED will be indicated on the checklist for the usual action entry. However, during accomplishment of the checklist, the actual position of the item will be stated.

PREFLIGHT CHECKS.

The visual inspections which must be accomplished prior to flight are the BEFORE INTERIOR INSPECTION, INTERIOR INSPECTION, TOP OF AIRCRAFT CHECK, CARGO COMPARTMENT CHECK, and EXTERIOR INSPECTION. The pilot is responsible for assuring that the visual inspections have been accomplished. The actual accomplishment may be delegated to the copilot or flight mechanic.

NOTE

The basic flight crew consists of a pilot, copilot, and flight mechanic.

NOTE

The pilot is responsible for insuring that the maintenance personnel have performed the dash 6 inspections in accordance with T.O. 1C-7A-6. The visual inspections requirements of this manual are predicated upon this assumption. However, checks of any equipment involving safety are duplicated in the preflight checks.

THRU-FLIGHT INSPECTION.

When the airplane is flown on the same mission, by the same crew, during the same day, and no maintenance or servicing is required, only those items preceded by an asterisk (*) need to be checked. When maintenance or servicing is required, only those systems and interior or exterior checklist inspection items affected need be checked prior to the next flight. All items in the

Before Take-Off and subsequent checklist must be accomplished for all flights. For flights when engines are not shutdown, air crews may proceed from the After Landing Checklist to the Before Take-Off Checklist.

NOTE

An ignition system check should be performed prior to each take-off.

BEFORE INTERIOR INSPECTION.

1. External power unit	In place
2. Fire extinguisher	In place
3. Wheel chocks	In place
4. Gear down locks	Installed
5. Static ground wire	In place
6. Pitot and canopy covers	Removed
7. Before interior inspection checklist	Complete

INTERIOR INSPECTION

1. Forms 781	Checked
a. Status of aircraft	Checked
b. Fuel, oil, deicing fluid, and oxygen service	Checked
2. Form 365F and load adjuster	Checked
3. Navigation publications	Checked
4. Hydraulic panel	Checked
a. Hand pump selector	NORMAL
b. Emergency landing gear down selector	OFF
c. Nosewheel down selector	OFF
d. Brake accumulator charging selector	OFF
e. Nosegear air bottle selector	IN

5. Cockpit air handles	As required
6. Nosewheel steering switch	ON
7. Brake emergency lever	IN/Secure
8. Autofeather switch	OFF
9. Emergency panel	Checked
a. Engine fire extinguisher handles	IN/Horizontal
b. Fuel emergency shutoff switches	DOWN/Guarded
c. Oil emergency shutoff switches	DOWN/Guarded
d. Cockpit heater fire extinguisher switch	DOWN/Guarded
e. Cargo compartment heater fire extinguisher switch	DOWN/Guarded
10. Gyro compass switch	SLAVE
11. Copilot's attitude indicator	CAGED
12. Free stream pressure selector	NORMAL
13. Engine switch panel	Checked
a. Oil dilution switches	OFF
b. Vent door switch	As desired
c. Hot fuel prime switch	OFF
d. Battery switch	OFF
14. Windscreen panel	Set
a. Windshield wiper switch	OFF
b. Windshield heat switch	OFF
15. Flaps	40 degrees

NOTE

Visually check that flaps are in FULL down position. If necessary use hand pump to lower flaps. Use brakes to deplete hydraulic pressure.

16. Ignition switches	OFF
-----------------------	-----

17. Landing gear selector lever

DOWN

18. Gust lock

LOCKED

NOTE

Assure the gust lock is unlocked prior to any flight control check, engine run-up, or take-off.

19. Circuit breaker panel

Checked

a. Circuit breakers

CLOSED

b. Emergency bus switch

NORMAL

c. Secondary bus switch (battery preflight only)

UP

d. FM power switch

OFF

e. Instrument transformer

MAIN

f. Fuse caps

Secure

20. Emergency exit lights

Checked/OFF

21. Seat belt/smoking sign switches

ON

22. Cargo door master switch

ON

23. Main gear emergency handle

Checked/Secure

24. Emergency slide

Checked

25. Heater and ventilation panel

Checked

a. Master switches

OFF

b. Fuel switch

OFF

c. Ignition switches

NORMAL

d. Anti-icing switches

OFF

26. Hydraulic pressure shutoff valve

ON

27. First aid kit

Checked

28. Hydraulic reservoir

Checked

29. Emergency exit jettison handle

Safetied

30. Portable fire extinguisher

Checked

- | | |
|--|-------------|
| 31. Portable oxygen bottle and face mask | Checked |
| 32. Emergency escape exit | Checked |
| a. Inverter and battery access panels | Secure |
| b. Escape hatch release handle | Locked |
| 33. Power | ON |
| a. Battery voltage | Checked/OFF |
| b. External power | ON |

NOTE

When external power is not available the battery will be used to complete the power on checks.

- | | |
|--|---------|
| 34. DC warning, indicating, and press to test lights | Checked |
| a. Propeller reverse/auto feather (3) | |
| b. Emergency panel (6) | |
| c. Doors unlocked (1) | |
| d. Marker beacon (1) | |
| e. Fuel low level/pressure (4) | |
| f. Windshield anti-icing (2) | |
| g. Landing gear (3) | |
| h. Oil low level/pressure (4) | |
| i. Generator/inverter failure (4) | |
| j. 26 volt ac failure (1). | |
| k. Ramp 15° (1) | |
| l. Heater control panel (3) | |
| m. Hydraulic low pressure lights (2) | |

35. Pitot heat

Checked

WARNING

Physically touch the pitot heads for heat. Do not leave the heat applied and wait before feeling the heads as serious burns may result.

36. Propeller anti-icing

Checked (when use is anticipated)

37. Windshield anti-icing

Checked (when use is anticipated)

a. Windshield heat switch

NORMAL

b. Failure lights

Out

c. Windshield heat switch

OFF

NOTE

If the ambient temperature is greater than 81°F (27°C), do not operate windshield anti-icing on the ground.

38. Landing gear warning switch

TEST

NOTE

When the gear warning switch is placed in the test position, the warning horn should blow and the warning light in the gear selector handle should illuminate. Both throttles must be in the closed position during this check.

39. Alarm bell

Checked

40. Troop jump lights

Checked

41. Inverters

Checked

a. Turn switch to MAIN and check both inverter lights are out

b. Turn switch to STANDBY and check the standby inverter light illuminates.

c. Leave the inverter switch on STANDBY

42. Engine fire detector system

Checked

CAUTION

Inoperative fire detection circuits must be corrected prior to flight. Fires in certain accessory areas could develop before detected by other means.

43. Fuel system

Checked

a. Quantity and distribution

Checked

b. Indicating system

Checked

- (1) Press the fuel quantity test button and note a decrease on the fuel gages
- (2) Release the buttons and note the gages return to original settings

c. Crossfeed

Checked

NOTE

When engines are not running, position fuel pumps to NORMAL prior to selecting HIGH to preclude damage to the carburetor diaphragm.

- (1) Turn the left boost pump to NORMAL and check left fuel pressure increases
- (2) Turn the fuel selector to BOTH ON LH TANK and check right fuel pressure increases
- (3) Turn the left boost pump to HIGH and note pressure increases
- (4) Turn the fuel selector to NORMAL and check right fuel pressure decreases
- (5) Turn the left boost pump OFF and check left fuel pressure decreases
- (6) Repeat the procedure with the right boost pump and fuel selector

- | | |
|-----------------------------------|--------------|
| 44. Inverters | OFF |
| 45. Secondary bus switch | DOWN/Guarded |
| 46. Power | As required |
| 47. Interior inspection checklist | Complete |

TOP OF AIRCRAFT CHECK

- | | |
|--|---------|
| 1. Fuselage general condition | Checked |
| a. Antennas | |
| b. Cargo compartment heater ducts | |
| 2. Left wing | Checked |
| a. Oil cooler | |
| b. Top accessory vent door | |
| c. Oil quantity | |
| d. Oil tank filler cap dipstick and access cover panel | |
| e. Propeller deicing quantity, filler cap and access panel | |
| f. Fuel tank filler cap and access cover panel | |
| g. Wing skin and control surface general condition | |
| 3. Right wing | Checked |
| a. Oil cooler | |
| b. Top accessory vent door | |
| c. Oil quantity | |
| d. Oil tank filler cap dipstick and access cover panel | |
| e. Propeller deicing quantity, filler cap and access panel | |
| f. Fuel tank filler cap and access cover panel | |

- g. Wing skin and control surface general condition

4. Top of aircraft checklist

Complete

CARGO COMPARTMENT CHECK

1. Oxygen compartment

Checked

- a. Pressure

Checked

- b. Filler valve

Closed

2. Static line retriever

As required

3. Forward portable fire extinguisher

Checked

4. Crash axe

Checked

5. Preheat outlet cover

Secure

6. Pendulum release handle

Checked

- a. Cable

Recessed

- b. Handle

Secure

7. Storage compartments

Checked

8. Tiedown devices

Checked

9. Seat and seat belts

Checked

10. Cargo floor/rollers

Checked

NOTE

A minimum of two (2) quarts of hydraulic fluid and tie-down equipment will be stowed in the storage compartment.

11. Ventilation levers

As desired

12. Emergency exit

Checked

13. First aid kits

Checked

14. Anchor lines and attachments

Checked

15. Door emergency exit

Checked

16. Ramp extensions

Stowed

17. Ramp door

Checked

18. Cargo door jettison mechanism/handle

Checked/Safetied

CAUTION

The cargo door jettison mechanism is properly locked when the red setting lever and the adjacent brackets of the locking carriage are aligned. The setting lever must also be safety-wired to the angle brackets using 0.020 inch copper safety wire.

- | | |
|--|---------|
| 19. Steady strut and steady strut attachment pin | Stowed |
| 20. Ramp and cargo door control handles | Checked |
| 21. Cargo loading light | Checked |

CAUTION


The light should be stowed with the lens down to prevent scorching or burning of material in the stowage well.

- | | |
|-------------------------------------|----------|
| 22. Left troop door | Checked |
| 23. Rear portable fire extinguisher | Checked |
| 24. Cargo compartment checklist | Complete |

EXTERIOR INSPECTION

- | | |
|-----------------------------------|---------|
| 1. Left aft fuselage | Checked |
| a. Condition of skin | |
| b. Passenger door | |
| c. Windows | |
| d. Emergency exit | |
| 2. Left inboard wing | Checked |
| a. Flaps and flap well | |
| b. Condition of skin | |
| c. Engine fire extinguisher discs | |
| d. Fluid leaks | |
| 3. Left wheel well | Checked |
| a. Gear doors | |
| b. Fluid leaks | |
| c. Drag strut and linkage | |
| d. Uplocks | |
| e. Electrical installations | |

exterior inspection diagram



EXTERIOR INSPECTION
VISUALLY EXAMINE EXTERIOR OF AIRCRAFT
IN ACCORDANCE WITH THE ABOVE FIGURE

Figure 2-1

- | | |
|---|---------|
| 4. Left main gear | Checked |
| a. Strut (<u>7-1/2 to 9-1/2 inches extension</u>) | |
| b. Tires and wheels | |
| c. Brake assembly | |

NOTE

Check that brake pins are not recessed 5/16 inch or more within the threaded bushing and that disc-to-puck-housing distance does not exceed 7/16 inch.

- | | |
|-----------------------|---------|
| d. Weight switch | |
| e. Pseudraulic lines | |
| 5. Left outboard wing | Checked |
| a. Augmentor tubes | |

- b. Fluid leaks
 - c. Flaps and flap wells
 - d. Control surfaces
 - e. Control hinges
 - f. Navigation light
 - g. Access panels
 - h. Deicing boots
 - i. Stall transducer
 - j. Landing light
6. Left engine Checked
- a. Vent doors
 - b. Fluid leaks
 - c. Cowling
 - d. Engine intakes
 - e. Propeller assembly
 - (1) Check dome plug and retainer nut are safetied
 - (2) Check dome, hub, and control unit for leaks and security
 - (3) Check condition of blades
7. Thrust indicator pitot heads Checked
8. Left inboard wing leading edge Checked
- a. General condition
 - b. Heater intake
9. Left forward fuselage Checked
- a. Skin and antennas
 - b. Brake accumulator pressure (800 to 850 psi)

- c. Brake emergency air pressure (1500 to 1600 psi)
 - d. Hydraulic leaks
 - e. Nose access door Closed/Secure
 - f. Static ports
 - g. Cockpit heater fire extinguisher discs
 - h. Top access panel
 - i. Cockpit heater ducts
10. Pitot tube Checked
11. Nose gear Checked
- a. Door safety pins
 - b. Nose gear doors
 - c. Nose steering limit blocks
 - d. Steering disconnect pins
 - e. Weight switch
 - f. Tires and wheels
 - g. Strut ($8\frac{1}{2}$ to $10\frac{1}{2}$ inches extension)
 - h. Taxi light
12. Pitot tube Checked
13. Right forward fuselage Checked
- a. Radome
 - b. Cockpit heater duct
 - c. Top access panel
 - d. Static ports
 - e. Hydraulic lines
 - f. Emergency air bottle (1200 to 1300 psi)
 - g. Oxygen system pressure (1800 ± 50 psi)

- h. Nose access door Closed/Secure
- i. Bottom escape hatch
- j. Antennas
- k. Cargo compartment heater fire extinguisher discs
- 14. Right inboard wing leading edge Checked
 - a. Ram air intake duct
 - b. General condition
- 15. Thrust indicator pitot heads Checked
- 16. Right engine Checked
 - a. Propeller assembly
 - (1) Check dome plug and retainer nut are safetied
 - (2) Check dome, hub, and control unit for leaks and security
 - (3) Check condition of blades
 - b. Engine intakes
 - c. Cowling
 - d. Fluid leaks
 - e. Vent doors
- 17. Right outboard wing Checked
 - a. Landing light
 - b. Stall transducer
 - c. Deicing boots
 - d. Access panels
 - e. Navigation light
 - f. Control hinges
 - g. Control surfaces
 - h. Flaps and flap wells

T.O. 1C-7A-1

- i. Fluid leaks
- j. Augmentor tubes

18. Right main gear

Checked

- a. Pneudraulic lines
- b. Weight switch
- c. Brake assembly

NOTE

Check that brake pins are not recessed more than 5/16 inch within the threaded bushing and that disc-to-puck-housing distance does not exceed 7/16 inch.

- d. Tires and wheels
- e. Strut (7-1/2 to 9-1/2 inches extension)

19. Right wheel well

Checked

- a. Gear doors
- b. Fluid leaks
- c. Drag strut and linkage
- d. Uplocks
- e. Electrical installations

20. Right inboard wing

Checked

- a. Fluid leaks
- b. Engine fire extinguisher discs
- c. Condition of skin
- d. Flaps and flap well

21. Right aft fuselage

Checked

- a. Condition of skin
- b. Passenger door
- c. Cargo door jettison handle

22. Empennage

Checked

- a. Vertical stabilizer, rudder, and trim tabs
- b. Horizontal stabilizer, fairings, elevators, and trim tabs
- c. Cargo door
- d. Steady strut As required
- e. Tail tiedown ring As required

CAUTION

The tail tiedown ring shall be removed prior to airdrop operation to preclude the possibility of damage to parachutes during deployment.

23. Static ground wire

Removed

24. Exterior inspection checklist

Complete

BEFORE STARTING ENGINES.

- | | | |
|--|------------|-------|
| 1. Forms 781 and 365F and navigation publications | "Checked" | P |
| 2. Pilot's briefing | "Complete" | P |
| * 3. Passenger briefing | "Complete" | P |
| * 4. Seats, rudder pedals, safety belt, shoulder harness | "Adjusted" | P, CP |

NOTE

The pilot's rudder adjustment handle will be positioned so as not to obstruct the view of the hydraulic gages and warning lights.

- | | | |
|--|----|----|
| * 5. Command radio and FM radio switch | ON | CP |
|--|----|----|

NOTE

During the battery start when tower and fire fighting facilities are not available, the command radio should not be turned ON until after engine start.

- | | | |
|---------------------------|-------------|----|
| 6. Electrical power panel | Set | CP |
| a. Generator switches | ON | |
| b. Inverter switch | As required | |

NOTE

Inverter switch will be MAIN when using external power. Inverter switch will be OFF when using battery power.

- | | | |
|----------------------|---------------|-----|
| 7. Oxygen regulators | "As required" | All |
| *8. Parking brakes | "Set" | P |

CAUTION

If hydraulic pressure has been depleted, the brake system must be pressurized to a minimum of 1000 psi by use of the hydraulic handpump before engines are started.

- | | | |
|--|-----------------|-------|
| 9. Instruments | "Checked" | P, CP |
| Check engine instruments, manifold pressure, and flight instruments. | | |
| *10. Carburetor air | "COLD/RAM" | P |
| 11. Flaps selector | "40°" | P |
| *12. Ignition switches | "OFF" | P |
| 13. Mixtures | "IDLE CUTOFF" | P |
| 14. Propellers | "FULL INCREASE" | P |
| 15. Throttles | "Set" | P |

CAUTION

The throttle friction lock lever should never be turned more than 3 turns (counterclockwise) from the friction applied position.

NOTE

Open throttles approximately 1/2 inch from closed position for starting.

- | | | |
|---------------------------------------|-----------------|----|
| *16. Landing gear selector | "DOWN" | P |
| *17. Down locks/steady strut/doors | "Aboard/Closed" | FM |
| *18. Before starting engine checklist | "Complete" | CP |

STARTING ENGINES.

- | | | |
|---------------------------|----------------------|-------|
| * 1. Propellers/fireguard | "Clear/Clear posted" | P, CP |
| * 2. Power | "ON" | P |

* 3. Navigation lights	ON	CP
* 4. Right boost pump	"NORMAL"	P
* 5. Right engine	Start	P, CP

NOTE

The pilot will engage the starter switch and after the minimum propeller revolutions are noted, he will direct the copilot to turn the ignition switch on. Simultaneously, the pilot will engage the vibrator and primer switches and hold until the engine starts. After the engine starts, the starter and vibrator switches will be released. If a battery start has been made, the copilot will turn the inverter switch to MAIN at this time. Both pilots will check engine pressures and the hydraulic pressure while noting the manifold pressure of the engine that has not been started. The pilot will stabilize the engine at 800 rpm with throttles and prime. When proper engine indications are noted, the pilot will direct the copilot to move the mixture lever to RICH. When a rpm drop is noted, the primer switch will be released.

a. Engage starter switch

CAUTION

If a liquid lock is encountered, do not rotate the propeller.

- (1) Turn prop through 15 blades when engine has been shut down for a period of one hour or longer
- (2) Turn prop through 6 blades if engine has been shut down less than one hour

b. Ignition switch on

c. Engage vibrator switch

- d. Engage primer switch

CAUTION

Do not use mixture to prime engine except for extreme cold weather operations. Simultaneous use of both primer and mixture often results in exhaust system fires and/or liquid locks. With hot engines and at high density altitude, it may be necessary to delay the initiation of prime until the engine fires.

- e. Set throttles for 800 rpm
f. Turn inverter switch to MAIN during a battery start.
g. Check oil pressure indication

CAUTION

A positive indication of oil pressure must be indicated immediately or engine will be shut down. 30 psi must be indicated within 30 seconds or engine will be shut down.

- h. Move mixture to AUTO RICH
i. Turn the boost pump switch OFF

* 6. Pressures/rpm

"Checked"

P

CAUTION

Do not exceed 1000 rpm until oil pressure stabilizes within normal operating limits. Then, do not exceed 1200 rpm until oil temperature reaches 40°C and CHT reaches 80°C.

NOTE

- 1000 rpm is recommended for all static ground operations.
- Check oil, fuel, hydraulic, and suction pressures for proper indications.

* 7. External power

"As required"

P

- | | | |
|----------------------|----------|-------|
| * 8. Battery switch | "ON" | P |
| * 9. Left boost pump | "NORMAL" | P |
| *10. Left engine | Start | P, CP |

NOTE

Repeat the same starting procedures for left engine.

- | | | |
|--------------------|-----------|---|
| *11. Pressures/rpm | "Checked" | P |
|--------------------|-----------|---|

NOTE

Check oil, fuel, and hydraulic, and suction pressures for proper indication.

- | | | |
|---------------------------------|------------------|----|
| *12. Flaps | UP 30.65 seconds | CP |
| *13. Carburetor air switches | As required | CP |
| *14. Starting engines checklist | "Complete" | CP |

BEFORE TAXIING.

- | | | |
|------------------------------|---------------|-------|
| * 1. Inverters/radio console | "As required" | P, CP |
| a. Radios | ON | |
| b. Navigation equipment | ON | |
| c. Radar inverter | ON | |
| d. Radar function switch | STANDBY | |

CAUTION

Caution must be exercised in ground operation to preclude a strong return which will damage the indicator. Should operation on the ground be necessary, make sure the scanning area is clear of large structures or aircraft. As an extra precaution, place antenna tilt control in 15° up position. This system may be employed to check operation of the set in runup position prior to take-off in instrument conditions.

- | | |
|-----------------|---------|
| e. IFF/SIF/AIMS | STANDBY |
|-----------------|---------|

- | | | |
|-----------------------------------|-----------|----|
| * 2. Alarm bell | Checked | CP |
| * 3. Ignition switch safety check | "Checked" | CP |
| a. Throttles 800 — 1000 rpm | | |

WARNING

The primary purpose of the following check is to determine if the engine firing ceases when the switch is in the OFF position. However, it also serves as a preliminary check for a possible dead magneto. Each position should be held long enough to assure that ignition continues in both L and R positions and that ignition ceases completely in the OFF position. If the engine does not cease firing in the OFF position during this check, it is an indication that the magneto ground wire is open at some point and any subsequent ignition check will be unreliable. In this case personnel must be warned to keep clear of the propeller after the engine is shut down until the defect is corrected.

- b. Turn ignition switches from BOTH, to L to R to OFF, stopping in each position momentarily, then back to BOTH.

- | | | |
|---------------------------------|-----------|---|
| 4. Stall warning and flap check | "Checked" | P |
|---------------------------------|-----------|---|

On aircraft not modified by T.O. 1C-7A-606, make stall warning and flap check as follows:

- a. Close throttles
- b. Check flaps are at zero degrees
- c. Turn stall warning test switch to the right and note that neither high intensity shakers operate
- d. Move test switch to the left, and note both low intensity stick shakers operate
- e. Hold switch to left and lower flaps to 40°. Both low intensity shakers should continue to operate
- f. Turn switch to right and note stick shakers stop

- g. Hold switch to right and advance both throttles approximately 3/4 inch from fully closed position. Both high intensity stick shakers should operate and the approach speed indicator pointer should move fully into the SLOW zone
- h. Move switch to left, both high intensity stick shakers should continue to operate, augmented by both low intensity stick shakers. The indicator pointer should return to the triangular index
- i. Release switch to OFF. Set throttles to 1000 RPM. Select flaps to zero degrees. Check that the flaps retract to the full up position. Shakers may continue to operate for approximately 10 seconds. Indicator pointer should remain at the triangular index

NOTE

Observe the flaps move from UP to DOWN in 15-25 seconds, from DOWN to UP in 30-65 seconds.

On aircraft modified by T.O. 1C-7A-606, make stall warning and flap check as follows:

- a. THROTTLES 800 - 1000 RPM
- b. Check flaps are at zero degrees
- c. Turn stall warning test switch to the right and note that shakers operate
- d. Move test switch to the left, and note stick shakers operate
- e. Hold switch to left and lower flaps to 40° shakers should continue to operate
- f. Release switch to OFF and select flaps to zero degrees. Check that the flaps retract to the full up position. Shakers may continue to operate for approximately 10 seconds. Indicator pointer should remain at the triangular index.

NOTE

Observe the flaps move from UP to DOWN in 15-25 seconds, from DOWN to UP in 30-65 seconds.

5. Generators

Checked

CP

- a. Check volt readings 27.5V plus or minus 0.5V and that ammeter readings coincide within 10% of the total load

NOTE



Individual generator voltage can be read only if that generator is the only one on the main bus.

- b. Turn left generator switch OFF and check that left ammeter reading drops to zero and right ammeter increases. Check that left generator failure light illuminates
- c. Turn left generator switch ON
- d. Repeat procedure for right generator

6. Wing and tail deicing

"Checked"

P, CP, FM

NOTE

Check only if icing conditions are anticipated.

- a. Set mode switch to MANUAL
- b. Check vacuum pressure
- c. Check deicing pressure
- d. Check deicing boot operations
- e. Set mode switch to OFF

7. Flight controls

"Checked"

P, FM

NOTE

Controls will be visually checked through the full range for proper movement.

8. Gust lock

"LOCKED"

P

* 9. Altimeter-Encoder/Altimeter

"Set"

P, CP

- a. Obtain taxi clearance and altimeter setting from the control tower

The local barometric pressure should be set into the altimeter at field elevation using the baroset knob on the front of the altimeter. A field elevation check should be made after barosetting. Each altimeter should agree with ± 75 feet of field elevation. If errors exceed these limits, discontinue operation until the altimeter is re-zeroed or replaced by the appropriate facility.

WARNING

It is possible to set the altimeter 10,000 feet in error and have the correct setting on the barometric scale. This occurs when the barometric pressure set knob is continuously rotated, until the barometric scale is out of view and the scale reappears from the opposite side. If the correct altimeter setting is then replaced on the barometric scale, the altimeter will be in error by approximately 10,000 feet. To avoid this, always check the ten thousand feet pointer for proper indication when setting the altimeter.

CAUTION

During normal use of the baroset knob on the AAU 21A/27A altimeters, momentary locking of the barocounters may be experienced. If this occurs, do not force the setting. Application of force may cause internal gear disengagement and result in excessive altitude errors. If locking occurs, the required setting may sometimes be established by rotating the knob a full turn in the opposite direction and approaching the setting again with caution.

*10. Chocks/cargo compartment

"Removed/Secure"

FM

CAUTION

The cargo door may be open during ground operations. Passenger doors will be kept closed when engines are running. The ramp door will not be lowered below the horizontal position while taxiing.

*11. Before taxiing checklist

"Complete"

CP

TAXIING.

When the nosewheel is lightly loaded or while taxiing on wet surfaces, skidding or skipping of nosewheel may develop. These conditions can be prevented by slow taxi speed, gentle brake applications, and avoiding abrupt steering changes. In turns or crosswind conditions, asymmetrical power may be necessary. Differential braking imposes excessive side loading on the nosewheel and should be avoided if possible.

CAUTION

- Excessive or prolonged use of the brakes while taxiing will cause overheating of the brake assemblies with possible wheel failure and/or tire or brake fire resulting. Taxi speed can normally be controlled by use of minimum engine power and propeller reversing. 800 rpm is the minimum continuous power recommended during taxiing to minimize spark plug fouling.
- Flaps must be retracted when taxiing over rough terrain. Extreme caution must be exercised and very low taxi speeds observed.
- Avoid turns with brakes locked on one side to prevent damage to the tires or the main landing gear. When possible, avoid braking to a stop in turns, since damage to the nose landing gear and/or supporting structure may result. See figure 2-2 for minimum space and clearance required for turning.

CAUTION

Reverse taxiing is not recommended. However if reverse taxiing is necessary, the nosewheel steering switch must be on. Reverse taxiing should be started and stopped with the nosewheel centered, the aircraft should be stopped with forward thrust. Sharp turns and use of brakes should be avoided. Brakes should be applied gradually when braking is necessary.

*** 1. Brakes****"Checked"****P, CP****NOTE**

- After the first flight of the day only the pilot needs to perform brake check.
- Hydraulic pressure must be monitored during ground operations.

*** 2. Flight instruments****"Checked/Set"****P, CP**

- a. Check that the turn needle is indicating turn in the proper direction and that the ball is free in the race
- b. Check the heading indicators for proper indication
- c. Uncage copilot's attitude indicator

3. Propeller reversing**"Checked"****P, CP**

- a. Set carburetor air switches to filter
- b. Set throttles to idle and push into reverse position. Feather button lights should come ON, reverse lights should come ON, feather button lights should go OUT
- c. Move throttles into reverse range and check thrust indicator for "O" reading

CAUTION

Do not exceed 1000 rpm until oil pressure stabilizes within normal operating limits. Then, do not exceed 1200 rpm until oil temperature reaches 40°C and CHT reaches 80°C.

minimum turning radius and ground clearance




Figure 2-2

- d. Move throttles into normal idle position and check for binding. The feather button lights should come ON, reverse lights should go OUT, feather button lights should go OUT. Check thrust indicators for positive thrust indication

CAUTION

During feathering, unfeathering, and the reversing cycles the propeller auxiliary pump motor is operating. To prevent burn-out of propeller auxiliary pump motor, operations must be restricted to 20 seconds on and 10 minutes off.

e. Carburetor air switches

As required

* 4. Taxi checklist

"Complete"

CP

ENGINE RUNUP.

NOTE

Avoid continuous ground operation under static conditions in a crosswind with the propeller governing.

* 1. Nosewheel, parking brakes

"Centered/Set"

P

* 2. Engine instruments

"Checked"

P, CP

NOTE

Do not advance throttles beyond 1200 rpm until oil temperature reaches 40°C and CHT reaches 80°C.

3. Feathering system

"Checked"

P, CP

NOTE

One of the feather operational checks is required during engine runup. It is not required to check both autofeather system and manual feather system. If the use of the autofeather system is not anticipated the autofeather check is not required. In this case proceed to manual feather check.

a. Autofeather system

- (1) Set throttles at 1000 rpm
- (2) Turn autofeather switch ON and check autofeather indicator light illuminates
- (3) Advance right throttle until left feathering button pulls in

NOTE

The feathering button light should illuminate and the autofeathering light should go out.

- (4) Return the right throttle to 1000 rpm and simultaneously pull out the left feathering button after a 100 - 200 rpm drop is observed

NOTE

At the instant feathering commences a pressure differential of $45 \pm 2\frac{1}{2}$ percent thrust should be indicated.

- (5) Reset the autofeathering switch by turning it OFF and then ON
- (6) Repeat the procedure to check the right engine autofeather system
- (7) Turn autofeather switch OFF

b. Manual feather

- | | | |
|---|----------|----|
| (1) Throttles | 1900 rpm | P |
| (2) LH feather button | Depress | P |
| Return button to neutral after 200 rpm drop | | |
| (3) RH feather button | Depress | CP |
| Return button to neutral after 200 rpm drop | | |

4. Propeller operation

"Checked"

P, CP

- a. Set throttles to 1900 rpm
- b. Set propeller to full decrease and check that the rpm decreases and stabilizes between 1100 and 1350 rpm
- c. Return propeller to full increase and check the rpm return to 1900

NOTE

It may be necessary to exercise the propeller several times to obtain 1900 rpm.

5. Carburetor heat

Checked

CP

- a. Set left carburetor heat lever to HOT
- b. Check for a rise in CAT and decrease in rpm

- c. Return lever to COLD position and check for a decrease in CAT and an increase in rpm
- d. Repeat procedure for right carburetor heat lever

* 6. Power and ignition system

- a. Set throttles to field barometric pressure
- b. Check that the tachometer indicates 2200 ± 50 rpm, and that all instruments are within desired range. Check thrust indicators for similar readings

"Checked"

P, CP

NOTE

When making a power check, approximately 2 rpm should be added for each knot of headwind and 2 rpm subtracted for each knot of tailwind.

- c. Turn ignition switch to R position and observe rpm

CAUTION

When rpm drop exceeds 150 or excessive roughness is encountered or ignition is accidentally turned OFF, retard throttle to idle RPM before returning magneto switch to BOTH.

NOTE

A drop of 50 to 75 rpm is normal. Maximum drop is 100 rpm provided no engine roughness is encountered. The maximum spread between drops of right and left magnetos should not exceed 40 rpm. It is essential that all readings be allowed to stabilize between ignition switch changes. This must not be construed to mean that the engines will be allowed to operate on single ignition at this speed for an extended period of time as preignition or detonation may occur. A period as long as 30 seconds is not considered excessive but should not be exceeded.

- d. Return ignition switch to BOTH position to stabilize rpm
- e. Repeat this procedure with ignition switch in L position

NOTE

If unacceptable magneto check occurs use de-fouling procedure in Section VII.

- f. Repeat the ignition check on the other engine

* 7. Gust lock	"LOCKED"	P
8. Radios and navigation equipment	"Checked"	P, CP
* 9. Engine runup checklist	"Complete"	CP

BEFORE TAKE-OFF.

1. Mixtures	"AUTO RICH"	CP
2. Propellers	"FULL INCREASE"	CP
3. Hydraulic pressure	"Checked"	CP
4. Autofeather switch	"As required"	P

WARNING

- Take-off conditions such as gusty cross-winds, inoperative nosewheel steering, or a suspected inaccuracy of the thrust differential system may require the autofeather switch to remain OFF. The pilot also may elect to leave the autofeather switch OFF during a short-field take-off.
- The autofeathering switch if used, must be selected ON before take-off only, and selected to OFF after the power reduction following initial climb. Its use during landing could be hazardous if a go-around is attempted and one propeller feathers due to uneven acceleration of the engines.

5. Fuel panel	"Set"	P
a. Fuel boost pumps	NORMAL	
b. Fuel quantity	Checked	
c. Fuel selector	NORMAL	
6. Crew briefing	"Complete"	P
a. Type take-off		
b. Applicable performance data		
c. Departure and emergency return procedure		
NOTE Only special procedures (weather, formation, etc) need to be covered. If any crew member is not completely familiar with his duties and procedures, as outlined in emergency section, these areas will be covered.		
7. Trim	"Set"	P
8. Flaps	"Set"	P, CP
9. Instruments/warning lights	"Checked"	P, CP
a. Flight instruments		
b. Flap position indicator		
c. Engine instruments		
d. Warning lights		
NOTE Maximum CHT for initiating the take-off roll is 180°C and the minimum is 80°C.		
10. Roof hatch	"Secure"	FM
11. Cargo compartment and engines	"Checked"	FM
a. Check engines for fuel, oil, and hydraulic leaks		
b. Check doors and escape hatches are closed/secure		

- c. Check that steady strut, chocks, and loose equipment are secure
- d. Check brakes for overheat condition
- e. Check that passengers are secure for take-off
- f. Check cargo for fumes, leaks, and tiedowns tight

NOTE

- The flight mechanic will visually check both main gear brakes for evidence of overheating due to dragging brakes during taxiing.
- If ground operating time exceeds 10 minutes, comply with antifouling procedures outlined in Section VII.
- Overhead shades should be stowed during flight.

12. Carburetor air	As required	CP
13. Lights	As required	CP
14. Seat belts and shoulder harness	"Fasten/Unlocked" "Fasten/Secure"	P, CP FM
15. Before take-off checklist	"Complete"	CP

LINE UP

1. RMI's/magnetic compass	"Checked"	P, CP
2. IFF/SIF/AIMS	As required	CP
3. Anti-icing switches	As required	P
4. Flight controls	"Checked"	P

NOTE

Controls must be checked for freedom of movement prior to flight anytime the gust lock is placed on and then released.

5. Line up checklist	"Complete"	CP
----------------------	------------	----

TAKE-OFF.

Depending upon the conditions encountered, various techniques for take-off must be employed in order to achieve satisfactory performance. At night the use of landing lights throughout the take-off run is recommended. Take-off data presented in T.O. 1C-7A-1-1 should be consulted to predict the expected

performance for the specific conditions involved in each take-off. No visual or verbal comments will be given to the pilot if the aircraft performance is normal. Any discrepancy which is noted will be brought to the attention of the pilot in the manner directed by the pilot during the pre-take-off briefing. Procedures for normal take-off, short-field take-off and crosswind take-off are given in the following paragraphs.

NORMAL TAKE-OFF

Flap settings from 0° to 15° may be used for take-off for gross weights up to 28,500 pounds if computed take-off performance for the specific conditions permit. 7° flaps is normally used for weights of 26,000 to 28,500 pounds and 15° flaps for weights below 26,000 pounds. Taxi the aircraft a short distance to align the aircraft with the runway and to center the nosewheel. Release brakes and advance the throttles gradually to maximum power.

NOTE

The Take-Off Charts in T.O. 1C-7A-1-1 are based on maximum power at brakes release.

During the take-off roll, the pilot maintains directional control with nosewheel steering until flight controls become effective. Concurrently, the copilot shall hold the control column in the neutral position and keep the wings level with ailerons. As speed increases, the pilot discontinues nosewheel steering and maintains directional control throughout the take-off roll by coordinated use of aircraft controls according to the circumstances of speed, crosswinds, and runway conditions. As the airspeed increases, the pilot will ease back on the control column and allow the aircraft to lift off at computed take-off speed or minimum control speed, whichever is higher. For a smooth transition to take-off attitude, rotation of the aircraft should be started prior to reaching take-off airspeed.

NOTE

If the nosewheel steering system is inoperative, the take-off procedure is the same for a normal or short-field take-off except rudder, differential power, and brakes may be used as required to maintain directional control. The nosewheel steering switch will be OFF.

SHORT-FIELD TAKE-OFF.

When making a short-field take-off, position the aircraft on the extreme threshold of the runway and center the nosewheel. The standard flap setting for a short-field take-off is 25°. Brakes will be applied and throttles advanced to maximum power, unless runway conditions such as rocks, sand, slippery surface, or obstructions to the rear of the aircraft are present that could cause equipment damage. If such a condition exist, advance power to 30 in. Hg. After all engines instruments have stabilized, release the brakes, and move the throttles to maximum power. Directional control will be maintained by nosewheel steering. Concurrently, the copilot shall hold the control column slightly forward of neutral in order to allow positive nosewheel steering and keep the wings level with ailerons. When rudder control becomes fully effective for directional control, but in no case below 50 KIAS, the pilot will discontinue use of nosewheel steering and transition to the yoke. Accomplish lift-off by positive control movement. Immediately after lift-off, reposition the yoke to establish climb attitude. At low altitudes, select gear and flaps up simultaneously after lift-off. Above 4000 feet density altitude and 26,000 pounds gross weight, raise the flaps to 7°. Upon acceleration to 85 KIAS retract flaps to 0° and climb out at 95 KIAS. After lift-off, the aircraft will be allowed to accelerate to 95 KIAS, unless the terrain necessitates a steeper initial rate of climb.

WARNING

Due to aircraft design, some pilots cannot obtain full left aileron when the control column is in the full aft position.

CAUTION

Caution must be used after take-off to prevent aircraft from over-rotating to an angle which will cause a drop in airspeed and result in a stall.

NOTE

- Terrain features may require flap management other than full retraction immediately after takeoff.
- In crosswind conditions, nosewheel steering will be maintained until the desired take-off airspeed has been reached. At that time the pilot will transition to the yoke and immediately fly the aircraft off the ground.

CROSSWIND TAKE-OFF

Crosswind take-offs with regard to directional control of the aircraft, are made essentially the same as normal take-offs. Initially, the yoke should be slightly forward and the aileron placed into the wind, to provide positive ground directional control. The pilot maintains directional control with nosewheel steering and differential power while the copilot maintains wing level attitude with the ailerons. Transition to the yoke should be delayed until take-off airspeed is reached. For maximum permissible crosswind components and take-off airspeeds, refer to T.O. 1C-7A-1-1.

CAUTION

Excessive differential power may cause inadvertent autofeathering of the downwind engine.

NO FLAP TAKE-OFF.

No flap take-offs may be used regardless of aircraft weight, and are mandatory above 28,500 pounds. The procedure is similar to a normal take-off, except that the nosewheel is lifted just clear of the runway at approximately 65 knots. This pitch attitude is maintained until the aircraft becomes airborne.

AFTER TAKE-OFF/CLIMB.

Procedures for normal climb and maximum climb are given in the following paragraphs. METO power referred to in this checklist is the maximum power that can be used for an indefinite period as long as mixture remains in the AUTO RICH position (42.5 in. Hg and 2550 rpm at sea level). Normal climb is at 105 knots IAS with power set to 35 in. Hg and 2250 rpm.

NORMAL CLIMB.

1. Gear

"UP"

P

NOTE

The flight mechanic will visually check the gear retraction action and will report any abnormalities to the pilot.

2. Flaps

"UP"

CP

The pilot will command flaps retraction and the copilot will accomplish the action. The gear and flaps should be retracted simultaneously immediately after the aircraft is airborne.

WARNING

The flaps will initially be set to one-half of the take-off setting. When it is determined the flaps are retracting properly, the flap lever will be placed in the up position. This is necessary to preclude an instantaneous full retraction in event of restrictor valve failure.

3. METO power

"Set"

P, CP

As the airspeed passes through 95 KIAS, reduce power to METO power setting. If a maximum climb is planned the checklist may be completed prior to establishing normal climb power. Maintain 95 KIAS during maximum climb.

4. Climb power

"Set"

P, CP

Reduce power to normal climb power settings after accelerating to normal climb speed.

5. Autofeather switch

OFF

P

6. Landing and taxi lights	As required	CP
7. Cargo compartment and engines	"Checked"	FM
a. Check engines and propellers for fluid leaks		
b. Check gear doors, cargo compartment, load, and security of passengers		
c. No smoking/Seat belts signs	As required	CP
8. After take-off/climb checklist	"Complete"	CP

MAXIMUM CLIMB.

Maximum climbs are normally used in conjunction with short-field take-offs when obstacles must be cleared. After take-off immediately retract gear and position flaps as required to establish a climb angle which will safely clear obstacles. Maintain maximum power until gear and flaps are fully retracted and obstacles have been cleared. When clear of obstacles, transition to normal or METO climb power. Maximum climbs will not be performed beyond that point at which obstacles are cleared. When a higher rate of climb is desired, maintain METO power and 95 knots until desired altitude is reached.

During maximum performance climbs, maintain airspeeds at or above computed take-off speed. As flaps retract, airspeed must be increased a minimum of 3 knots for each 5° flap retraction to prevent the aircraft from stalling. So that airspeed will increase above these minimum values as rapidly as possible, climb angle should be no steeper than necessary.

CRUISE.**NOTE**

Refer to T.O. 1C-7A-1-1 for power settings for desired BHP.

1. Cruise power	"Set"	P, CP
2. Boost pumps	"OFF"	P
Monitor fuel pressure as boost pumps are turned off. Boost pumps will be operated in NORMAL above 10,000 feet or when fuel pressure fluctuates within limits.		
3. Mixtures	"As required"	CP

CAUTION

Manual leaning of mixture beyond AUTO LEAN is prohibited.

NOTE

Mixture levers are moved one at a time to AUTO LEAN. Refer to Section V for auto lean limitations.

4. Cargo compartment and engines

"Checked"

FM

- a. Check engines and propellers for fluid leaks
- b. Check for proper heating and lighting
- c. Check security of passengers and cargo

NOTE

Cargo compartment and engines will be checked hourly.

5. Cruise checklist

"Complete"

CP

DESCENT.

Conditions permitting, the descent from cruising altitude should be made using cruise power settings. If a considerable reduction in manifold pressure is required, the rpm should be reduced accordingly to provide one inch of Hg per 100 rpm. If a rapid descent is necessary, use a clean configuration and descend at 165 knots IAS, power off, or by lowering landing gear and descending at 120 knots IAS maximum and slight positive thrust indication. The descent checklist should be completed prior to entering the downwind leg of the traffic pattern.

WARNING

A sudden pitchdown condition could be the result of failure of the flap/stabilizer interconnect mechanism. Airloads will normally move the stabilizer to the upper limit (aircraft nose down). The greater the airspeed, the more severe the nosedown tendency. Pitch control can be maintained under these conditions only with the extension of flaps. This stabilizer upper limit movement relates to the position it is designed to assume in the full flap extension. Descent speeds below 120 KIAS and gear extended will result in steeper descent angle and facilitate flap extension in event of stabilizer interconnect failure.

CAUTION

Rapid descents should be avoided.

NOTE

During combat operation, sufficient manifold pressure should be set to provide a slight positive thrust indication.

1. Nosewheel steering switch
2. Windshield heat/anti-icing

"ON"

P

"As required"

P

CAUTION

Should the descent necessitate passing through probable icing conditions, apply carburetor heat prior to entry, and maintain a carburetor air temperature of 15°C throughout. It is possible that a rapid descent from a very cold level into visible moisture at a warmer level can create airframe icing even though the ambient temperature may not be conducive to ice formation.

3. Prop reverse circuit breaker
4. Fuel panel
 - a. Fuel boost pumps
 - b. Fuel tank selector
5. No smoking/Fasten seat belts sign

CLOSED

CP

"Set"

P

Normal

Normal

"ON"

FM

NOTE

The flight mechanic will notify the pilot when the cargo and passengers are briefed and secured for landing.

6. Crew briefing
 - a. TOLD card
 - b. Special instructions
7. Altimeter-Encoder/Altimeter
8. Seat belts/Shoulder harness
9. Descent checklist

"Complete"

P

Reviewed

Briefed

"Set"

P, CP

"Fastened/unlocked"

P, CP

"Cargo Compartment Secure"

FM

"Complete"

CP

BEFORE LANDING.

- | | | |
|-------------------|-------------|----|
| 1. Carburetor air | As required | CP |
|-------------------|-------------|----|

NOTE

The filter position will be selected for landing in areas of sandy or dusty conditions and when reverse is anticipated.

- | | | |
|------------------------|-------------|----|
| 2. Landing/taxi lights | As required | CP |
| 3. Mixtures | "AUTO RICH" | CP |
| 4. Propellers | "2250 rpm" | CP |
| 5. Gear | "DOWN" | P |

NOTE

The pilot will check the green indicator lights - ON, hydraulic pressure within limits, the gear selector red light - OUT. The flight mechanic will visually check the landing gear down and report any abnormal conditions to the pilot.

- | | | |
|----------------------------|-----------------|----|
| 6. Flaps | "As required" | CP |
| 7. Hydraulic pressure/gear | "Checked/Down" | CP |
| 8. Seat belt | "Fastened" | FM |
| 9. Propellers | "FULL INCREASE" | CP |

NOTE

Move propeller to full increase rpm when throttles are retarded below governing speed.

- | | | |
|------------------------------|------------|----|
| 10. Before landing checklist | "Complete" | CP |
|------------------------------|------------|----|

LANDING.

NORMAL LANDING.

Variable flap settings may be used. Refer to T.O. 1C-7A-1-1 for threshold airspeeds and distances.

Every landing should be planned according to runway length available and the general prevailing operating conditions. Normal landings should be planned to promote safe, smooth, and unhurried operating practices; to preclude abrupt reverse power changes; and to save wear and tear on brakes. On final approach, begin to decrease airspeed at a point that will allow a gradual slow-up to Normal Threshold Airspeed.

NOTE

Threshold airspeed is that airspeed at which roundout is initiated.

Roundout should be planned to arrive at the touchdown point at an airspeed above stall speed as computed from the appropriate performance chart (see T.O. 1C-7A-1-1). After the main wheels touch down, lower the nosewheel smoothly to the runway before elevator control is lost. When the main landing gear and nose landing gear are firmly on the ground, the copilot will maintain wing level attitude and hold slight forward pressure on the control column to insure adequate nosewheel steering capability.

NOTE

Forward pressure on the control column must not be such that the nose gear strut is fully compressed and shock absorption nullified.

Concurrently, the pilot maintains directional control and decelerates the aircraft through the coordinated use of the rudder, nosewheel steering, and brakes, according to the speed, wind, and runway conditions. If necessary, differential power may be used to assist in maintaining directional control. Reverse thrust may be applied if needed. Brakes must be checked during the landing roll. When the landing roll is complete and the aircraft slowed to taxi speed, engage the gust lock prior to turning off the runway.


CAUTION

During gusty wind conditions, the threshold airspeed will be recommended threshold airspeed plus one-half the gust factor. (Any increase in touchdown speed will increase landing ground roll distance). Landings will not be conducted if the computed crosswind component is not in the recommended area of the applicable crosswind component landing chart.

CAUTION

Do not transmit on hf frequencies when flying below 90 kts IAS with flaps less than 20° down, or below 70 kts IAS with flaps 20° or more down. The high rf energy level generated during transmission will affect lift transducer signals near stall speeds and nullify stick shaker operation and short-field approach speed indication.

landing pattern-typical



NOTE:
REFER TO T.O. 1C-7A-1-1 FOR LANDING DISTANCE AND
THRESHOLD SPEEDS

Figure 2-3

CROSSWIND LANDING.

Approaching flare, correct the approach drift by lowering the upwind wing, applying opposite rudder, and differential power as required; maintain the correction throughout the flare. Immediately after touchdown, lower the nosewheel to the ground. Normally nosewheel steering will be adequate for maintaining directional control during ground roll. In strong crosswind, it may be necessary to augment nosewheel steering with rudder, brakes, and differential power while the copilot maintains a wing level attitude with aileron. (Refer to T.O. 1C-7A-1-1 for maximum permissible crosswind components.)

SHORT-FIELD LANDING.

Short-field landings are accomplished with 30/40° flaps, and at short-field threshold airspeed as computed from T.O. 1C-7A-1-1.

NOTE

Threshold airspeed is that airspeed at which roundout is initiated.

Upon completion of turn to final approach, establish and maintain short-field threshold airspeed by a combination of pitch and power. Airspeed is best controlled by pitch adjustment and power adjustments. Determine sink rate and touchdown point. Ideally, approach is made with power set at 13 - 15 in. Hg, and a rate of descent of approximately 700 fpm. Short-field threshold airspeed should be maintained until the aircraft commences roundout. Power should then be reduced at a rate that places the throttle at IDLE as the aircraft is rotated through a level attitude during the flare. During the short-field approach, care should be taken to accurately monitor and maintain the approach airspeed down to the commencement of the flare.

NOTE

On aircraft equipped with short-field approach speed indicator, the indicator may be used to maintain the optimum approach speed, provided 40° of flaps are used.

A power off approach is not recommended unless absolutely necessary to clear obstacles on the approach end of the runway. The short-field landing performance data is based on an idle power approach to obtain the minimum air distance possible. Ground run distance will not be affected by a powered or unpowered approach if proper threshold airspeed is indicated at the initiation of flare. The aircraft is especially sensitive to slight wind shear, and wind gusts as low as 5 knots. Dropping the nose to pick up airspeed loss due to wind shear is not recommended without a corresponding increase in power since rate of descent will increase significantly. At threshold airspeed with rates of descent higher than 1200 fpm, there is not enough lift available in the flare to insure a safe landing. In the flare a 2 knot gust increase has a noticeable effect on how well the flare decreases rate of descent; while a 2 knot gust decrease is about the maximum acceptable without increasing power. Be prepared to arrest rate of descent with power if the flare is not effective.

CAUTION

Short-field landing distances shown in T.O. 1C-7A-1-1 can only be repeated if threshold speeds are precisely maintained. During gusty wind conditions, increase threshold airspeed

by one-half the gust factor. Total landing distance will be increased 4 percent for each knot increase in recommended threshold airspeed.

CAUTION

Do not use reverse pitch prior to touchdown. Immediately after the main wheels are firmly on the ground, move the throttles into the reverse range. Normally the throttles should be returned to the forward thrust idle position before resulting debris can cause restriction to visibility or engine damage.

CAUTION

To preclude the possibility of overstressing the center wing section upon landing, do not apply initial braking until the main wheels are firmly on the ground. The most effective braking is obtained by repeated use of maximum brake for periods not to exceed one second followed by a momentary complete release of the brakes. Maximum braking should be used only when normal braking would be inadequate.

NO FLAP LANDING.

Base leg airspeed will be 100 knots IAS. (See T.O. 1C-7A-1-1 for Normal Threshold Airspeeds.)

GO-AROUND.

Upon command of the pilot to go around, proceed as follows:

- | | | |
|--|-------------|----|
| a. Advance the propellers to full increase rpm | | CP |
| b. Advance throttles to maximum power | | P |
| c. Flaps | UP | CP |
| d. Gear | UP | P |
| e. Carburetor air | As required | CP |
| f. Refer to appropriate checklist | | |

TOUCH AND GO/CLOSED TRAFFIC PATTERN.

Certain requirements often dictate that the aircraft remain in the traffic pattern area, with the landing(s) to be made by any one of the following three types: Touch and go; stop and go; full stop taxi back. Touch and go landings require a significant element of caution because of the many actions that must be executed while rolling on the runway at high speed or while flying within the immediate proximity of the ground. Touch and go landings are to be accomplished when authorized or directed by the Major Command concerned. The actions required when the pilot intends to remain in closed traffic are divided into three categories: After Take-off, Before Landing, and On the Runway. This procedure is designed for use when the aircraft remains in the traffic pattern, and may be used until the aircraft departs traffic. The On the Runway portion is applicable to touch and go/stop and go landings only. Once the aircraft is on the runway when making a touch and go or stop and go landing the pilot will call for the appropriate take-off flap setting, and the copilot will position the flaps to the required position, set carburetor air as required, reset the trim tabs, turn on autofeather switch if required and check the flap indicator for proper indication. The pilot will then advance the power and continue with the take-off.

AFTER TAKE-OFF/CLIMB.

1. Gear	"UP"	P
CAUTION The gear may be left extended for brake cooling as outlined in Section VII.		
2. Flaps	"UP"	CP
3. METO power	"Set"	P, CP
4. Climb power	"Set"	P, CP
5. Landing/taxi lights	As required	CP
6. Cargo Compartment and engines	"Checked"	FM

BEFORE LANDING.

7. Crew briefing	"Completed"	P
8. Carburetor air	As required	CP
9. Gear	"DOWN"	P
10. Landing/taxi lights	As required	CP
11. Flaps	"As required"	CP
12. Hydraulic pressure/gear	"Checked/Down"	CP
13. Propellers	"FULL INCREASE"	CP
14. Before landing checklist	"Complete"	CP

ON THE RUNWAY (Touch and go/stop and go).

15. Flaps	"As required"	CP
16. Carburetor air	As required	CP
17. Trim tabs	"Set for take-off"	CP

AFTER LANDING.

1. Gust lock	"LOCKED"	P
NOTE		
Engage gust lock after aircraft is slowed to taxi speed prior to turning off runway. The remainder of the checklist should be delayed until the aircraft clears the runway.		
2. Carburetor heat/air	As required	CP
3. Flaps	As required	CP
4. Windshield heat switch	OFF	CP
5. Anti-icing/deicing switches	OFF	CP
6. Landing/taxi/anti-collision lights	As required	CP
7. Radio console	As required	CP
a. Radios		
b. Radar function switch	Standby	
c. IFF/SIF/AIMS	"As required"	P,CP

NOTE

Turn the AIMS/IFF to OFF or STBY to eliminate signals that may block the controllers scope and interfere with the control of airborne aircraft. If it is desired to retain the mode 4 codes between flights, it is necessary to lock the codes into the transponder computer before turning the MASTER control to OFF. Turning the MASTER control to OFF, or removing power from the aircraft without first locking the codes into the transponder computer, will zeroize the mode 4 codes. To lock the code, momentarily place the CODE control in the HOLD position after landing, and then proceed with the normal stopping procedure. When power is next applied, the transponder computer will again operate normally. If it is again desired to lock the code in the transponder computer, it is necessary to

repeat the HOLD procedure. The transponder computer will zeroize any time that power is applied and the CODE control is turned to ZERO, even if the HOLD function has been activated. Once the code is zeroized, the code is not available until reset.

8. After landing checklist

"Complete"

CP

POST FLIGHT ENGINE CHECKS.

Post flight engine checks are to be made upon completion of the last flight of the day, prior to entering the parking area. Where possible, head aircraft into the wind.

1. Nosewheel, parking brake

"Centered/Set"

P

2. Ignition switch safety check

Checked

CP

NOTE

Follow the same procedure as outlined in BEFORE TAXIING checklist.

- | | | |
|------------------------------|-----------|-------|
| 3. Carburetor air | Set | CP |
| a. Heat levers | Cold | |
| b. Air switches | RAM | |
| 4. Power and ignition system | "Checked" | P, CP |

NOTE

Follow the same procedures as outlined in ENGINE RUN-UP checklist. The carburetor induction switch will be at RAM for power check.

- | | | |
|--|------------|-------|
| 5. Gust lock | "LOCKED" | P |
| 6. Idle speed and mixture check | "Complete" | P, CP |
| a. Close throttles | | |
| b. Check idle speed (650 ± 25 rpm) | | |
| c. Slowly move left mixture toward IDLE CUT-OFF position until a decrease in rpm is noted. | | |

NOTE

If the rpm rises more than 20 rpm, it is an indication that the idle mixture is too rich. If there is no rise, the idle mixture is too lean.

- | | | |
|------------------------------------|------------|----|
| d. Return the mixture to AUTO RICH | | |
| e. Repeat check on right engine | | |
| 7. Post flight engine checklist | "Complete" | CP |

ENGINE SHUTDOWN.

- | | | |
|---------------------------------|----------------|----|
| 1. Nosewheel, parking brake | "Centered/Set" | P |
| 2. Trim tabs | Centered | CP |
| 3. Copilot's attitude indicator | Caged | CP |
| 4. Heater switches | "OFF" | P |
| 5. TACAN, radar inverters | OFF | CP |

6. Boost pumps

"OFF"

P

CAUTION

Prior to engine shutdown operate engines at 1000 rpm for 30 seconds to scavenge the oil.

7. Right engine mixture

"IDLE CUT-OFF"

CP

NOTE

Should engine continue firing in idle cut-off, close the throttle, turn off the fuel tank selector switch and slowly open the throttle.

8. Flaps

"As desired"

CP

NOTE

When another take-off is scheduled, the flaps may be set at 40°. Flaps will be positioned UP on the last flight of the day.

9. Hydraulic pressure/suction

Checked

CP

10. Left engine mixture

"IDLE CUT-OFF"

CP

11. Ignition switches

"OFF"

CP

NOTE

Do not turn ignition switches OFF until the engines have completely stopped.

12. Radio

OFF

CP

13. Inverter switch

OFF

CP

14. Lights

"OFF"

ALL

15. FM power switch

"OFF"

CP

16. Battery switch

"OFF"

P

17. Wheel chocks

"In place"

FM

18. Parking brake

"Released"

P

19. IFF/SIF/AIMS codes

"As required"

P

20. Engine shutdown checklist

"Complete"

CP

BEFORE LEAVING THE AIRCRAFT.

Make appropriate entries in the Form 781 covering any limits in the Flight Manual that have been exceeded during flight. Entries must also be made when, in the judgement of the pilot, the aircraft has been exposed to unusual or excessive operations, such as hard-landing or excessive braking action during aborted take-offs. The flight mechanic will complete the following items as required.

1. Landing gear ground locks	Installed	FM
2. Covers/dust excluders	Installed	FM
3. Servicing/securing	As required	FM
4. Equipment	Stowed	FM
5. Cargo compartment	Cleaned	FM
6. Before leaving the aircraft checklist	"Complete"	FM

SECTION III EMERGENCY PROCEDURES

TABLE OF CONTENTS

INTRODUCTION	3-1	ELECTRICAL SYSTEM FAILURES	3-20
ENGINE SHUTDOWN CONDITIONS	3-1	INVERTER FAILURES	3-23
GROUND EMERGENCIES	3-2	CARGO JETTISON	3-24
TAKE-OFF EMERGENCIES	3-3	BAILOUT PROCEDURES	3-24
INFLIGHT EMERGENCIES	3-7	LANDING EMERGENCIES	3-25
PROPELLER FAILURES	3-13	EMERGENCY ENTRANCES	3-35
FIRES	3-14	DITCHING	3-35
FUEL SYSTEM FAILURES	3-19		

INTRODUCTION.

This section contains the procedures to be used in coping with the various emergencies that may be met during flight and landing. A thorough knowledge of these emergency procedures will enable crew members to perform these emergency duties in an orderly manner, and to judge more quickly the seriousness of the emergency. This will permit early planning for a bailout or forced landing and will greatly increase the crew's chances for survival. The procedures consist of items classified as critical or noncritical. The critical items are actions that must be performed immediately to avoid aggravating the emergency and causing injury or damage. Critical items are presented in boldface type and must be committed to memory. Noncritical items are actions that contribute to an orderly sequence of events. After determining that an emergency exists, the pilot should establish communication with a ground station. The ground station should be given a complete description of the emergency, the action taken, an accurate position report and the pilot's intentions. The ground station should be further

notified of any changes or developments in the emergency, so that the station can alert Air Rescue Service or other agencies to stand by, if necessary. In checklists presented, the codes P, CP, and FM stand for pilot, copilot, and flight mechanic. This presentation does not preclude the pilot from redelegating the duties at crew briefing.

CAUTION

Crew members should never initiate a procedure before receiving command from the pilot.

ENGINE SHUTDOWN CONDITIONS.

If any of the following conditions occur in flight, corrective action may be limited, and in most cases will require the affected engine to be shut down.

Engine fire

Engine failure

Certain propeller malfunctions (see PROPELLER FAILURES in this section)

Fuel leaks

Excessive drop in oil pressure

Excessive rise in oil temperature/pressure

Unusual vibration or roughness

When it is necessary to continue operation of an engine with any of these conditions present, in the interest of safety of the aircraft and crew, operate the engine with extreme caution, and at the minimum power required.

GROUND EMERGENCIES.

GROUND ENGINE FIRE SHUTDOWN PROCEDURE.

If an engine fire develops during starting, discontinue priming, but continue cranking with the starter and open the throttle. If the fire goes out, shut down the engine and investigate. If the fire continues to burn, continue with the ground engine fire shutdown procedure below. If the engine is already running and an engine fire develops, stop the aircraft, open the throttle and attempt to blow out the fire. If this action fails to extinguish the fire, immediately execute the ground engine fire shutdown procedure and notify the control tower.

1. MIXTURES

IDLE CUT-OFF

CP

2. FUEL AND OIL SHUTOFFS

UP

P

3. FIRE EXTINGUISHER

DISCHARGE (IF FIRE EXISTS)

CP

NOTE

If fire exists after the engine stops, actuate the fire extinguisher. If the first shot does not extinguish the fire, push the fire extinguisher handle fully in, turn counterclockwise 90° and pull for second shot.

4. Boost Pumps

OFF

P

5. Ignition switches

OFF

CP

6. Electrical power

OFF

P

NOTE

The external power unit will be disconnected if being used.

7. Notify crew -

Fight The Fire

FM

Signal ground crew to assist in fighting fire.

NOTE

A red colored push-in panel located to the rear of each engine nacelle at the lower left cowl is marked FIRE ACCESS. Pushing in the panel will allow access for a hand fire extinguisher, which may be discharged into the engine accessories compartment.

TAKE-OFF EMERGENCIES.

ABORT PROCEDURES.

Should a malfunction occur during the take-off roll prior to refusal airspeed and while the aircraft is on the ground, retard the throttles to idle, or to reverse power, if required, and use reverse power and/or brakes to stop the aircraft. Full reverse power can be used; however, it should be applied gradually in order to maintain directional control. Nosewheel steering should be used during propeller reversing and wheel braking. This is especially important if the abort decision was made because of an engine failure, since maximum wheel braking during single engine reversing can only be applied if steering is used to maintain a straight path.

ENGINE FAILURE DURING TAKE-OFF.

If an engine failure occurs during take-off, abort the take-off in accordance with abort procedures in this section if airspeed is below the computed refusal speed or if gross weight is above the take-off gross weight limitation shown in figure A3-1, T.O. 1C-7A-1-1.

If an engine failure occurs during rotation or immediately after take-off, the take-off may be continued provided airspeed has increased to the single engine minimum control speed. Normally, take-off airspeed will be above minimum control speed except during a short-field take-off with 25 degrees flaps.

WARNING

If engine failure occurs above refusal speed with 25 degrees flaps while the aircraft is still on the ground, allow the

aircraft to accelerate on the ground until the minimum control speed with 25 degrees of flaps is attained (63 KIAS).

In a continued single engine take-off, liftoff must be accomplished with the operative engine wing low to develop the sideslip. As liftoff is accomplished, the aircraft will yaw but a track down the runway can be maintained with the wing low. Full aft yoke will probably be required to get airborne with a reposition of the yoke to establish an attitude which will keep the aircraft off the ground. Once safely airborne, retract the gear and raise the flap to 15°.

If the aircraft is airborne but still below the minimum control speed, the aircraft will yaw toward the inoperative engine and the wing with the operating engine will tend to rise. Initially, maximum aileron and rudder will be required into the operative engine and power must be adjusted to maintain directional control. Minimum control speed is based on sideslip developed by a 5° bank into the operative engine; therefore, it is imperative that the wing with the operative engine be kept low. If the wing is not kept down, full aileron control may not be enough to stop a roll in the other direction. Reduction of power on the operative engine will always improve directional and lateral control. However, too much of a reduction of power will result in a controlled crash landing since insufficient power will be available for continued flight. If flight cannot be maintained, prepare for a crash landing and land straight ahead. The aircraft can be flown at speeds near minimum control speed, but a sideslip is required to maintain directional control. If airspeed is above minimum control speed, the sideslip angle required will be less than if below minimum control speed.

single-engine control speeds

MINIMUM CONTROL AIR SPEED

OPERATIVE ENGINE - MAXIMUM POWER

INOPERATIVE ENGINE PROPELLER- **WINDMILLING**

LANDING GEAR- **DOWN**

FLAPS - 25°

FLAPS - 15°

FLAPS - 0° and 7°

63 — 66 — 70

Minimum control airspeed is based on take-off configuration, recommended maximum gross weight, standard day conditions, inoperative engine propeller windmilling, maximum power on the operative engine, and 5° of bank towards the operative engine.

SAFE SINGLE - ENGINE AIR SPEED

89

KIAS

Safe single engine airspeed is defined as the highest of the following airspeeds:

- Lowest airspeed for 100 fpm rate of climb
- 120% of the power off stall speed
- Minimum control speed

Where the airspeed is based on sea level standard day conditions with maximum power on the operative engine, propeller of the inoperative engine feathered, landing gear retracted, flaps up, and maximum recommended gross weight.

NOTE

An increase in ambient temperature or altitude will result in a deterioration in performance.

Figure 3-1

SINGLE ENGINE BEST CLIMB SPEED

MODEL: C-7A
 DATE: APRIL 1970
 DATA BASIS: FLIGHT TEST (AFFTC)

ENGINE(S): (2) R-2000
 FUEL GRADE: 115/145
 FUEL DENSITY: 6.0 LB/GAL

NOTES:

1. SEA LEVEL STANDARD DAY.
2. OPERATING ENGINE AT TAKEOFF POWER.
3. INOPERATIVE ENGINE PROPELLER FEATHERED
4. LANDING GEAR RETRACTED.
5. SPEEDS ARE FOR ALL GROSS WEIGHTS

FLAP SETTING	SINGLE ENGINE BEST CLIMB SPEED (ALL GROSS WEIGHTS)
0°	91 KNOTS IAS
7°	85 KNOTS IAS
15°	74 KNOTS IAS
20°	73 KNOTS IAS
25°	72 KNOTS IAS

Figure 3-2.

MAXIMUM GLIDE CLEAN CONFIGURATION

MODEL: C-7A
 DATE: SEPTEMBER 1967
 DATA BASIS: FEATHERED (AFFTC)
 ONE PROP WINDMILLING (ESTIMATED)

ENGINE(S): (2) R-2000
 FUEL GRADE: 115/145
 FUEL DENSITY: 6.0 LB/GAL

EXAMPLE: BOTH PROPS ARE FEATHERED. FIND
 DISTANCE FLOWN DURING DESCENT FROM 15,000
 FEET TO 9000 FEET.

ENTER CHART AT 15,000 FEET ON VERTICAL SCALE
 AND FIND THE CORRESPONDING VALUE OF 29.0
 NAUTICAL MILES ON THE HORIZONTAL SCALE.

REPEAT THE PROCESS AT 9000 FEET AND FIND THE
 CORRESPONDING VALUE OF 17.5 NAUTICAL MILES.

THE DESCENT RANGE $29 - 17.5 = 11.5$ NAUTICAL MILES.

GROSS WEIGHT POUNDS	BOTH PROPS FEATHERED KIAS KNOTS	ONE PROP WINDMILLING KIAS KNOTS
20,000	90	80
22,000	94	83
24,000	98	87
26,000	102	90
28,000	106	94




Figure 3-3.

If the pilot elects to continue the take-off on one engine, the landing gear should be retracted immediately after continued flight is assured since the elimination of landing gear drag greatly improves single engine climb capability. Raise flaps to 15° (short-field), accelerate to 70 KIAS, raise flaps to 7°, accelerate to 85 KIAS, raise flaps to 0° and accelerate to 91 KIAS.

Best single engine rate of climb is with 0° of flaps and at 91 KIAS. Raising the flaps too rapidly can result in settling in with loss of ability to continue single engine flight. If power was reduced to maintain a ground track, it should be increased as speed increases. However, maintain control of the aircraft.

INFLIGHT EMERGENCIES.

INFLIGHT ENGINE FIRE/SHUTDOWN PROCEDURE.

In the event there is a loss of power, attempt to return the affected engine to normal operation by: reducing power, placing the mixture to AUTO RICH, boost pump to NORMAL, switching fuel tanks, and adjusting carburetor heat. If normal or partial power cannot be maintained, shutdown the affected engine in accordance with the inflight engine shutdown procedures below. Cargo and equipment should be jettisoned if safe altitude cannot be maintained. If directional control, altitude, or airspeed cannot be maintained, the passengers and crew should be alerted for bailout. Normally, flight on one engine is possible; however, the aircraft should be landed at the nearest suitable landing field.

CAUTION

- It is essential that directional control of the aircraft be maintained. Do not allow airspeed to dissipate below single-engine best climb airspeed.
- If an engine failure occurs at a time when additional power is required to maintain safe flight, increase power on the good engine prior to isolating the failed engine by placing the mixture lever to AUTO RICH, adding power as required, and turning the boost pump switch to NORMAL.

SHUTDOWN.

1. THROTTLE

CLOSED

WARNING

Do not retard throttle in case of fire.

2. PROPELLER	FEATHER	CP
3. MIXTURE	IDLE CUT-OFF	CP
4. FUEL AND OIL SHUTOFFS	UP	CP
5. FIRE EXTINGUISHER	DISCHARGE (IF FIRE EXISTS)	CP

NOTE

If fire exists after the engine stops, actuate the fire extinguisher. If the first shot does not extinguish the fire, push the fire extinguisher handle fully in, turn counterclockwise 90 degrees and pull for second shot.

6. GEAR	AS REQUIRED	P
---------	-------------	---

CAUTION

If gears are down and landing is imminent, leave gear down.

7. FLAPS	AS REQUIRED	CP
----------	-------------	----

APPLY POWER TO GOOD ENGINE.

8. Mixture	AUTO RICH	CP
9. Propeller	As required	CP
10. Throttle	As required	P
11. Boost pump switch	NORMAL	P

CLEAN UP.

12. Propeller	Full DECREASE	CP
13. Autofeather switch	OFF	CP
14. Boost pump switch	OFF	P
15. Ignition switch	OFF	CP
16. Generator switch	OFF	CP

17. Nonessential electrical equipment	OFF	CP
18. Secondary bus reset switch	UP	CP
19. Fuel tank selector	As required	P

WARNING

- Do not attempt to restart an engine which was shut down because of fire or any other engine malfunction unless, in the opinion of the pilot, a greater emergency exists.

NOTE

- Moderate airframe vibrations can be expected during single engine operation, increasing with lower airspeed.
- During extended flight on one engine, symmetrical fuel load should be maintained by use of crossfeed selection.

SINGLE ENGINE FLIGHT CHARACTERISTICS.

The aircraft has good flight characteristics during single engine operation. Gear tabs and trim tabs are provided to assist the pilot in maintaining directional control. Should an engine fail in flight, the initial yaw should be controlled by rudder and a bank of 3° to 5° towards the operative engine. Adequate trim is available to relieve control pressures as long as safe single engine or higher airspeeds are maintained. In a clean configuration all normal maneuvers may be performed during single engine operations. The airspeed should be closely monitored and the angle of bank restricted during all maneuvers.

Flight characteristics at speeds between minimum control speed and 5 to 10 knots faster are acceptable. However, aircraft response to control movements is very slow and large control movements are required. Roll control is limited and it is important for the pilot to correct deviations immediately with full aileron control.

Under conditions of high power settings and speeds near minimum control speed, it is important for the pilot to maintain a bank of 3° to 5° toward the operative engine. Otherwise, full aileron

control may not be enough to correct for a roll into the inoperative engine. If an uncontrollable roll is encountered, recovery is possible by increasing speed or reducing power on the operative engine. Power changes should be made gradually since the controls required will vary with power setting. An abrupt increase of power could cause an uncontrollable roll and/or yaw.

Operation at full power and near minimum control speed would be required only during continued single engine take-offs, single engine go arounds, and single engine landings if the pilot is undershooting the runway. When an engine fails near minimum control speed, the following principles apply:

- Bank into the operative engine 3° to 5°. Develop sideslip to maintain directional control.
- Do not make abrupt power increases.
- Directional or roll control can be regained by reducing power on the operative engine.
- Make turns into the operative engine if possible.

DETECTION OF INOPERATIVE ENGINE.

Should engine failure occur, the inoperative engine can be determined by:

Noting the change in directional trim.

Noting a drop in thrustmeter reading.

Observation of the affected engine, i.e., engine roughness, spewing of oil, or backfiring.

Noting abnormal cylinder head temperature.

Noting change in manifold pressure.

PRACTICE MANEUVERS WITH ONE ENGINE INOPERATIVE.

Engine failures may be simulated for practice when desired. To simulate a feathered propeller, set the power to indicate zero thrust (approximately 1500 rpm and 15 in. Hg). Checklist procedures for engine failure can be called out without actually performing the operations named. Practice all maneuvers at a safe altitude. Select a base point and set up a simulated field elevation. Traffic patterns can be flown at the normal altitude above the base point.

During practice feathering, perform engine shutdown in accordance with INFLIGHT ENGINE SHUTDOWN PROCEDURE in this section.

ENGINE RESTART IN FLIGHT.

To restart an engine in flight, the procedure is as follows:

WARNING

An engine will not be restarted unless it can be determined that it is safe to do so. Such factors as known condition of the aircraft and remaining engine, environment, and power requirements of the aircraft must all be considered. Place the oil emergency shutoff switch to DOWN and turn the engine over with the starter every 30 minutes if a restart is anticipated.

NOTE

During practice feathering, simulate actuating the fuel and oil emergency shutoff switches and fire extinguishers.

TURNS.

Turns can be safely made in either direction with one engine inoperative, if airspeed is maintained sufficiently high in respect to minimum control speed and stall speed.

LANDING AND GO-AROUND.

Landing and go-around with a feathered engine may be simulated at altitude by flying a traffic pattern over a basic altitude. Roll out most of the rudder trim during approach to the touchdown point. During practice go-around, note the time required to establish safe climb conditions. Note the altitude lost while gear and flaps retract. Compare the altitude lost for immediate flap retraction to 0° and step flap retraction as outlined in ENGINE FAILURE DURING TAKE-OFF.

WARNING

Do not allow airspeed to decrease below safe single engine airspeed.

1. Airspeed

130 knots IAS maximum

P

NOTE

At 110 knots IAS or below, the airflow may be insufficient to windmill the propeller and the starter may have to be used.

CAUTION

As a precaution against overspeeding during unfeathering, it is recommended that the propeller of the feathered engine be set to DECREASE rpm, the throttle be closed and airspeed reduced to 130 knots or below.

2. Throttle

Closed

CP

3. Propeller

Full DECREASE

CP

4. Mixture

IDLE CUT-OFF

CP

5. Fuel emergency shutoff switch

DOWN and guarded

CP

6. Oil emergency shutoff switch

DOWN and guarded

CP

7. Secondary bus switch

DOWN and guarded

CP

8. Propeller reverse circuit breaker

Closed

CP

WARNING

With the propeller reverse circuit breaker open, the number 2 blade switch will be rendered inoperative and the propeller may go into reverse if the propeller governing system fails.

9. Starter switch

As required

P

CAUTION

If an engine has been shutdown for less than fifteen minutes, use the starter to crank propeller through 6 blades prior to unfeathering to check for a liquid lock. If an engine has been shutdown for more than 15 minutes crank through 15 blades to insure adequate engine pre-oiling.

10. Boost pump	NORMAL	P
11. Ignition switch	BOTH	CP
12. Propeller feathering button	Pull	CP

Pull the feathering button out and hold until the tachometer indicates 500-600 rpm then release. Check that feathering button returns to the neutral position. Maximum time for propeller auxiliary pump operation is 20 seconds continuous operation. The feathering button must be released before 800 rpm is reached. As the propeller unfeathers, monitor the rpm for engine overspeed. The rpm should rise to approximately 1500 rpm and stabilize at approximately 1300 rpm.

WARNING

If the rpm continues to increase unchecked, a runaway propeller is evident. Employ RUNAWAY PROPELLER PROCEDURES in this section.

CAUTION

If the propeller hesitates due to hydraulic lock, push the feathering button full in and refeather the propeller to preclude damage to the engine.

13. Oil pressure	Checked	CP
14. Mixture	AUTO RICH	CP
15. Engine instruments	Checked	CP

NOTE

If engine has been shutdown for a period of time that the oil temperature has dropped below the minimum required, engine oil pressure will be abnormally high, operate engine at 1500 rpm and 15 in. Hg MAP until oil temperature has reached a minimum of 40°C.

16. Generator	ON	CP
17. Electrical equipment	As required	CP
18. Boost pump	OFF	P
19. Power	As required	P

PROPELLER FAILURES.

A propeller malfunction will be indicated by one of the following conditions.

Propeller oil low-level warning light or visible propeller oil leak.

An engine overspeed.

RPM surge or fluctuation.

Failure of propeller to feather or unfeather.

PROPELLER OIL LOW LEVEL WARNING LIGHT.

Should a propeller oil low level warning light illuminate, monitor the tachometer and the propeller. If the rpm fluctuates or visible oil is detected, immediately shut down the affected engine in accordance with INFLIGHT ENGINE SHUTDOWN PROCEDURES in this section.

ENGINE OVERSPEED/RUNAWAY PROPELLER.

An engine overspeed will be detected by tachometer indications and an audible beat. If an overspeed occurs, attempt to control the propeller by the propeller lever. If at any time in flight the propeller overspeeds and cannot be maintained within limits with the propeller lever, a runaway propeller is evident, proceed as follows:

1. THROTTLES**RETARD****P****WARNING**

Should the runaway propeller occur just after takeoff or less than 500 feet above the ground and flight is to be maintained, retard only the throttle of the affected engine and control airspeed with pitch.

2. AIRSPEED**REDUCE****P****NOTE**

Reduce airspeed, but never below minimum control speed.

3. PROPELLER**FEATHER****CP****NOTE**

Should the propeller fail to feather, check that the propeller feather circuit breaker is closed.

4. Employ INFLIGHT ENGINE SHUTDOWN PROCEDURE after propeller has feathered**P, CP**

WARNING

If an excessive rpm condition is not brought under control immediately, excessive vibration, with possible blade failure may occur.

WARNING

- If unable to feather, maintain the slowest safe airspeed possible, move the passengers away from propeller line of rotation, and land as soon as possible.
- If the propeller fails to feather and there is no evidence of fire, the oil emergency shut-off switch should be left DOWN to supply oil to the engine for lubrication and to prevent engine seizure. If the propeller fails to feather and minimum safe altitude cannot be maintained, re-establish power to zero thrust if possible. If fire is evident, the oil emergency shutoff switch should be pushed UP.

PROPELLER FLUCTUATION.

An actual propeller fluctuation will be accompanied by an audible beat and/or aircraft vibration. Press to test the propeller oil low level warning light and visually check the propeller to insure that the malfunction is not due to oil starvation. Move the propeller through complete pitch ranges several times in an attempt to re-establish governor control. If the fluctuation is due to an electrical malfunction, it may be controlled by opening the propeller reverse circuit breaker.

CAUTION

If the propeller reverse circuit breaker is open, the propeller oil low level warning light and propeller reverse system will be inoperative.

PROPELLER LINKAGE CONTROL FAILURE.

The rpm may fluctuate above and/or below, then stabilize at approximately 2200 rpm if the propeller governor cable, cable pulleys, and linkage fail.

FIRES.

ENGINE FIRE.

Should an engine fire occur, it will be indicated by Zone 2 and Zone 3 fire warning lights. The engine must be shutdown immediately in accordance with INFLIGHT ENGINE SHUTDOWN PROCEDURE in this section.

WARNING

The fuel pump for the heaters is located in the right wing. In the event of fire in the right nacelle, both heater systems must be shutdown as soon as possible.

engine smoke and flame identification chart




CONDITION	CAUSE	ACTION
 1. AFTER BURNING	Excessively rich mixture	Reduce power. Lean mixture
2. BLACK SMOKE WITH ROUGH ENGINE 	Detonation after fire or backfire from lean mixture	Reduce power
3. BLACK SMOKE 	Possible oil leak	Monitor oil pressure and quantity light. If pressure drops below minimum feather
 4. BLUISH GREY SMOKE	Damaged or worn piston rings permitting cylinder to pump oil	No inflight action possible. Record on Form 781 and monitor condition
 5. BLACK OR BLUISH GREY SMOKE	Oil fire	Use fire and feather procedures
 6. FLAME	Gasoline fire	Use fire and feather procedures
 7. DENSE WHITE SMOKE	Fire in induction system, magnesium engine case has probably ignited	Use fire and feather procedures. Alert crew for bailout as fire can cause major structural damage

Figure 3-4

COMBUSTION HEATER FIRE.

A fire in either of the combustion heater systems will be indicated by the appropriate heater fire warning light. Should a heater fire occur, proceed as follows:

FLIGHT COMPARTMENT HEATER FIRE

- | | | |
|-----------------------|------|----|
| 1. Master switch | OFF | FM |
| 2. Air control handle | PULL | P |
| 3. Fire extinguisher | UP | CP |

NOTE

Should smoke be detected in the aircraft, employ SMOKE ELIMINATION procedure in this section.

- | | | |
|-----------|------|-----|
| 4. Oxygen | 100% | ALL |
|-----------|------|-----|

CARGO COMPARTMENT HEATER FIRE.

- | | | |
|-----------------------|------|----|
| 1. Master switch | OFF | FM |
| 2. Air control handle | PULL | FM |
| 3. Fire extinguisher | UP | CP |

NOTE

Should smoke be detected in the aircraft, employ SMOKE ELIMINATION procedure in this section.

- | | | |
|-----------|------|-----|
| 4. Oxygen | 100% | ALL |
|-----------|------|-----|

FUSELAGE FIRE.

Should a fire develop inside the aircraft, it should immediately be fought with hand fire extinguishers by the FM/LM. 100% oxygen should be used. All entrances and windows should be kept closed until the fire is out. After the fire is out employ SMOKE ELIMINATION procedure in this section.

CAUTION

Fire extinguishing agent (CF₃Br) should not be allowed to come in contact with the skin as it may cause frostbite or low temperature burns. The extinguishers should be discharged one at a time to prevent inadvertent splashing.

WING FIRE.

Except for an engine fire that spreads to the wing, in all probability a wing fire will originate electrically. It is essential, therefore, to deenergize the offending circuit if it can be isolated and, as additional circuits could be damaged by the fire and create other possible hazards, to deenergize all nonessential services for the remainder of the flight. The circuits contained in the outboard wings are:

- a. Heater fuel pump
- b. Landing lights
- c. Fuel boost pumps
- d. Fuel quantity
- e. Gyro compass
- f. Navigation lights
- g. Formation lights
- h. Aileron trim
- i. Stall warning
- j. Fuel low level light
- k. Pitot heat (lift transducers)

The actions to be taken subsequently depend entirely on whether or not the fire persists; its locality and severity, with due regard to the fuel tanks; and aircraft altitude. Sideslipping the aircraft will assist in diverting the fire as necessary.

WARNING

If the fire persists or increases and indications of consequent structural failure are evident, the aircraft should be abandoned, ditched, or landed immediately.

ELECTRICAL FIRE.

When fire or smoke in the aircraft is suspected to be of electrical origin but the source is not determined, proceed as follows:

1. EMERGENCY BUS	EMERG	CP
2. BATTERY	OFF	P
3. GENERATORS	OFF	CP
4. OXYGEN	100%	ALL

5. Fight the fire

FM

If the fire goes out the defective circuit is either on the main bus or secondary bus. If the fire continues to persist, it is probable that a short circuit exists in one of the emergency bus power systems. All emergency bus power systems can be deactivated by returning the emergency bus switch to normal or each system can be deactivated by opening individual emergency bus circuit breakers. Depending on requirements and flight conditions, isolate the emergency bus circuits by pulling emergency bus circuit breakers one at a time until the defective system is identified or returning emergency switch to normal.

WARNING

All essential navigational instruments, radios and interphones will be deactivated if the emergency bus switch is returned to normal. Do not select normal if these systems are required due to flight conditions.

6. All electrical switches/circuit breakers (affected buses) OFF/OPEN

ALL

NOTE

If the defective system cannot be identified, turn all electrical systems off.

7. Generators and battery switches

ON

P, CP

- a. Turn the battery and generators on, one at a time, after the smoke/odor has cleared, check for a defective system
- b. Turn on only those systems required. Allow sufficient time between turning systems on to observe results before energizing the next system
- c. If cause of fire cannot be identified, land as soon as possible, use only those systems required for flight

SMOKE/FUMES ELIMINATION.

If smoke or fumes are detected in the aircraft, proceed as follows:

WARNING

Smoke and fumes elimination procedures will not be used until fire has been extinguished.

CAUTION

Use smoke mask attached to the walk-around oxygen bottle when smoke and fumes are present.

Close pilots' sliding windows and overhead vents.

Cockpit air control and air selector handles in.

Pilots' fresh air vents open.

abin air control handle pulled.

Cabin hot day valves open.

Cargo door opened approximately 12 inches.

FUEL SYSTEM FAILURES.**FUEL PRESSURE DROP – GROUND OPERATION.**

Shutdown affected engine.

FUEL PRESSURE-DROP – ENGINE STOPS.

Should a low fuel pressure warning light illuminate and the engine stop, close the throttle and check the engine for fuel leaks. If there is no evidence of a fuel leak, proceed as follows:

Turn the boost pump to HIGH. If the warning light does not go out, turn the boost pump off, turn the other boost pump to HIGH and turn the fuel tank selector to feed both engines from the other tank. If the low fuel pressure warning light continues to glow, shutdown the affected engine in accordance with INFLIGHT ENGINE SHUTDOWN PROCEDURE in this section.

NOTE

If operation of the affected engine is restored, the boost pump should be turned to NORMAL.

FUEL PRESSURE-DROP – ENGINE OPERATES NORMALLY.

Should the fuel pressure drop below normal operating limits and the engine continue to function normally, make a visual check for fuel leaks in the engine nacelle and at the aft end of the augmentor tubes. If fuel leaks are noted, shutdown the engine immediately by changing the mixture to IDLE CUT-OFF and then follow INFLIGHT ENGINE SHUTDOWN PROCEDURES in this section.

WARNING

The boost pump must not be turned on if fuel pressure drops below the low limit while the engine continues to operate normally. A fuel leak may be responsible for the pressure drop.

If the cause of the fuel pressure drop cannot be determined and no evidence of a fuel leak exists, the engine may be operated only if necessary while the crew maintains a watch for fire.

Shutdown the engine prior to making any throttle movement or change in aircraft attitude. The engine must be shutdown by changing the mixture to IDLE CUT-OFF and then follow INFLIGHT ENGINE SHUTDOWN PROCEDURE in this section.

WARNING

It is possible to fly for several hours having a suspected fuel leak but no evidence of fire. This condition may be due to the airflow with its cooling and dispersing effects serving to prevent fire outbreak. Retarding the throttles or changing the aircraft attitude which changes the airflow characteristics, may cause a fire to develop. For this reason, the engine must be run at the same power setting until no longer required.

CAUTION

Should a fuel low pressure warning light illuminate, it should be accepted as indication of low fuel pressure, regardless of the fuel pressure indicated. Should the fuel pressure gage indicate a pressure below normal operating limit, but the warning light fails to illuminate, press-to-test the warning light and make visual checks for fuel leaks before deciding the fault is due to a defective gage only.

ELECTRICAL SYSTEM FAILURES.

It is extremely difficult to anticipate all the possible electrical failures and procedure for each failure. However, a broad analysis of the situation indicates that failures fall into three possible categories:

1. Loss of one or more of the primary power sources.
2. Malfunctions of the main bus or distribution system.
3. Malfunctions within equipment items.

Malfunctions in the distribution system and load circuits should be controlled through protection devices such as circuit breakers, fuses, and current limiters. Should one of these devices fail to operate, considerable smoke can result and some emergency action on the part of the crew may be needed. Loss of the main dc bus is unlikely. Loss of one or more of the primary power sources, however, will require the crew to take prompt action by closely watching electrical loads, so that the remaining power sources will not be overloaded.

FAILURE OF ONE GENERATOR.

Should a generator power failure warning light illuminate, proceed as follows:

1. Generator switch
 - a. Push the generator switch down to the RESET position and then ON
 - b. Manually reset the field control relay by pushing the manual reset lever down should the electrical reset switch fail

RESET/ON

CP/FM

NOTE

- The generator field reset circuit breaker must be closed to electrically reset the field control relay. Only one attempt should be made to reset the circuit breaker.
- Main bus voltage will be indicated on both voltmeters even though one generator is inoperative. If the affected generator continues to drop off the line, it may be due to an over-voltage condition. In this case the voltmeters

will show a momentary increase immediately after RESET/ON. If the voltage of the affected generator is too high it must be adjusted before the generator can be returned to the line.

2. Ammeter

Checked

CP

NOTE

The field control relay has been reset if the failed generator ammeter indicates a load and warning light is extinguished.

If generator output cannot be restored, the generator must be turned OFF and the following procedure employed. The aircraft must be landed at the nearest suitable airfield.

3. All unnecessary electrical equipment

Off

ALL

4. Generator switch

OFF

CP

5. Secondary bus reset switch

UP

CP

6. Ammeter

Checked

CP

CAUTION

- Do not allow the operating generator output to exceed 300 amperes.
- Periodically check the engine to ascertain that the failed generator does not cause an engine fire.

FAILURE OF TWO GENERATORS.

Should both generators fail, proceed as follows:

1. Generators

OFF

CP

2. Generator

RESET/ON

CP

- Select either (not both) generator to RESET, then ON.
- Should the generator be restored, employ FAILURE OF ONE GENERATOR procedure to restore the remaining generator.

- c. If electrical reset is unsuccessful on both generators, the following items must be accomplished:

NOTE

The generator field reset circuit breaker must be closed to electrically reset the field control relay. Only one attempt should be made to reset the circuit breaker.

- | | | |
|---|-------|-------|
| 3. Emergency bus | EMERG | CP |
| 4. Battery | OFF | P |
| 5. All unnecessary electrical equipment | OFF | P, CP |
| 6. Generator switch (select one) | ON | CP |
| 7. Manual reset lever | RESET | FM |
- a. Manually reset the field control relay by pushing the manual reset lever down.

NOTE

The generator may drop off the line due to an over-voltage condition. In this case the voltmeters will show a momentary increase after RESET/ON. If the voltage of the affected generator is too high, it must be adjusted before the generator can be returned to the line. Attempt to do this by rotating the generator voltage regulator rheostat counterclockwise.

- | | | |
|------------|---------|----|
| 8. Ammeter | Checked | CP |
|------------|---------|----|

NOTE

- The field control relay has been reset if the ammeter indicates a load and the warning light is extinguished.
- If generator output cannot be restored, the generators must be turned OFF. Conserve the battery as much as possible and land at the nearest suitable airfield.

WARNING

The propeller feathering controls, propeller reverse controls, and fuel boost pumps are inoperative when the main dc bus is deenergized.

Should a generator be restored employ **FAILURE OF ONE GENERATOR** procedure to restore remaining generator.

If power is restored proceed as follows:

9. Emergency bus switch

10. Battery switch

11. Electrical equipment

NORMAL

ON

As required

CP

P

CP

AMMETER FAILURE.

Should the ammeter for either generator indicate zero when other electrical indications are normal, check for a malfunctioned ammeter as follows:

Press to test generator failure light.

Turn off the generator switch for the affected generator.

Check for an increase on the opposite ammeter.

NOTE

An increased reading will indicate that both generators are operating and that malfunction is in the ammeter circuit.

Turn the generator switch on if the opposite ammeter reading increases. If no increase is noted, proceed with **FAILURE OF ONE GENERATOR** procedure in this section.

RUNAWAY AILERON TRIM.

Should a runaway trim occur, proceed as follows:

Reduce airspeed to relieve control pressure. Physical control of the aircraft will not be difficult. If the trim can be reversed, pull the aileron trim

circuit breaker as the trim passes through the neutral position.

INVERTER FAILURES.

MAIN INVERTER.

Should the standby inverter light illuminate while both generators are operating proceed as follows:

Check that the inverter circuit breakers are closed. Turn the inverter switch off then on to MAIN. If the standby light continues to glow, select the inverter to **STANDBY**.

NOTE

When the standby light illuminates, it indicates that the inverter circuit has been automatically transferred to the standby inverter.

If the inverter failure light and the 26 volts ac failure light illuminates with the inverter switch at MAIN, select the standby inverter. If the standby inverter light comes on, it indicates failure of the main inverter and changeover relay.

STANDBY INVERTER.

Should the standby inverter light go out while the standby inverter is operating, the ac failure light should illuminate to indicate a complete ac power failure. Should this happen, proceed as follows:

Check that the inverter circuit breakers are closed.

Check that the dc power circuit breakers are closed.

Turn the inverter switch OFF and then to MAIN.

If the ac failure light and the standby inverter light both go out, leave the inverter switch at MAIN. If the ac failure light continues to glow, turn the inverter switch OFF.

MAIN INSTRUMENT TRANSFORMER.

Failure of the main instrument transformer is indicated by illumination of the 26 volts ac failure light. Select the standby instrument transformer. If the 26 volts ac failure light goes out either the 1-ampere fuse has blown or the main instrument transformer is inoperative.

CARGO JETTISON.

Jettisoning of cargo can be dangerous, due to possible loss of aircraft control or structural damage; therefore, the aircraft commander must consider carefully the emergency situation, mission requirements, availability of suitable drop area, and whether jettisoning is necessary.

Parachutes or restraining harness will be worn by personnel jettisoning cargo. Cargo should be jettisoned out the ramp and cargo door opening. The ramp and cargo door should be in the airdrop position.

NOTE

Relatively light weight cargo should be jettisoned by hand.

JETTISONING PALLETIZED CARGO ON ROLLERS.

Cargo palletized on rollers, but not rigged for airdrop, may be jettisoned if the aircraft gross

weight limitation and MAC limitations are observed. If cargo is loaded on multiple pallets, pallets may be jettisoned one at a time provided the position of the pallets remaining in the aircraft does not cause the center of gravity to exceed limits. If a malfunction of the extraction system exists, the cargo may be jettisoned by pushing out or gravity extraction.

JETTISONING CARGO NOT ON ROLLERS.

Jettison of large heavy palletized or unpalletized cargo resting on the floor should be attempted only as a last resort.

CARGO JETTISON TECHNIQUE.

Detailing of emergency procedures is not practical because of the many variables. The following provides a basic procedure applying to emergency jettison of palletized cargo on rollers, but must be supplemented by sound pilot judgement for the specific conditions:

Establish nose up attitude to obtain a component of gravity for the extraction force.

Apply power to accelerate the aircraft to increase the effective extraction force.

CAUTION

During cargo jettison, move the elevator control slowly, smoothly, and no more than is necessary, to avoid the possibility of exceeding structural limits.

BAILOUT PROCEDURES.

In-flight evacuation exits are shown in figure 3-7. If the aircraft is under control and time permits, the order of preference for bailout exits are ramp and cargo door, right entrance door, and the flight compartment bottom hatch. The cabin emergency door exit, because of its small size should only be used as a bailout exit as a last resort. When time and aircraft control permit, proceed as follows:

Give bailout warning over the interphone system and three short rings on the alarm bell.

Reduce airspeed if possible.

NOTE

The recommended airspeed for bailout is 100 knots IAS.

If possible, head the aircraft toward an unpopulated area.

Open the ramp and cargo door.

If unable to open the ramp and cargo door, jettison the right entrance door and flight compartment bottom hatch.

NOTE

The flight compartment bottom hatch may be jettisoned by operating a handle located in a recess in the bulkhead above the upper doors and marked **BOTTOM HATCH JETTISON - OPEN INSIDE DOORS BEFORE PULLING HANDLE**. The upper (inside) doors must be opened first as they would be difficult to open during flight with the bottom hatch jettisoned.

NOTE

The cargo compartment emergency door, on the left of the cargo compartment near the wing, is jettisonable. The handle is marked **EMERGENCY EXIT - LIFT GUARD AND TURN HANDLE TO OPEN**. The right passenger door is jettisonable and has a jettison lever above the door marked **CABIN DOOR JETTISON - PULL LEVER DOWN**.

WARNING

The cargo door may be opened but must not be jettisoned during flight.

Give bailout command over the interphone system and by one long ring on the alarm bell.

LANDING EMERGENCIES.**HYDRAULIC SYSTEM FAILURES.**

Failure of an engine driven hydraulic pump will be indicated by the illumination of its respective warning light. The other pump will maintain sufficient system pressure to operate the hydraulic systems. Should a loss of hydraulic pressure occur due to both hydraulic pumps failing or the engines not operating, the main hydraulic system can be pressurized with the hydraulic hand pump by placing the hand pump selector to **NORMAL SYSTEM**. All normal systems will be operational at a reduced rate. If a leak in the system develops, the hydraulic pressure shutoff valve must be turned off immediately, and remain off during the remainder of the flight. The emergency procedures must then be used to extend the landing gear and charge the brake accumulator.

NOTE

Hydraulic fluid will become extremely hot when the hydraulic pressure shutoff valve is turned OFF. Land as soon as possible to minimize danger of heat damage to hydraulic seals.

LANDING GEAR MALFUNCTION.

Should one or more landing gear indicator lights fail to illuminate when the gear is selected down and the selector lever light remains illuminated, press to test the indicator light(s). If the light(s) illuminate when pressed, it can be assumed that the associated gear(s) is not locked down. Should the selector lever light illuminate only while the gear is in transit and the indicator light(s) fail to illuminate when pressed, it can be assumed that a fault exists in the circuit to the indicator light(s). In either case, the throttles should be closed to check the warning horn. A visual check should be made of the main gear red/white index marks for alignment, and of the nose gear condition through the nose gear observation window. If visual inspection indicates the gear(s) is not down and locked check system pressure, fluid level, circuit breakers, and proceed with emergency landing gear extension procedures.

LANDING GEAR EMERGENCY EXTENSION.

Emergency extension of the landing gear is listed as two separate procedures since different operations are used for the main gear and the nose gear. The nose gear should be lowered first as more time is required for this operation and less drag is imposed than from the main gear.

NOSE GEAR EXTENSION.

Should the nose gear fail to extend when a normal selection is made, proceed as follows:

1. Landing gear selector	DOWN	P
2. Hand pump selector	EMERGENCY SYSTEM	FM
3. Emergency landing gear down selector	ON	FM
4. Nosewheel down hand pump selector	ON	FM
5. Hand pump	Actuate	FM

NOTE

Continue hand pump operation until the nose gear indicator light indicates the gear is down and locked.

Should the nose gear fail to extend after having used both normal and hand pump systems, continue as follows:

6. Nosewheel emergency down (air)	Pull	FM
-----------------------------------	------	----

CAUTION

The nose gear emergency air bottle should be actuated only during an emergency. The nose gear must remain extended until the system is bled on the ground.

With a suspected nose landing gear indicating system malfunction, the nose gear should be extended using the air bottle. The handle labeled NOSEWHEEL EMERGENCY DOWN (AIR) should be pulled and held extended throughout the landing roll until the aircraft is stopped and down locks installed.

NOTE

- Pull the selector up and hold until the nose gear indicator light indicates the gear is down and locked.
- Failure of the nose gear to extend from the wheel well may result if a cocked nosewheel is encountered. See COCKED NOSEWHEEL.

COCKED NOSEWHEEL (A/C MODIFIED BY T.O. 1C-7A-595).

Should a cocked nosewheel condition be encountered while airborne, the following procedures may be used to center the nosewheel:

- a. Nosewheel steering switch ON
- b. Emergency steer switch ON (Switch is spring loaded
OFF and must be held ON).
- c. With third person visually checking alignment through the nose gear observation window at station 160, normally steer nosewheel to center (wheels vertical) using nosewheel steering wheel

NOTE

If gear is extended, alignment can be checked by viewing the strut housing and universal joint. The nosewheel is centered when the universal joint is parallel to the strut housing. (See figure 3-5.)

- d. Release nosewheel steering wheel and check that the nosewheel remains centered.
- e. Release emergency steer switch. Recheck nosewheel centered.


nose wheel housing and universal joint

Figure 3-5

MAIN GEAR EXTENSION.

Should either or both main gear fail to extend when a normal selection is made, proceed as follows:

- | | | |
|---|------|----|
| 1. Landing gear selector | DOWN | P |
| 2. Emergency landing gear down selector | ON | FM |
| 3. Main gear emergency extension | Pull | FM |

CAUTION

Visually check the gear down lock index marks and indicator lights to determine if the gear is in the down and locked position.

NOTE

Extension of the gear may be assisted by the application of "g" forces, or an increase in airspeed.

FAILURE OF GEAR TO RETRACT.

Should the gear fail to retract when selected "UP", proceed as follows:

Check hydraulic pressure.

Select the nosewheel steering switch "OFF". Allow sufficient time for nosewheel to center, then return switch to "ON."

Check the hydraulic circuit breaker is closed.

Check the hydraulic system quantity.

Check the hydraulic emergency panel to insure the emergency landing gear down selector is completely in the OFF position.

① Check main gear stabilizer rod.

If the gear will not retract after completing the above checks, place the landing gear selector in the DOWN position and land at a suitable airfield with crash and rescue equipment standing by.

WARNING

Do not recycle gear. If the gear fails to retract as the result of a bent or failed stabilizer rod, the gear may collapse on landing, even with all indications that the gear is down and locked. If the visual check indicates that the stabilizer rods are damaged keep a constant brake application immediately after touchdown until the aircraft is stopped and parking brakes are set. Keep brakes applied until airplane is stopped then set brakes without releasing. As the aircraft slows increase power to keep a positive rearward force on the gear. Once stopped with power on, have nose wheel chocked and then shut down. Leave parking brakes set and be prepared for possible gear collapse.

NOTE

Failure of the nose gear to fully retract may be caused by a cocked nosewheel. See COCKED NOSEWHEEL.

WING FLAP EMERGENCY OPERATION.

Should a hydraulic failure occur, due to loss of engine driven pumps, the wing flaps can be actuated as follows:

Turn the hand pump selector to **NORMAL SYSTEM**.

Turn all other hydraulic selectors off.

Place the wing flap selector to the desired flap setting.

Operate the hand pump until the flaps are extended to the desired setting.

BRAKE SYSTEM FAILURE.

If sufficient pressure is not available in the normal brake system for adequate braking, proceed as follows:

- | | | |
|-------------------------------|------------------|----|
| 1. Hand pump selector | As required | FM |
| a. In case of pump failure | NORMAL SYSTEM | |
| b. In case of low fluid level | EMERGENCY SYSTEM | |

NOTE

If the hand pump selector has been placed to **EMERGENCY SYSTEM**, the nosewheel steering switch should be turned **OFF**.

- | | | |
|--|-----------------------------|----|
| 2. Brake accumulator hand pump charging selector | ON, all other selectors OFF | FM |
| 3. Hand pump | Actuate | FM |

NOTE

Actuate the hand pump until 3000 psi is indicated on the brake pressure gage. Continue pumping during the landing roll until the aircraft is stopped.

CAUTION

Use brakes as little as possible during the landing roll. Use reverse power to assist stopping the aircraft.

NOTE

If brake pressure and reverse power is not sufficient to stop the aircraft, pull the emergency air brake handle steadily aft.

CAUTION

The emergency air brake handle must not be operated with a pumping action as this will rapidly deplete the compressed air supply.

NOTE

After the aircraft is stopped, the engines should be shutdown and chocks installed. No attempt should be made to taxi after brake failure.

LANDING WITH ONE ENGINE INOPERATIVE.

The approach for landing with one engine inoperative (figure 3-6) is made in the same manner as for a normal landing except flaps should not be extended more than 15 degrees until landing is assured. On final, establish the threshold airspeed as in a normal landing; however, do not allow the airspeed to drop below minimum control airspeed before landing is assured and all possibilities of a go-around have been eliminated. Due to the decreased drag of the feathered propeller, caution should be exercised to prevent overshooting.

WARNING


When operating close to stall speeds with gear extended and flaps full down, slipping the aircraft through excessive use of rudder must be avoided. Under these conditions, with aircraft in a bank, application of top rudder can cause the angle of bank to increase rapidly and uncontrollably unless immediate corrective action is taken to neutralize the rudder and/or increase airspeed.

A normal landing should be made. Directional control should be maintained by nosewheel steering, differential braking, and reverse power on the good engine. Aircraft will tend to swerve toward operative engine with power increased in reverse range.

SINGLE ENGINE GO-AROUND.

The decision to go around should be made as early as possible and before lowering flaps more than 15°. Below 400 ft above ground level with gear down and flaps more than 15°, a successful go around may not be possible. It may be desirable to make a controlled crash landing rather than attempt a single engine go around.

single engine landing and go-around - typical



NOTE:
DO NOT EXCEED 15° FLAP SETTING
UNTIL LANDING IS ASSURED

Figure 3-6

If a single engine go-around is to be made, the procedure to follow is:

- | | | |
|--------------|---------------|----|
| 1. PROPELLER | FULL INCREASE | CP |
| 2. THROTTLE | MAXIMUM POWER | P |

WARNING

Abrupt power increases may cause loss of directional control.

- | | | |
|----------|----|----|
| 3. FLAPS | UP | CP |
| 4. GEAR | UP | P |

NOTE

The gear and flaps should be retracted simultaneously to reduce drag as soon as possible. Less altitude will be lost by stopping flap retraction at 7° and accelerating to 85 KIAS. After the descent rate is arrested, raise flaps to 0° and accelerate to 91 KIAS.

- | | | |
|-------------------|-------------|----|
| 5. Carburetor air | As required | CP |
|-------------------|-------------|----|

LANDING WITH TIRE FAILURE.

Nose Landing Gear Tire Failure.

If one or both nosewheel tires are flat at time of landing, a normal landing may be made. Use brakes as little as possible. Hold the nose off the runway as long as possible and as speed decreases, gently lower the nose gear to the runway prior to loss of elevator control. Use nosewheel steering to maintain directional control. If necessary use asymmetric reverse power to assist in directional control. Taxiing is not recommended.

Main Landing Gear Tire Failure.

If a main wheel tire is flat at time of landing, a normal landing should be made. Lower the nose gear as soon as possible and use reverse power and

nosewheel steering to maintain directional control. If both tires on a main landing gear are flat, there will probably be a tendency to swerve towards that side. Line up and land on the side of the runway with good tires. Touch down the nose gear as soon as possible, hold forward pressure on the control column, and assure directional control with the nosewheel steering system and asymmetric reverse power. Use wheel brakes (on the side opposite the flat tires only) to assist in maintaining directional control. Use reverse power cautiously but to the fullest extent possible to reduce landing roll to a minimum. Do not attempt to taxi.

LANDING WITH GEAR RETRACTED.

Landing With One or Both Main Gears Retracted.

If, after attempting all possible gear lowering methods, one or both main gear cannot be

extended and locked, the following procedure is recommended:

Attempt to retract all landing gear by placing the landing gear selector in the UP position.

If all gear retract, lower the nose gear by leaving the landing gear selector in the UP position and proceed with the remaining items on the NOSE GEAR EXTENSION checklist. Land with only the nose gear down. (Refer to GEAR UP LANDING.)

Landing With Nose Gear Retracted and Main Gears Down.

WARNING

If the main gear is extended and the nose gear has failed to extend, retract the main gear and attempt to lower the nose gear with the emergency system after relieving the pressure. Turning the hydraulic pressure shutoff valve off will relieve the pressure.

WARNING

If the nose gear fails to respond to normal and emergency operating procedures, an emergency landing may be accomplished. An aft CG is desirable. Make a normal approach and landing holding the nose of the aircraft up as long as possible but not until elevator control is lost. The nose should be gently lowered to the runway. (Refer to GEAR UP LANDING.)

The pilot is prevented from bending forward when shoulder harness is locked; therefore, insure that all controls which cannot be easily reached are properly positioned before locking the harness.

Landing With One Main Gear in an Intermediate Position.

In the event one main gear remains in an intermediate position, i.e., cannot be fully extended or retracted, anticipate that the malfunctioning gear will collapse upon landing.

The recommended procedure is to retract the other main gear and nose gear, then complete the procedure for lowering the nose gear and land with nose gear down as outlined in the Landing With One or Both Main Gear Retracted procedures.

GEAR-UP LANDING.

Before making a gear-up landing, burn off as much fuel as practicable and perform the following:

Select radio distress frequency, select IFF/SIF if necessary, inform appropriate control facility and request runway be foamed.

Give warning over the interphone system and give six short rings on the alarm bell.

Open the side escape hatch and cargo door.

Jettisoning of cargo should be considered.

Stow or secure all loose equipment.

Turn off heaters and all unnecessary electrical equipment.

Take crash landing position, passengers behind cargo.

Turn on the FASTEN BELTS/NO SMOKING signs.

Fasten shoulder harness and inertia reel locks.

Make a normal approach, flaps as desired.

Assume a normal landing attitude.

Give warning over the interphone and give one long ring on the alarm bell prior to impact.

After contact with the runway, move mixture to IDLE CUT-OFF, turn off ignition switches, select fuel emergency shutoff and oil emergency shutoff switches UP.

If fire is evident, pull the fire extinguisher control prior to turning off the battery switch and abandon the aircraft immediately after movement stops.

LANDING ON SOFT GROUND OR UNPREPARED RUNWAYS.

If it should become necessary to land on soft ground or an unprepared runway, the decision to land with gear extended or retracted must be made by the pilot. However, if the decision is to land with the landing gear retracted, the recommended procedure is to land with the nose gear extended and the main gear retracted. Procedures outlined in GEAR-UP LANDING should be followed. If the nature of the terrain is not too rough, it is advisable to land with all gear down, using the short-field landing technique.

MAXIMUM GLIDE AND LANDING WITH BOTH ENGINES INOPERATIVE.**CAUTION**

To provide continuous hydraulic pressure, one or both propellers must be windmilling. If both propellers are feathered, the landing gear will have to be lowered using the emergency system and the flaps by using the hand pump and the normal system.

emergency escape routes, exits and equipment




Figure 3-7

In the clean configuration with both propellers feathered, the recommended glide speeds are contained in T.O. 1C-7A-1-1. The descent should be planned to arrive over the threshold of the landing area at 1500 ft. From this point, put the landing gear down and initiate a continuous turn to position the aircraft on final at 800 feet approximately 1/2 mile from touchdown point. Flaps will be lowered as conditions dictate to control touchdown point and final approach speeds.

NOSEWHEEL STEERING FAILURE.

CAUTION

- With the nosewheel steering off, no attempt should be made to restrain or

operate the steering wheel. Manual control of the steering wheel in this condition would cause fluid to be emptied from the nose gear shimmy damper.

- Avoid taxiing into congested areas.

Should a malfunction of the nosewheel steering system occur, or with the loss of normal hydraulic system pressure, the nosewheel steering switch should be turned off. Directional control will be maintained through coordinated use of flight controls, differential power, and differential brakes according to the prevailing circumstances of speed, crosswinds, engine out and runway conditions.

NOSEWHEEL SHIMMY.

Nosewheel shimmy is an indication of unbalanced condition of one or both nosewheel tires or failure of the steering system. If this occurs during takeoff, the decision regarding whether to abort or to continue will depend on the severity of the shimmy and whether the refusal point has been passed, back pressure on the yoke will reduce nosewheel shimmy on takeoff. If shimmy occurs during the landing roll, decelerate gradually and apply up-elevator to keep as little load on the nosewheels as possible. In landing with a known shimmy condition, keep the nosewheels off the ground as long as possible, but touch down while elevator effectiveness allows gentle lowering of the nose.

EMERGENCY ENTRANCES.

Emergency entrances are those used by ground rescue personnel (figure 3-8).

EXTERNAL RELEASES.

Both entrance doors, the cargo compartment emergency door, the flight compartment bottom hatch, and the flight compartment roof hatch are equipped with external releases. The cargo door may be jettisoned by using the control on the right side exterior of the aircraft.

CHOPPING AREA.

A chopping location marked in yellow is painted on the left side of the fuselage beneath the wing. The location is marked on the inside and outside of the fuselage.

DITCHING.**DITCHING CHARACTERISTICS.**

Knowledge of the ditching characteristics of the C-7A is very limited; however actual ditching experiences and scale model ditching tests


emergency entrances

Figure 3-8

indicate that structural damage to the fuselage may occur which will cause rapid flooding of the flight and forward cargo compartments. On the basis of these tests, it is concluded that the following results can be expected upon ditching.

NOTE

- The characteristics assume the aircraft is ditched in a nose high attitude with flaps at 40°, and touching down with power on.
- In conditions of poor visibility or calm winds where flare point judgment is not possible, set up a rate of descent of 100 to 200 fpm at approximately 500 to 700 feet above the surface, and hold attitude, airspeed, and sink rate until contact.

Upon contact with the water, the aircraft may experience a pronounced nose-down attitude. The forward fuselage may momentarily be immersed, resulting in structural damage to the flight and forward cargo compartments which will permit rapid flooding up to the level of the wings. The aircraft will probably settle rapidly in a nose-down attitude. As the nose settles during the final part of the ditching run, the cockpit and fuselage will fill with water fairly fast.

DITCHING PROCEDURES.

WARNING

The aircraft should only be ditched as a last resort. It is recommended that the occupants bail out rather than ditch whenever possible.

In ditching situations in which the passengers can safely bail out, the large life raft in the cargo compartment should be dropped by parachute. This should be accomplished at an altitude of 500 feet and at an airspeed of 110 knots IAS after the passengers have bailed out and are in the water. The drop should be planned so that the life raft will land upwind of the survivors. The parachute, if partially inflated after contact with the water, will carry the raft towards the survivors. No provisions are made to inflate the raft during descent; therefore, the possibility of the raft being blown away from the survivors faster than they can maneuver to it is minimized. The ditching charts

(figure 3-9) give duties of personnel prior to, and during ditching. Figure 3-10 illustrates the emergency exits and evacuation routes used during ditching.

The following are the standard alarm signals for ditching:

SIX SHORT RINGS... PREPARE FOR DITCHING

ONE LONG RING BRACE FOR IMPACT

EMERGENCY DITCHING EQUIPMENT.

Ditching equipment should be in readiness at all times when flying over water. Prior to each overwater flight, the pilot will ensure that the necessary equipment is aboard, in serviceable condition, and stowed in the proper places.

EMERGENCY DITCHING EXITS (FLIGHT CREW).

From the evidence available concerning ditching, it is apparent that the pilot may be able to accomplish the maneuver without assistance. While this may not be true in all ditching situations, it would be worthwhile to consider stationing the copilot in the cargo compartment if conditions permit. The cockpit is considered to be the most hazardous area in the aircraft and stationing the copilot there not only increases the possibility of injury but could make it more difficult for either pilot to egress.

Refer to figure 3-10 for emergency exits. Normally, crew members in the flight compartment will use the roof hatch for exit after ditching. Crew members in the cargo compartment will normally exit through cargo door.

EMERGENCY DITCHING EXITS (PASSENGERS).

The loadmaster and flight mechanic will normally assist in evacuating passengers and carrying out duties outlined in the Ditching Chart (figure 3-9). The loadmaster will be responsible for briefing the passengers prior to flight. He will explain the use of the emergency equipment. The loadmaster will normally be seated in the passenger seat forward of the left entrance door when passengers are carried. All occupants of the cargo compartment will exit through the cargo door.

PREPARATION FOR DITCHING.

Plans for ditching cannot be made without taking the wind direction into consideration. Waves move downwind, and the spray from the wave crest is also blown downwind. Foam formed by the wave crest moves upwind from the crest and must not be

misinterpreted as indicating the wind direction. Also, swells do not always indicate wind direction and can be very large even when the wind is calm. Swells are the result of underwater disturbances. Over a sea, a pilot must be more exacting and alert when judging height.

ditching chart

T.O. 1C-7A-1

CREW MEMBER	FIRST ACTION	DITCHING IMMINENT (10 MINUTES LEFT)	AFTER DITCHING
PILOT'S DUTIES	1. Order crew to prepare for ditching, giving approximate time remaining. Order crew to start emergency procedures. Each crew member will acknowledge. 2. Transmit on VHF/UHF "Mayday" 3 times, and identification 3 times. Transmit tone for 20 seconds and request fix or bearing. 3. Obtain flashlight. 4. Don antiexposure suit and life vest. Fasten shoulder harness and safety belt.	1. Alert cargo compartment personnel with interphone and six short rings on the alarm bell. 2. Order copilot to transmit final distress signal. 3. If applicable, order all crew members and passengers to turn on emergency flashlights connected to life vests. 4. Order all crewmembers and passengers to secure themselves in ditching position. (Consideration should be given to stationing the copilot in the cargo compartment). 5. If copilot is positioned in cargo compartment, give one long ring on the alarm bell. 6. Lock shoulder harness. 7. Immediately before ditching, warn personnel over interphone to "brace for impact"; and, if copilot is positioned in flight compartment, order him to give one long ring on alarm bell.	1. Check flight station and cargo compartment to insure that all personnel and emergency equipment have been evacuated. 2. Exit through flight station escape hatch or cargo door and inflate life vest. 3. Board life raft and receive emergency equipment.
COPILOT'S DUTIES	1. Acknowledge pilot's order to prepare for ditching. 2. IFF/SIF/AIMS to emergency. Transmit emergency signal on HF radio followed as soon as possible by emergency message. 3. Obtain D/F service, bearings, fixes, etc. 4. Obtain flashlight. 5. Don antiexposure suit, and life vest, fasten shoulder harness and safety belt. 6. Continue transmitting outlined emergency message as required.	1. Transmit final distress signal and intentions of pilot as to ditching. 2. On orders from pilot, assume final position for impact (may be either flight compartment or cargo compartment). 3. If in flight compartment: Lock shoulder harness. If in cargo compartment: Select a seat and fasten safety belt. 4. If in flight compartment: On orders from pilot, give one long ring on alarm bell.	1. Exit through flight station emergency escape hatch, or cargo door. 2. Inflate life vest and board life raft.

Figure 3-9 (Sheet 1 of 2)

ditching chart (cont)

CREW MEMBER	FIRST ACTION	DITCHING IMMINENT (10 MINUTES LEFT)	AFTER DITCHING
FLIGHT MECHANIC'S DUTIES	1. Acknowledge pilot's order to prepare for ditching. 2. Obtain drinking water container and flashlight. 3. Open cargo door. Check ramp fully closed and draftproof door up and secure. 4. Don antiexposure suit and life vest.	1. Secure loose articles in flight compartment. 2. Select a seat in cargo compartment and fasten safety belt.	1. Assist in launching life rafts. 2. Exit through cargo door with container of water. 3. Inflate life vest, and board life raft.
LOADMASTER'S DUTIES	1. Acknowledge pilot's order to prepare for ditching. 2. Advise passengers of impending emergency. 3. Prepare to jettison cargo and advise pilot when ready. Jettison on command. 4. Obtain flashlight. 5. Don antiexposure suit and life vest. 6. Rebrief passengers in evacuation and distribution on life rafts. 7. Notify pilot when cargo compartment is prepared for ditching.	1. Insure that passengers are behind cargo if possible and properly seated. 2. Secure all loose equipment. 3. Fasten safety belt.	1. Launch life rafts. 2. Direct evacuation of passengers. 3. Exit through cargo door. 4. Inflate life vest and board life raft.

Figure 3-9 (Sheet 2 of 2)

ABANDONING AIRCRAFT.

Evacuation of the aircraft after ditching should be accomplished in an orderly manner in the shortest time possible. This cannot be done well without practice and in the event that the fuselage is dark and filling with water, further difficulty can be expected.

WARNING

The crew and/or passengers must not leave ditching positions until it is ascertained that the aircraft has stopped forward movement. Serious injuries can occur as the result of personnel unfastening safety belts prior to the aircraft coming to a full stop.

ditching exits




Figure 3-10

Immediately after the aircraft comes to a stop, additional emergency equipment may be collected and distributed to each crew member. The crew members must carry out their duties (figure 3-9) and then evacuate the aircraft through the appropriate exit carrying the required equipment. They must also see that each piece of equipment for use in the life raft is secured by lines to prevent its being lost overboard.

WARNING

Assure that personnel are outside the aircraft and clear of escape exits prior to inflating life vest.

CREW DUTIES.

When it is certain that the aircraft has come to a complete stop, each crew member will proceed with the following duties:

The pilot and copilot will check each other to see if either has been injured. The copilot exits through the roof hatch and receives equipment being passed to the pilot, the pilot will exit through the roof hatch.

NOTE

If the copilot's ditching station is the cargo compartment, his primary ditching exit is the cargo door.

The flight mechanic and loadmaster will check to see if either has been injured. They will jettison the life raft through the cargo door and inflate. The loadmaster will assist passengers in evacuating through the cargo door and pass emergency

equipment to the life raft. The flight mechanic insures that all emergency equipment has been removed and passengers have been safely evacuated, and then exits through the cargo door.

DITCHING TECHNIQUE.

If possible, burn off as much fuel as possible to lighten the aircraft and reduce stalling speed. Empty tanks also help keep the aircraft afloat.

If possible, jettison cargo to lighten the aircraft.

Prior to commencing approach, turn on the FASTEN BELTS, NO SMOKING signs. Passengers should be warned to tighten their safety belts and lean towards the nose of the aircraft as far as possible, half turning and resting head on arms, and bracing their arms against the next passenger.

Open the cargo door.

NOTE

The cargo door must be fully open prior to touchdown as structural damage may preclude opening while in the water.

Check that the cargo ramp is fully closed.

DITCHING.

Best results will be obtained by following the procedures outlined below:

Ditch while power is available. Power will allow the pilot to choose the spot for ditching, and the most favorable landing position and attitude.

Use 40 degree flaps.

Execute a normal approach and assume a normal landing attitude.

WARNING

Under no circumstances should the aircraft be stalled in, since this will result in severe impact and cause the aircraft to nose into the water.

Touch down with power on and insure that the aircraft does not contact the water in a fully stalled attitude.

In daylight it is recommended that the aircraft be ditched along the top of the swell, paralleled to the rows of swells, if the wind does not exceed 30 knots. In high winds, it is recommended that ditching be conducted upwind to take advantage of lowered forward speed. However, it must be remembered that the possibility of ramming nose-on into a wave is increased, as is the possibility of striking the tail on a wave crest and nosing in.

CROSSWIND DITCHING.

The basic rules for ditching listed in DITCHING will still apply, in addition to the following:

Crab the aircraft to kill drift.

Land on the downwind side of the swell or wave.

UPWIND DITCHING.

The basic rules for ditching listed in DITCHING will still apply, in addition to the following:

Maintain nose-up attitude, avoid striking wave face.

Touch down immediately behind the crest of a rising wave, avoid the face of the wave.

Hold nose up after first impact.

NIGHT DITCHING.

Night ditching will be conducted with the aid of instruments to establish proper attitude of aircraft.

Make an instrument approach, holding airspeed the same as for DITCHING. At 500 to 700 feet above the water, set up approximately 200 feet per minute rate of descent with 40 degrees of flaps.

Use landing lights as necessary.

Hold wings level to avoid digging a wing into water and cartwheeling the aircraft.

Close throttles and turn off electrical power immediately upon contact with the water.

SECTION IV AUXILIARY EQUIPMENT

TABLE OF CONTENTS

INTRODUCTION	4-1
HEATING AND VENTILATING SYSTEMS ...	4-1
ANTI-ICING AND DEICING SYSTEMS.....	4-11
ENGINE PREHEAT SYSTEM	4-14

COMMUNICATION AND ASSOCIATED ELECTRONIC EQUIPMENT	4-18
--	------

INTRODUCTION.

This section includes the description, normal operation, and emergency operation of all equipment not directly contributing to flight but which enables the aircraft to perform certain specialized functions.

HEATING AND VENTILATING SYSTEM.

The flight and cargo compartments are each provided with a flight and ground operable heating system. The ducting and outlets of each system can also be used for ventilation on the ground and in flight when either heater is out. Each system consists of a combustion heater with the necessary components and ducting controls to regulate the temperature inside the flight compartment and cargo compartment within a range of 40° to 80° F. Within each system are fans, recirculation ducts, and air selector valves to provide for ground operation; and an outlet from the cargo compartment heating system provides hot air for preheating the engines on the ground. The electrical controls for each heater are on a panel mounted on the forward face of the bulkhead behind the pilot. Fuel for both heaters is provided from the fuel tank in the right wing by an electrically driven fuel pump outboard of the engine nacelle.

LIGHTING SYSTEMS	4-33
OXYGEN SYSTEM.....	4-38
CARGO LOADING EQUIPMENT	4-41
CARGO DOOR AND RAMP SYSTEM	4-43
AIR DROP SYSTEM.....	4-47
MISCELLANEOUS EQUIPMENT.....	4-47

DC power for each temperature control system, and ground operation provision, is supplied from the secondary bus through push-to-reset circuit breakers, and through a switch type circuit breaker for each heater fuel control system. Provision is made for hot-day ram air ventilation of the flight compartment and cargo compartment. A fan air pressure switch which is operated by ram air from the copilot's pitot pressure line, serves both the flight compartment and cargo compartment heating systems. In the cargo compartment system the air selector valves are moved automatically to their ground or flight position by an electrical actuator operated by the fan air pressure switch. In flight the pressure switch maintains the combustion air fan and the ventilating air fan inoperative in both systems. The cargo compartment heater mixing valve can be controlled manually in the event of malfunction of the automatic control circuit.

FLIGHT COMPARTMENT HEATING SYSTEM.

The flight compartment combustion heater is rated at 50,000 BTU and consumes 0.66 gallon of fuel per hour maximum. It is mounted in the nose section of the fuselage and is accessible through a removable panel forward of the windshield. The left and right ram air ducts in the nose of the fuselage have 20- and 10-ampere electrically heated

anti-icing intakes respectively, and both are powered from the secondary bus through the 25-ampere push-to-reset circuit breaker. They are both controlled by the 5-ampere switch - type circuit breaker, under the INTAKE ANTI-ICING marking, on the lower section of the heating control panel (figure 4-2). The left duct supplies ram air, in flight, to the heater combustion chamber where it mixes with fuel and is ignited by a spark plug. The current for the spark plug is supplied through normal or standby vibrator contacts in an ignition unit. The exhaust gases flow through heat exchanger passages and are vented to the atmosphere. The right duct supplies ventilating ram air, in flight, which is passed over the hot walls of the heat exchanger. The resulting warm air is distributed to ten outlets in the flight compartment.

Temperature Control System.

The temperature control system of the heater is automatic. It consists of a heater outlet duct thermostat, compartment thermostat, temperature selector, and a temperature control box. The heater is protected from overheating by a cycling thermal switch and a high limit thermal switch in the heater outlet duct. The cycling switch, in conjunction with a relay, operates the cycling solenoid in the fuel control unit to restrict the continuous operating temperature to a maximum of 250° F. The high limit switch operates at 350° F to energize the heater electrical system should the cycling switch malfunction. A further safeguard is provided by a fire detecting element in the heater outlet duct which will illuminate the fire warning light on the left side of the emergency panel if the temperature rises to 550° F.

Preparation For Operation.

Before the heater can be started on the ground or in flight, the following conditions must exist:

1. The cockpit air control handle on the pilot's pedestal must be pushed fully in (open).
2. The cockpit air selector handle on the pilot's pedestal must be positioned for ground or flight operation as appropriate.
3. A combustion ram air pressure equivalent to approximately 80 knots IAS must be sensed by the ram air pressure switch.

4. The heater discharge temperature must be less than 350° F.

Provided these conditions exist, when the master switch and fuel pump are turned on, the heater will start operating provided the start switch is depressed. The start switch indicator light will illuminate to show that the system is energized.

Heater Controls.

The lower section of the heating control panel (figure 4-2), on the bulkhead behind the pilot's seat, is marked COCKPIT HEAT & VENTILATION and contains the switches and controls necessary for operation of the flight compartment heater, and for control of the heater intake anti-icing elements.

Heater Fuel Pump Switch. The heater fuel pump two-position switch is marked FUEL and OFF. The switch controls the electrical circuit of the fuel pump in the right wing, which supplies fuel to both the flight compartment and cargo compartment heaters.

Heater Ignition Switch. The heater ignition switch is of the toggle type and has two positions, marked EMERG and NORMAL. When operating in the normal position and the heater fails, select the emergency position. Enter the discrepancy in Form 781 at the completion of the flight. The EMERG position provides a standby set of vibrator contacts to restore ignition.

Heater Master Switch. The heater master two-position toggle switch is labeled MASTER SWITCH. The switch controls the dc power from the secondary bus to the heater and fuel control system.

Heater Start Switch. The heater start push-type switch is marked PUSH TO START and controls the electrical power to a hold-in relay supplying the heater ignition unit electrical circuit. A light in the switch will illuminate when the circuit is energized. The master switch must be on before the start switch is depressed.

Heater Temperature Selector. The heater temperature selector is marked TEMP. SELECTOR and is graduated in °F with numerals at 40, 60, and 80. The selector sets the temperature control system of the heater to maintain the temperature

in the compartment, as sensed by the compartment thermostat and the heater outlet duct thermostat.

Heater and Fan Circuit Breakers. A 5-ampere push-to-reset circuit breaker marked HEATER protects the heater electrical circuit. A 10-ampere push-to-reset circuit breaker marked FAN protects the circuits of the combustion ram air fan and ventilation return air fan.

Heater Intake Anti-Icing Circuit Breakers. Below the INTAKE ANTI-ICING marking is a 5-ampere switch-type circuit breaker control marked CONT., for selection of the heater intake anti-icing circuit, and a 25-ampere push-to-reset circuit breaker marked HEATER for circuit protection.

Air Control Handle. The air control handle on the pilot's pedestal is marked COCKPIT AIR CONTROL and PULL TO CLOSE. The handle is used to mechanically adjust a butterfly-type valve in the heater outlet duct to regulate the amount of ventilating air entering the flight compartment. When the handle is pushed in, the valve is opened and releases its pressure on a microswitch to allow operation of the heater. When the handle is pulled fully out, the valve closes and operates the microswitch to deenergize the heater electrical circuit; this position should be selected in the event of fire.

Air Selector Handle. The air selector handle on the pilot's pedestal is marked COCKPIT AIR SELECTOR, and FLIGHT-PUSH, GROUND-PULL. The handle is used to mechanically actuate two butterfly-type valves, one in the ventilating ram air intake duct and one in the ventilating air return duct. When the handle is pulled out to the GROUND position the ram air intake duct valve operates a microswitch which energizes two fans, one in the ram air intake duct to supply combustion air and one in the air return duct to recirculate the air from the flight compartment. An air pressure switch, in the fuselage nose section, deenergizes the circuit of the fans after take-off upon attaining an airspeed of approximately 85 knots IAS; and prevents operation of the fans should the air selector handle be inadvertently left at GROUND position during flight. The air pressure switch is pressurized from the copilot's pitot line and is common to both the flight compartment and cargo compartment heating systems.

Operation.

Ground and flight operation of the heating system is covered in the following paragraphs.

Ground Operation.

1. Heater and fan circuit breakers - Set.
2. Cockpit air control handle - Push in (open).
3. Cockpit air selector handle - GROUND.
4. Fuel pump switch - UP (on).
5. Heater ignition switch - NORMAL.
6. Temperature selector - Set to desired temperature.
7. Master switch - UP (on).
8. Start switch - Depress.
9. Start switch indicator light - Should illuminate and remain on during heater operation.

On transition from Ground to Flight operation of the heater, it will be noted that only actions 3 & 8 of the following paragraphs are necessary.

Flight Operation.

1. Heater and fan circuit breakers - Set.
2. Cockpit air control handle - Push in (open).
3. Cockpit air selector handle - FLIGHT.
4. Fuel pump switch - UP (on).
5. Heater ignition switch - NORMAL (EMERG if NORMAL is inoperative).
6. Temperature selector - Set to desired temperature.
7. Master switch - Up (on).

flight compartment heating and ventilating system




Figure 4-1

heating control panel




Figure 4-2

8. Start switch - Depress.
9. Start switch indicator light - Should illuminate and remain on during heater operation.

CARGO COMPARTMENT HEATING SYSTEM.

The cargo compartment combustion heater is rated at 200,000 BTU and consumes 2.66 gallons of fuel per hour maximum. It is mounted in the right side of the cargo compartment roof immediately aft of

the flight compartment bulkhead. The ventilating ram air duct, in the leading edge of the right wing does not have an anti-icing intake. In flight, the duct in the left wing supplies ram air to the heater combustion chamber where it mixes with fuel and is ignited by a spark plug. The current for the spark plug is supplied through normal or standby vibrator contacts in an ignition unit. The exhaust gases then flow through heat exchanger passages and are exhausted to atmosphere. The duct in the right wing supplies ventilating ram air in flight, and

the flow of air divides before reaching the heater. Some of the air passes over the hot walls of the heat exchanger, and some of it passes through a heater bypass duct. The heated air and cold bypass air rejoin at the discharge end of the heater, where the degree of mixing is controlled by an electrical actuator-operated mixing valve which is positioned according to cargo compartment temperature selector requirements. Variations are sensed by the cargo compartment thermostat in the rear exhaust outlet and the heater outlet duct thermostat. The flow then passes to eight outlets along each side of the cargo compartment and to one outlet in the cargo compartment roof at the rear. Two interconnected ventilating air exhaust outlets in the cargo compartment roof pass used air to atmosphere, through the cargo compartment exhaust vent, during flight. During ground operation, mechanically interconnected electrical actuator-operated valves in the combustion air duct, ventilation air duct, and cargo compartment exhaust vent are closed; and a combustion air bypass duct and ventilating air bypass duct are opened, and a fan in each is energized. An amber colored CAUTION light will illuminate during operation of the fans. The combustion air fan draws air through the ram air intake in the left wing and passes it to the heater combustion chamber. The ventilation air fan draws cargo compartment air through the cargo compartment air exhaust outlets and recirculates it over the hot walls of the heat exchanger and then passes the heated air to the outlets on each side of the cargo compartment. (See figure 4-3.)

Temperature Control System.

The temperature control system of the heater is basically automatic. However the heater mixing valve can be manually controlled, in the event of failure of the automatic control circuit, by means of a control selector on the upper section of the heating control panel. The system consists of a heater outlet duct thermostat, cargo compartment thermostat, temperature selector, control selector, and a temperature control box. Cargo compartment temperature is automatically controlled in a similar manner to that given for the flight compartment heater. The heater is protected from overheating and is safe-guarded in a similar manner to that given for the flight compartment heater. However, the fire warning light for the cargo compartment heater is on the right side of the emergency panel.

Preparation For Operation.

Before the heater can be started on the ground or in flight, the following conditions must exist:

1. The cargo compartment air control handle, located below the heating control panel, must be pushed fully in to open the valves in the tee duct at the outlet end of the heater and allow the safety microswitch to complete the electrical circuit.
2. A combustion ram air-pressure equivalent to approximately 80 knots IAS must be sensed by the ram air pressure switch.
3. The heater discharge temperature must be less than 350° F. Provided these conditions exist when the master switch and fuel pump switch are turned on, then the heater will operate when the start switch is depressed. The start switch is depressed. The start switch indicator light illuminates to show that the system is energized. The mechanically interconnected air selector valves are automatically positioned for the type of operation, ground or flight, by an electrical actuator operated by the fan air pressure switch in the fuselage nose section. When the air pressure sensed by the switch is less than the equivalent of 85 knots IAS the selector valves are positioned for ground operation, the fans are energized and the CAUTION light illuminates. Above 85 knots IAS the selector valves are positioned for flight operation, and the fans are deenergized and the CAUTION light is off.

Heater Controls.

The upper section of the heating control panel (figure 4-2), on the bulkhead behind the pilot's seat, is marked CABIN HEAT & VENTILATION and contains the switches and controls necessary for operation of the cargo compartment heater, and for control of the heater combustion ram air intake anti-icing element. The heater fuel pump electrical circuit is controlled by the fuel pump switch on the lower section of the heating control panel. For a description of the ignition, master, and starter switches, refer to flight compartment heater.

Heater Temperature Selector. The heater temperature selector is marked TEMP. SELECTOR and graduated in °F with numerals at 40, 60, and

cargo compartment heating and ventilating system




Figure 4-3

80. The selector sets the temperature control system of the heater to maintain the temperature in the cargo compartment, as sensed by the cargo compartment thermostat and the heater outlet duct thermostat.

Heater Control Selector. The four-position control selector is marked CONT. SELECTOR with positions OFF, MAN. HOT, AUTO, and MAN. COLD. The selector setting determines the type of operation of the heater. In the AUTO position the mixing valve, at the junction of the heater outlet and heater bypass duct, is automatically controlled by the temperature control system to regulate the amount of cold bypass air mixing with the heated air from the heater. In the MAN. HOT position the temperature control system is bypassed and the mixing valve is moved to close the heater bypass duct to allow heated air only to be fed to the cargo compartment outlets. In the MAN. COLD position the temperature control system is bypassed and the mixing valve closes the heater outlet to allow cold air only to be fed to the cargo compartment outlets. During manual operation the mixing valve can be positioned at intermediate settings by moving the control selector to OFF when the desired setting is reached. The valve takes approximately 45 seconds to move from MAN. HOT to MAN. COLD.

Heater And Fans Circuit Breakers. A 7-ampere push-to-reset circuit breaker marked HEATER protects the heater electrical circuit. Two push-to-reset circuit breakers protect the FANS circuit; the 5-ampere breaker marked COMB. for the combustion air fan, and the 20-ampere breaker marked VENT for the ventilating air fan. When the winterization equipment hi-capacity fans are installed, the 5- and 20-ampere breakers will be replaced by 35- and 50-ampere breakers respectively.

Caution Light. An amber light marked CAUTION will illuminate when the ventilating air fan and combustion air fan are in operation. If the light illuminates in flight, indicating that the fans are energized, the COMB. fan circuit breaker should be pulled to deenergize combustion fan and light circuit.

Cargo Compartment Air Control Handle. The cargo compartment air control handle, below the heating control panel, is marked AIR CONTROL - CABIN, PULL TO CLOSE. The handle is used to manually

position butterfly-type valves to regulate the amount of ventilating air entering the cargo compartment. When the handle is pulled to fully close the valves, the heater electrical system is deenergized. Pull the handle in the event of fire. When the handle is pulled to fully close the valves, a microswitch is actuated to deenergize the heater electrical system; select this position in the event of fire.

Operation.

Normal and emergency operation of the cargo compartment heating system is covered in the following paragraphs.

Normal Operation. Cargo compartment heater operation, both on the ground and in flight, is similar. Automatic positioning of the system air selector valves, and control of the fans, occurs at an air pressure equivalent to approximately 85 knots IAS; below this speed the system is placed in ground operation, and above this speed it is placed in flight operation. To start the heater proceed as follows:

1. Engine preheat outlet cover - Check secure during preflight inspection.
2. Hot day duct valves - Closed.
3. Heater and fans circuit breakers - Set.
4. Cargo compartment air control handle - Push in (open).
5. Fuel pump switch - Up (on).
6. Control selector - AUTO.
7. Temperature selector - Set to desired temperature.
8. Heater ignition switch - NORMAL (EMERG if NORMAL is inoperative).
9. Master switch - Up (on).
10. Start switch - Depress.
11. Start switch indicator light - Should illuminate and remain on during heater operation.

WARNING

If heat is not apparent within two minutes of switching on, heaters will be switched off and left off until the cause of the malfunction is determined and corrected.

12. Amber CAUTION light - Should illuminate and remain on to indicate that the fans are energized during ground operation. It should go out at airspeeds above 85 knots IAS, to indicate that the fans are deenergized and the air selector valves are in their flight operating positions.

WARNING

In the event of fire, the cargo compartment air control handle must be pulled to the fully closed position and the master switch moved to off.

CAUTION

If the thrust indicator free stream pressure selector, on the copilot's flight instrument panel, is moved to the EMERG OFF position in flight, and the heating control panel CAUTION light illuminates, pull out the COMB. fan circuit breaker. For subsequent system operation on the ground, circuit breaker must be reset.

Emergency Operation. If the automatic control of the heater air mixing valve malfunctions, the mixing valve can be controlled manually to regulate the temperature of the air being fed to the cargo compartment outlets. Temperature control is accomplished by moving the control selector as follows:

1. Position at MAN. HOT for approximately 30 seconds to move the mixing valve and close the heater bypass duct.
2. Position at MAN. COLD for 10 seconds, then to OFF. This partially opens the

heater bypass duct to admit cold air and reduce the temperature of the heated air fed to the cargo compartment outlets.

3. Repeated adjustment in this manner, varying the number of seconds at MAN. COLD, will modulate the heat supply until the desired temperature is obtained.

Operation Of Cargo Compartment Vent Air Exhaust Valve. When the system is switched off in the air, the cargo compartment vent air exhaust valve remains open. The valve only closes when the system is in ground mode. To prevent rain or moisture entering the valve when the aircraft is on the ground, the master switch should be switched on for a few seconds before shutting down the engine. This action will motor the valve to ground mode and it will close. With the master switch ON, insure engine rpm are sufficient to charge both generators.

FLIGHT COMPARTMENT VENTILATING SYSTEM.

The flight compartment ventilating system utilizes the ducting and outlets of the heating system with the heater in a deenergized condition. For hot day use two cooling louvers are installed, one on each side of the flight compartment, to provide additional fresh air for the pilot and copilot. Each louver is installed at the aft end of a short ram air intake, forward of the windshield. The direction and amount of ventilating air flow can be adjusted by turning the spherical louver and rotating its shutter knob. An adjustable air exhaust louver is installed in the rear of the canopy to the right of the aircraft centerline. Maximum ventilating air is provided when the hot day louvers and the cockpit air control handle are at the fully open position.

Operation.

Ground and flight operation of the flight compartment ventilating system is covered in the following paragraphs.

Ground Operation.

1. Heater circuit breaker - Pull out.
2. Fan circuit breaker - Set.
3. Cockpit air control handle - Push in (open).

4. Cockpit air selector handle - GROUND.
5. Master switch - Up (on).
6. Hot day louvers - Open for maximum ventilating air, if required.

NOTE

On transition from Ground to Flight operation of the ventilating system, only actions 4 and 5 of the following paragraphs are required.

Flight Operation.

1. Heater circuit breaker - Pull out.
2. Fan circuit breaker - Set.
3. Cockpit air control handle - Push in (open).
4. Cockpit air selector handle - FLIGHT.
5. Master switch - Down (off).

WARNING

In the event of fire the cockpit air control handle must be pulled to the fully closed position.

CARGO COMPARTMENT VENTILATING SYSTEM.

The cargo compartment ventilating system utilizes the ducting and outlets of the heating system with the heater in a deenergized condition. For hot day use in flight, ambient air can be admitted to the cargo compartment through ducting connected to the ventilating ram air intake in the leading edge of the right wing, and to three louvers in the cargo compartment roof. Two of these louvers are ahead of the forward air exhaust outlet, and the third louver is just aft of the wing rear spar. The amount of ambient air admitted through the louvers is controlled by manually operated butterfly-type valves. One just aft of the forward louvers and one at the rear louver; both marked HOT DAY VENTILATION ON-OFF. For hot day ventilation in flight, the cargo compartment air control handle must be pulled fully out (close) to shut off the

normal ventilating system and allow the maximum amount of ambient air to be directed to the three roof louvers, where the flow of air can be manually controlled. On the ground, ambient air ventilation can be supplied through the hot day louvers provided the right engine is operating; the propeller slipstream produces a ram air effect at the ventilating ram air intake.

Operation.

1. Heater and fans circuit breakers - Set.
2. Cargo compartment air control handle - Push in (open).
3. Master switch - Up (on).
4. Start switch - Do not depress.
5. Amber CAUTION light - Should illuminate and remain on to indicate that the fans are energized during ground operation, and should go out at airspeeds above 85 knots IAS to indicate that the fans are deenergized and the air selector valves are in their flight operating positions.

CAUTION

If the thrust indicator free stream pressure selector, on the copilot's flight instrument panel, is moved to the EMERG OFF position in flight, and the heating control panel CAUTION light illuminates, pull out the COMB. fan circuit breaker. For subsequent operation on the ground, circuit breaker must be reset.

Hot Day Ventilation Operation.

1. Cargo compartment air control handle - Pull out (close).
2. Hot day duct valves - Open.

NOTE

This operation can be used on the ground to supply fresh air ventilation, provided the right engine is operating.

ANTI-ICING AND DEICING SYSTEM.

The ice protection facilities consist of windshield anti-icing, heater and ventilating air intake anti-icing, and pitot head anti-icing; propeller deicing, and wing and tail deicing.

WINDSHIELD ANTI-ICING.

Both the pilot's and copilot's windshields are constructed of polyvinyl butyral sandwich panels. The laminations are heated electrically by current that passes through a transparent conductive coating between the sheets. In addition to providing anti-icing, heating of the panels prevents misting and also raises their birdproof qualities.

NOTE

Maximum bird proofing qualities of the windshield are obtained when the vinyl interlayer is maintained in the temperature range of 68° to 130° F. The windshield heat system maintains a temperature of $105 \pm 5^\circ \text{F}$, and the windshield is therefore at its maximum strength with the heat on.

Single phase ac power for each windshield panel is derived from individual windshield inverters powered from the secondary bus; the circuits being protected by 70-ampere circuit breakers. The associated dc relay circuits are protected by 5-ampere circuit breakers. Operation of the windshield heat is controlled by the windshield heat switch on the center switch panel. The switch, marked WINDSCREEN HEAT, has three positions: NORM., OFF, and EMERG. The switch should be set to NORM. at least three minutes prior to take-off. Should the pilot's windshield power supply fail, switching to EMERG. will transfer power to the pilot's panel from the copilot's panel, which will then cool. A warning light for each windshield inverter, marked FAIL, PILOT'S and COPILOT'S, is located adjacent to the control switch and will illuminate if its respective inverter fails.

CAUTION

If inverter failure is the cause of the defect, the appropriate circuit breaker should be pulled and no attempt must be

made to reactivate the inverter, or further damage to the system may result.

HEATER INTAKE ANTI-ICING.

The inlets for the flight compartment heater combustion and ventilation air intakes, and the cargo compartment heater combustion air intake, are electrically anti-iced. The cargo compartment heater ventilation air intake is not anti-iced. Below the IN-TAKE ANTI-ICING marking on both the cockpit heating and cargo compartment heating sections of the heating control panel, are provided a 5-ampere toggle-type circuit breaker control and a 25-ampere push-to-reset circuit breaker. The toggle-type circuit breaker marked CONT. controls the heater intake anti-icing circuit and the push-to-reset circuit breaker marked HEATER protects the circuit. The anti-icing elements are powered from the secondary bus.

PITOT HEAD ANTI-ICING.

Electrical anti-icing is provided for the four thrust-indicating pitot heads, and two pitot heads supplying the flight instruments. A switch marked PITOT is located on the deicing switch panel (figure 4-5). The switch also controls a heater at each stall warning lift transducer. Power for the flight instrument pitot heads and lift transducers is taken from the emergency bus through two 15-ampere circuit breakers, and for the thrust indicating pitot heads from the secondary bus through two 10-ampere circuit breakers.

PROPELLER DEICING.

An alcohol deicing system is provided for each propeller. Each system consists of an 8.4 gallon tank, an electrically operated shutoff valve, an electrically operated pump and the necessary piping to a slinger ring and cuffs. Both systems are controlled by a switch marked PROP on the deicing switch panel (figure 4-5). Power for each system is derived from the emergency bus through the left and right hydraulic and engine oil emergency shutoff switches respectively. When energized, the pump supplies fluid under pressure to the slinger ring, and is distributed to the leading edge of the propeller blades by centrifugal force.

The shutoff valve is solenoid operated and remains open while the pump circuit is energized.

NOTE

The rate of flow of each propeller deicing system is 1.27 gallons per hour, and will provide protection for 6.5 hours of continuous operation. However, as the alcohol deicing system is only used intermittently, the supply is sufficient for the endurance of the aircraft.

WING AND TAIL DEICING SYSTEM.

The system, (figure 4-4) is of the inflatable rubber-boot type, deicing being provided at the horizontal stabilizer leading edges and the wing leading edges outboard of the landing lights. Included in the system are two engine-driven air pumps, two combination units, distributor valves, an electronic timer, and the control switches on the deicing panel. System pressure and suction is indicated by two gages, marked DEICING, and PRESS and SUCT respectively, located on the copilot's pedestal. Refer to Section V for instrument markings. Electrical power for the system is taken from the secondary bus through two circuit breakers, AUTO and MANUAL, labeled DEICING WING & TAIL.

The deicer boots are arranged in sections. Two sections at the stabilizer, one left, one right; and two sections, an inboard and an outboard, at each wing. Each section is further divided into an inner and outer boot. A distributor valve serves each wing-boot section; one distributor valve is provided to serve both tailboot sections. The distributor valve has a pressure inlet port, a suction outlet port and a dump port. Two additional ports A and B are connected to related A (inner) and B (outer) boot ports. Pressure and suction is alternated through the A and B ports by movement of a solenoid-operated servo valve. The distributor valves are each connected to a common pressure manifold and a common suction manifold; pressure and suction being applied by either or both engine-driven air pumps. The suction side of each pump is connected direct to the suction manifold; suction being indicated at all times on the gage. The pressure delivery is routed through the combustion unit from which pressure is dumped

when the system is inactive or, when in use, is regulated to the pressure manifold to maintain 15 psi. Both pumps will provide satisfactory operation up to 20,000 feet. In the event of engine or pump failure, the remaining pump will provide satisfactory operation up to 15,000 feet.

An electronic timer is provided for automatic operation of the system; a separate circuitry being provided to bypass the timer for manual operation. The normal cycle of the timer is 1-minute for excessive icing (29 seconds on, 31 seconds off) and 4 minutes for light to moderate icing (29 seconds on, 211 seconds off). When the system is switched on, there is an initial tube warm-up delay of 20 seconds, then the cycle commences with a 5-second period during which the solenoids of the combination units are energized to close the dump valves and pressurize the system. Thereafter, six contacts are energized successively, each for a period of 4 seconds during which the appropriate distributor-valve solenoids are in turn energized to fully inflate their respective boots. The boots are inflated and deflated once per cycle, in symmetrical pairs, consecutively from the inboard inner wing-boots to the outer tail-boots (see figure 4-4). Suction is applied to hold the boots flush with the leading edge during the intervening periods of the cycle. During the balance of the cycling time (31 or 211 seconds), the dump valves are open and system pressure is unloaded.

NOTE

If the system is switches OFF during a cycle, the timer will zero for commencement of another cycle.

Wing And Tail Deicing Switches.

Under WING & TAIL, a mode switch has three positions marked AUTO, OFF, and MAN; the function being self-explanatory (figure 4-5). A related two-position switch marked FAST-SLOW selects respectively the 1-minute or 4-minute cycle, and is operative only in the AUTO mode. Three BOOTS switches, INBD, OUTBD, and TAIL, have positions marked INNER-OFF-OUTER, and are for manual operation of the boots either when a particular icing condition makes manual mode preferable or in the event of failure of the automatic function. When manual mode is selected, the system remains loaded at 15 psi and the boot switches bypass the timer to route power

wing and tail deicing system




Figure 4-4

direct to the distributor-valve solenoids; the boot remaining inflated while the switch is held selected.

Normal Operation.

1. WING & TAIL DEICING circuit breakers - Set.
2. Mode switch - AUTO.
3. System pressure and suction indicators - Check 15 psi and 4 in. Hg respectively.
4. Cycling switch - FAST or SLOW, as required.

NOTE

With the system operating automatically, the build-up and shedding of ice should be closely observed, bearing in mind the fact that the characteristics of the icing condition may require a change in the manner of system operation. The wing inspection lights are provided for observations during night operation.

Manual Operation. Should a failure in the timer, or characteristic of the icing condition require manual mode of operation, proceed as follows:

1. Mode switch - MAN.
2. System pressure and suction - Check.
3. BOOT switches - Commencing with the INBD switch, hold each switch in turn first to the INNER position and then the OUTER position for a period of 4 seconds each approximately.
4. Repeat the cycle as necessary.

NOTE

For wing and tail deicing procedures refer to cold weather operation in Section IX.

ENGINE PREHEAT SYSTEM.

An engine preheat system is provided to permit heating each engine and its accessory compartment to a reasonable temperature prior to starting the

deicing switch panel




Figure 4-5

engines in still air temperatures of 0°F (-18°C) and below. The system consists of flexible piping which can be connected to an engine preheat outlet in the tee-duct at the discharge end of the cargo compartment heater and to the snout of the engine covers. The cargo compartment emergency exit door must be open to allow the flexible pipe to be connected to the engine preheat outlet. Air flow for ground operation of the cargo compartment heater is supplied by a high-capacity fan in the combustion air bypass duct, and one in the ventilating air bypass duct. To obtain maximum flow of heated air through the engine preheat outlet, the cargo compartment air control must be pulled to its closed position. The engine preheat flexible piping can be secured to the snout on the left side of the engine covers for engine preheating, and/or to the preheat access at nacelle station 57.50, marked ACCESSORY COMPT PREHEAT CONNECT, for engine accessory compartment preheating. The preheat access adapter access adapter cover on each nacelle is secured by four quick-release fasteners; and has a spring-steel insert marked FIRE ACCESS which can be pushed in to allow fire extinguishing agent to be sprayed into the accessory compartment.

OPERATION.

1. Flexible piping - Connect between engine preheat outlet and engine cover as appropriate.

NOTE

When the flexible piping is connected to the engine preheat outlet it actuates a cargo compartment air control microswitch to permit operation of the cargo compartment heater.

2. Flight compartment canopy cover, cargo compartment heater forward air exhaust cover and left wing air intake cover - Remove.

3. Cargo compartment heater - Start as for ground operation, then pull the cargo compartment air control to the closed (out) position.

NOTE

Secure cover on engine preheat outlet when preheat system is not in use, and push the cargo compartment air control to its open (in) position.

4. Cockpit heater inlet and exhaust cover - Remove to permit ground operation of the flight compartment heater during preheating of the engine.

5. Engine preheat should be applied to one engine and its accessory compartment at the same time. Connect the preheat flexible piping to the preheat outlet, and to the engine cover snout and engine accessory compartment preheat access adapter. Maintain application of preheat until the cylinder head temperature gage indicates above 0°C, then transfer the flexible piping to the cold engine and its accessory compartment. Remove the engine cover and oil cooler air exhaust cover from the preheated engine, and start the engine using the hot fuel prime system if installed. Allow the engine to warm up at 1000 rpm and carry out boil-off procedure detailed in Section IX. Remove the flexible piping, engine cover, and oil cooler air exhaust cover from the engine being preheated when its cylinder head temperature gage indicates above 0°C, and proceed as for the operating engine. Select the hot fuel prime switch to OFF after both engines are operating.

WINTERIZATION COVERS.

Fifteen winterization covers are provided, twelve are installed externally and three internally. A

light-weight folding ladder is provided for use when installing the external covers; the ladder length is 12 feet 1.7 inches when unfolded, and 7 feet 5.8 inches when folded.

External Covers.

Engine Covers. Two engine covers, one for each engine, are stenciled ENGINE COVER SD5525-1, with TOP at the appropriate position to facilitate installation. Elastic cord assemblies with attachment rings are provided at the aft edge of each cover which are held secure to the nacelles by appropriately located ball-lok pins. Before installing an engine cover insure that the propeller blades are at the 2, 6, and 10 o'clock positions. The blade cuffs of the cover are secured to the propeller by means of elastic cord assemblies with ring and hook attachments. Insure that the heating duct snout of the cover is at approximately the 4 o'clock position.

Cargo Compartment Heater Intake and Exhaust Covers.

a. Two covers, one for each cargo compartment heater air intake in the leading edge of the wing center section, are stenciled SD5605-1 COVER, AIR INTAKE LE CS WING and can be secured in position by means of two button fasteners. Each cover has a warning streamer. Remove left cover before preheating the engines.

b. A shaped cover stenciled SD5606-1 COVER, AIR EXHAUST, CABIN HEATER can be slipped onto the cargo compartment heater combustion air exhaust and secured in position by means of four button fasteners. The cover has a warning streamer. Remove this cover before preheating engines.

c. A shaped cover stenciled SD5607-1 COVER AIR EXHAUST, CABIN HEATER can be slipped onto the cargo compartment heater ventilating air exhaust and secured in position by means of two button fasteners. The cover has a warning streamer.

Landing Gear Covers.

a. Two covers, one for each main landing gear opening, are stenciled SD5609-1 COVER, OPENING, MAIN LG and FORWARD. Each cover can be secured in position by means of eight

winterization equipment general arrangement

- | | |
|--|---|
| 1. ENGINE PREHEAT OUTLET | 9. SD5609-1 COVER, OPENING, MAIN LG |
| 2. SD5525-1 COVER, ENGINE | 10. FIRE ACCESS AND PREHEAT ACCESS CONNECTION |
| 3. SD5606-1 COVER, AIR EXHAUST, CABIN HEATER | 11. PIPING, FLEXIBLE, ENGINE ACCESS. COMPT. PREHEAT |
| 4. SD5638-1 COVER, AIR EXHAUST, OIL COOLER | 12. SD5611-1 COVER, OPENING, NOSE LG |
| 5. SD5605-1 COVER, AIR INTAKE, LE CS WING | 13. CANOPY COVER |
| 6. LADDER, FOLDING, LT WT | 14. PIPING, FLEXIBLE, ENGINE PREHEAT FROM APU EXHAUST |
| 7. SD5607-1 COVER, AIR EXHAUST, CABIN HEATER | 15. APU EXHAUST PIPE |
| 8. HOT FUEL PRIME UNIT (IN NACELLE) | |

* THESE COVERS MUST BE REMOVED PRIOR TO PREHEATING ENGINES

ENGINE PREHEAT USING CARGO COMPARTMENT HEATER AND APU

ENGINE PREHEAT USING CARGO COMPARTMENT HEATER ONLY

Figure 4-6

ball-lok pins, twenty button fasteners, and an elastic cord lacing at the rear panel.

b. A cover for the nose landing gear opening is stenciled SD5611-1 COVER, OPENING, NOSE LG and can be secured in position by means of fourteen button fasteners. Remove this cover before operating the APU, if installed.

Cockpit Heater Inlet and Exhaust Cover. A cover for the flight compartment heater air intake and exhaust outlet is stenciled SD5610-1 COVER INLET AND EXHAUST, COCKPIT HEATER and can be secured in position by means of two button fasteners at the fuselage nose and to the heater exhaust on the right side of the fuselage nose. The cover has a warning streamer. Remove this cover before operating flight compartment heater during preheating of the engines.

Oil Cooler Air Exhaust Covers. Two covers, one for each oil cooler air exhaust, are stenciled SD5638-1 COVER ASSY, OIL COOLER and can be secured in position by means of seven button fasteners. A warning streamer is attached to each cover adjacent to a stenciled instruction reading HANG WARNING STREAMER SD2892-9 OVER LEADING EDGE OF WING. Remove appropriate cover before starting the engine.

Internal Covers.

Three covers colored sky-green are provided to block off the hot day ventilation louvers when the aircraft is being operated in winter climates. The covers are secured in position by means of the twelve existing attachment bolts at each louver.

ENGINE PREHEAT SYSTEM. (USING APU EXHAUST HEAT).

On aircraft equipped with a gas turbine auxiliary power unit, an engine preheat system utilizing the APU exhaust heat is provided to permit heating both engines to a reasonable temperature prior to starting in still air temperatures of 0°F (-18°C) and below. The system (figure 4-6) comprises an exhaust pipe which can be connected to the APU exhaust outlet adapter on the left side of the fuselage nose, and a flexible duct assembly connected between the exhaust pipe tee-junction and the snout of each engine cover. Near the upper end of the exhaust pipe is a stub pipe which is engaged with the APU exhaust outlet adapter so

that the lower tee end of the exhaust pipe is below the level of the fuselage. A chain is attached to the tee end of the exhaust pipe and the free end can be hooked onto an eyebolt marked APU EXHAUST PIPE SUPPORT on the fuselage left side above the battery location marking. The adapter ends of the flexible duct assemblies attach to the left and right ends of the tee-junction, and the other end connects into the respective engine cover snout. The exhaust pipe has two manually controlled butterfly-type valves, one at each end, and both are marked HOT and COLD at the closed and open position respectively. The upper valve controls the amount of cold ambient air entering the pipe to mix with the APU hot exhaust gases. The lower valve directs the hot gases to atmosphere when the valve is at the COLD position, or to the engine covers when the valve is at the HOT position. A bimetal thermometer with a range from 150° to 750°F (65.5° to 398.9°C) protrudes into the exhaust pipe just above the tee-junction and shows the temperature of the hot gases in the pipe.

Operation.

1. Remove APU exhaust outlet cover.
2. Securely install exhaust pipe on APU exhaust outlet adapter, hook chain to exhaust pipe support eyebolt.
3. Connect flexible duct assembly between exhaust pipe tee-junction and the respective engine cover snout.
4. Insure engine cover snout is securely laced to its flexible duct assembly.
5. Set exhaust pipe upper and lower valves to COLD position.
6. Remove nose gear well cover.
7. Start APU.
8. After one minute adjust exhaust pipe upper valve to give 250°F (121.1°C) maximum temperature.
9. Set exhaust pipe lower valve to HOT position to direct hot gases to engine cover snouts.

ENGINE ACCESSORY COMPARTMENT PREHEAT SYSTEM.

The engine accessory compartment preheat system utilizes cargo compartment heater hot air feed through an engine preheat outlet and a flexible duct assembly to each engine accessory compartment. The engine preheat outlet is on the tee-duct at the discharge end of the cargo compartment heater. The engine accessory compartment preheat connection is on the left side of each engine nacelle at station 57.50, and is marked ACCESSORY COMPT PREHEAT CONNECT. The preheat connection has a cover secured by four quick-release fasteners; and has a spring-steel insert marked FIRE ACCESS which can be pushed in to allow fire extinguishing agent to be sprayed into the accessory compartment. The flexible duct assembly has three ducts joined together at a Y-junction; the duct from the column of the junction is led into the fuselage and attaches to the engine preheat outlet of the cargo compartment heater, and the ducts from the arms of the junction attach one to each engine accessory compartment preheat connection. Air flow for ground operation of the cargo compartment heater is supplied by a high-capacity fan in the combustion air bypass duct, and one in the ventilating air bypass duct. To obtain maximum flow of heated air through the engine preheat outlet, the cargo compartment air control must be pulled to its closed position.

Operation.

1. Remove engine accessory compartment preheat connection cover from each nacelle, and attach appropriate flexible duct.
2. Pass the flexible duct from the Y-junction column into the fuselage through the opened cargo compartment emergency exit.
3. Remove engine preheat outlet cover and attach the flexible duct to the adapter.
4. Remove appropriate external covers from heater inlet and exhaust ducts.
5. Pull the cargo compartment air control to its closed position.
6. Initiate cargo compartment heater ground operation.

COMMUNICATION AND ASSOCIATED ELECTRONIC EQUIPMENT.

The electronic equipment that may be installed in the aircraft is discussed in the following paragraphs. A brief description of each system, its capability, location, and operating instructions is included.

WARNING

This aircraft contains various combinations of navigational receivers, course indicators, and radio magnetic indicators. Before flight, pilots must determine the type of navigation equipment installed and operational; the operation of controls and switches used to select navigation displays; the function of each RMI, bearing pointer, and course indicator and the means of monitoring identification signals of NAVAIDS being used.

DESCRIPTION AND DATA.**Purpose And Use.**

The radio equipment that may be provided in the aircraft is listed in figure 4-7. The configurations vary according to the theater of operations and the production series.

DESCRIPTION AND OPERATION-INTERCOMMUNICATION SYSTEM (SB-329 AR AND C-1611A AIC).

The intercommunication system permits voice communication between pilot, copilot and one to three auxiliary stations in the flight or cargo compartments. Audio signals from radio receivers can be monitored at each of the stations. Transmissions through the radio transmitters, however, can be accomplished only at the pilot's and copilot's station. A three position microphone/interphone switch on both the pilot's and copilot's control wheels and pedestals permits transmissions from these positions. The switches at the base of the pedestals are foot-operated. Intercommunication control panels are identified within each aircraft, depending on configuration. The intercommunication system operates from

communication and associated electronic equipment

TYPE	DESIGNATION	USE	RANGE DISTANCE AT SPECIFIC ALTITUDE	LOCATION OF CONTROLS	REMARKS
UHF COMMAND COMMUNICATIONS	Radio set AN/ARC-55B/ ARC-27 or -51X/ 51BX	Two-way voice com- munications in the frequency range of 225.0 to 399.9 mc voice reception on preset guard fre- quency	Line of sight 50 miles at 3000 ft (ap- proximately)	Sliding Console	
VHF COMMAND COMMUNICATIONS	Radio Set AN/ARC-73, -73A/101	Two-way voice com- munications. Re- ception in the fre- quency range of 108.00 to 151.95 mc (control panel 614U-5), or 116.00 to 151.95 mc (con- trol panel 614U-6). Transmission in the frequency range or 116.00 to 149.95 mc (with either con- trol panel).	Line of sight 50 miles at 3000 ft (ap- proximately)	Sliding console	
HF RADIO COMMUNICATIONS	Radio Set AN/ARC-59	Two-way voice com- munications in the frequency range of 2.0 to 18.5 mc	Indefinite	Sliding console	
HF-SSB RADIO COMMUNICATIONS	Radio Set AN/ARC-102	Two-way voice com- munications in the frequency range of 2.0 to 30.0 mc	Indefinite	Sliding console	
FM LIAISON COMMUNICATIONS	Radio Set AN/ARC-44	Two-way voice com- munications in the frequency range of 24.0 to 51.9 mc, and intercrew com- munications.	Line of sight up to 50 miles	Sliding console	AN/ARC-44 dynamotor (DY-107()/AR) supplies power for operation of signal dis- tribution pan- els (SB-329/ AR)
	Radio Set FM 622A	Two-way voice com- munication in the frequency range of 30 to 75.95 mega- cycles.	80 miles at 2000 feet or 100 miles at 4000 feet or above	Sliding console	Either FM 622A or AN/ARC-44 may be used (but not simul- taneously)

Figure 4-7 (Sheet 1 of 3)

communication and associated electronic equipment (cont)

TYPE	DESIGNATION	USE	RANGE DISTANCE AT SPECIFIC ALTITUDE	LOCATION OF CONTROLS	REMARKS
INTER-COMMUNICATIONS	Intercommuni- cation Set C-1611A/AIV and SB329 AR	Intercrew com- munications	Within air- craft	Sliding console	Permits selective control of the facilities
VOR/ILS LOCALIZER RECEIVER	Radio Receiv- ing Set AN/ARN-30D, or -30E	VOR and ILS localizer naviga- tional aid and Vhf voice reception in the frequency range of 108.0 to 126.9 mc	Line of sight 50 miles at 3000 ft (ap- proximately)	Sliding console	
LF NAVIGATION RECEIVER (ADF)	Direction Find- er Set AN/ARN- 59	Radio range and broadcast recep- tion: automatic direction finding in the frequency range of 0.19 to 1.75 mc	200 miles at 3000 ft, de- pending on conditions	Sliding console	
ILS GLIDE SLOPE RECEIVER	Radio Receiv- ing Set AN/ARA-54/ ARN-18	Visual indication of ILS glide slope in the frequency range of 329.3 to 335.0 mc	15 miles ap- proximately	Sliding console	
MARKER BEACON RECEIVER	Radio Receiv- ing Set AN/ARN- 32, or R-1041/ ARN	Aural and visual indication of marker beacon location	Vertical	Sliding console	75 mc pre- tuned not adjustable
MARKER BEACON AND GLIDE SLOPE RECEIVER	Radio Re- ceiving Set AN/ARN-58	Aural and visual in- dication of marker beacon location. Visual indication of glide slope in the frequency range of 329.3 to 335.0 mc	Marker beacon ver- tical; glide slope 15 miles approx- imately	Sliding console	
IFF IDENTIFICATION	Transponder Set AN/APX-44	Identification; friend or foe, supplement- ed by selective iden- tification feature	Line of sight 50 miles at 3000 ft (ap- proximately)	Sliding console	
WEATHER RADAR	AN/APN-158	Primarily weather observation and penetration system	Line of sight	Mounted in the engine instru- ment panel	Additional capability i.e., as ground mapping nav. radar and anti-collision system

Figure 4-7 (Sheet 2 of 3)

communication and associated electronic equipment (cont)

TYPE	DESIGNATION	USE	RANGE DISTANCE AT SPECIFIC ALTITUDE	LOCATION OF CONTROLS	REMARKS
TACAN	AN/ARN-21	Provides bearing and distance information	Up to 200 miles line of sight, depending on altitude	Sliding console	
TALAR	AN/ARN-97	Provides glide slope and localizer information	Up to 10 nmi in 10 nm of rainfall per hour; up to 28 nmi in clear weather	Sliding console	Installed on airplanes modified by T.O. 1C-7A-588
RADAR ALTIMETER	AN/APN-22	Indicates terrain clearance of the airplane	Reliable to 5000 feet absolute altitude	Pilot's Instrument Panel	Removed from airplanes modified by T.O. 1C-7A-608.
AIMS/IFF TRANSPONDER SYSTEM	AN/APX-72	Provide automatic radar identification and altitude information to suitably equipped challenging facilities	Line-of-sight, 50 miles at 3000 ft (approximately)	Sliding console	

Figure 4-7 (Sheet 3 of 3)

27.5 volt, dc power supplied by the emergency bus through the FM POWER and KEYING CKTS or INTERPHONE and CONTROL CKTS circuit breakers on the electronics circuit breakers panel located on the forward face of the flight compartment rear bulkhead.

Intercommunication System Control Panel.

Control panels are installed on each side of the sliding console (8 and 9, figure 4-9), in the cargo compartment aft of the flight compartment door, on the roof at the midway point of the cargo compartment, in the flight compartment adjacent to the hydraulic reservoir, and on the roof at the rear of the cargo compartment. The latter two auxiliary stations are only installed in some aircraft. Each station control panel is equipped with monitoring and/or mixer switches, a transmission selector switch and volume control.

Monitoring Switches. The monitoring switches enable all communication and audio navigational systems to be connected to the intercommunication system. The switches are

On-Off pin type (up for ON and down for OFF). Each of the control panels is equipped with switches which provide interconnection with the following communication and audio navigational systems:

Switch 1 - FM liaison radio.

Switch 2 - UHF or HF radio, as selected on UHF-HF select panel on the sliding console (13, figure 4-9).

Switch MB - Marker beacon receiver.

Switch NAV - VOR, ADF and TACAN.

With the TRANS switch set to INT, transmission to other stations in the aircraft is possible without use of the I/C or INTERCOM switch (hot mic).

Transmission Selector Switch C-1611A/AIC. The rotary transmission selector switch (TRANS) on the INT panel may be set to transmit within or outside the aircraft. On early model aircraft the

selector switch has 4 positions, and on later models, INT and PVT positions were added.

Position 1 - FM liaison Radio

Position 2 - UHF

Position 3 - VHF command radio or standby VHF transmitter as selected on standby VHF control panel.

Position 4 - HF liaison Radio.

Position INT - Interphone.

Position PVT - Interphone for flight engineer, cargo compartment and cargo ramp stations only (some aircraft).

The following information is applicable to both systems.

NOTE

- Simultaneous transmission on UHF and FM should be kept to an absolute minimum.
- The receiver associated with the selected transmitter is also connected to the headset by the TRANS switch, regardless of the setting of the monitor or mixer switch.
- Although the auxiliary INT panels in the cargo compartment are equipped with identical TRANS switches, only the INT and PVT positions are operable. The auxiliary INT panel in the flight compartment can be used for external transmissions.

Volume Control. The volume control (VOL) varies the audio level of mixed interphone and receivers, except the ADF receiver(s).

Normal Operation.

Pilot and Copilot Stations. To operate the intercommunication system, check the FM POWER and KEYING CKTS (or INTERPHONE and CONTROL CKTS) circuit breakers ON. There are two modes of transmission, press-to-talk and hot mike (mic). In the press-to-talk mode, the pilot

or copilot press the microphone switch on the control wheel to I/C, or the foot-operated switch to INTERCOM to transmit to other stations within the aircraft. When using the I/C or INTERCOM switch, the setting on the TRANS switch is not a factor. To receive other stations within the aircraft the monitor INT switch must be selected ON or the TRANS switch selected to INT. For reception of radio communications and audio navigational systems select the appropriate monitor switch to the ON position for that system. Adjust VOL control on INT panel for suitable audio level.

Auxiliary Stations. To transmit on the intercommunication system, set TRANS switch to INT position then press the microphone button switch. In some aircraft, with the TRANS switch set to PVT and the monitor INT switch ON, the auxiliary stations can transmit and receive each other while monitoring pilot and copilot transmissions. The PVT position permits interphone transmission that does not interfere with pilot and copilot. For reception of radio communications and audio navigational systems select appropriate monitor switch to the ON position. Adjust VOL control on INT panel for suitable audio level.

Standby Audio Operation. Standby audio operation is provided on aircraft with an FM power switch. In the event that the FM dynamotor or INT panel fails, the FM power switch and all facilities not required should be turned off. The receiver and microphone audio circuits bypass the INT panels and the desired transmitter must be selected by the TRANS (transmit-interphone) switch on the INT panel for Uhf, hf, vhf transmission. Communication through the FM liaison radio set is not possible. During emergency standby-audio operation, only the facility required should be turned on and the volume level adjusted by means of its control panel volume control. Interphone is available between the pilot and copilot only, in the standby-audio mode.

UHF COMMAND RADIO (AN/ARC-55B/ARC-27 OR AN/ARC-51X/51BX).

The UHF command radio provides voice transmission and reception in the frequency range of 225.0 to 399.9 megacycles, with 1750 frequencies available in steps of 0.1 megacycles. Receiver and transmitter tuning is accomplished automatically after a frequency change. A main

receiver and a guard receiver are used in the system. The main receiver tunes to any selected frequency; the guard receiver remains tuned to a guard frequency. The UHF command radio system is supplied 27.5 volt dc power from the main dc bus through the UHF POWER circuit breaker on the electronic circuit breaker panel. The control panel located on the sliding console (10, figure 4-9) contains a dual audio volume and sensitivity control, manual frequency selector controls and a master function switch. Primary control of the set is accomplished by use of the function switch. When turned to T/R position, the switch energizes the set to provide normal frequency selection and operation. The T/R + G position energizes the separate guard receiver and provides monitoring of the guard frequency as well as normal transmission and reception. The ADF position is not connected: To put the radio into operation proceed as follows.

1. On INT panel, set monitor 2 switch to ON and set VOL control.

2. Set UHF-HF select switch on sliding console (13, figure 4-9) to UHF position.

3. On UHF control panel, set function switch to T/R + G position. Allow one minute for warmup.

4. Adjust UHF and INT VOL controls to obtain suitable audio level.

5. Adjust SENS control fully counter-clockwise then clockwise until background hissing noise is eliminated. Do not turn SENS control any further than amount required for elimination of hissing sound, otherwise weak incoming signal will not be heard.

6. To transmit, place TRANS switch to position 2.

7. Should transmission be necessary on the guard frequency, set manual frequency selector controls to the guard frequency.

VHF COMMAND RADIO (AN/ARC-73 OR 73A/101).

The VHF communication system consists of a VHF transmitter, a VHF receiver and a control unit. The VHF system provides communication facilities in the frequency range of 116.00 to 149.95 megacycles, with reception possible to

151.95 megacycles. There are 680 crystal controlled channels available for transmission and 720 or 880 (108.00 to 151.95 mc) channels available for reception depending on control panel used. All frequencies may be selected at intervals of 50 kilocycles from the control panel located on the sliding console. The VHF command radio receives 27.5 volt dc power from the emergency bus through the VHF XMTR and VHF RCVR circuit breakers located on the electronic circuit breaker panel. The control panel (15, figure 4-9) contains a frequency indicator, a power on-off switch, two frequency selector knobs, and a dual control for squelch and volume. The two frequency selector knobs are used to select an operating frequency. The selected frequency appears as a number (in megacycles) in the frequency indicator window. The power ON-OFF switch controls the power to the system. The VOL and SQ controls adjust the receiver volume level and squelch on the receiver. The SCS-DCS/DCD switch is not used in this installation. To put the radio into operation, proceed as follows:

1. On INT panel, set monitor 3 switch ON, and set VOL control.

2. On VHF control panel (15, figure 4-9) set power switch to ON. Allow 1 minute for warm-up.

3. Select a frequency, using the two frequency selectors.

4. Adjust SQ control counter-clockwise until background hissing noise is eliminated. Do not turn SQ control any further than amount required for elimination of hissing sound, otherwise weak incoming signals will not be heard.

5. Adjust VOL control for suitable volume. If necessary, adjust INT panel VOL control to obtain suitable audio level.

6. To transmit, place TRANS switch on INT panel to position 3.

FM LIAISON RADIO (AN/ARC-44).

The FM liaison radio provides short range two-way voice communications in the frequency range of 24.0 to 51.9 megacycles. The FM system consists of a receiver-transmitter, dynamotor and control

panel. The dynamotor unit supplies high voltage dc and 400 cycle-per-second ac power for operation of the receiver-transmitter and INT panels. The control panel located on the sliding console (11, figure 4-9) contains a power switch marked ON-OFF; a volume control marked VOL; two frequency selector controls (knurled knob and wing type) marked FREQ with indicator window; and a selector switch marked REM-LOCAL. The REM-LOCAL switch is used only on installations having two or more FM control panels. On this aircraft the switch should be left in the LOCAL position. The FM system is supplied 27.5 volt dc power from the emergency bus through the FM POWER and KEYING CKTS (or INTERPHONE and CONTROL CKTS) circuit breakers located on the electronic circuit breaker panel. To put the radio into operation, proceed as follows.

1. On INT panel set monitor 1 switch ON and set VOL control.
2. Set power switch to ON position. Allow two minutes for warm-up. A 400 cycle signal may be heard in headset, lasting approximately six seconds.
3. Turn VOL control for suitable volume, then adjust INT panel VOL control as desired.
4. On FM squelch control panel (7, figure 4-9) (on some aircraft) select squelch switch to ON and listen for characteristic noise. Operate squelch switch and squelch receiver.
5. To transmit place TRANS switch on INT panel to position 1.

FM LIAISON RADIO (622A).

The FM 622A radio is frequency modulated providing 920 channels over a frequency range of 30 to 75.95 MC. The equipment requires 28 vdc power for operation and is protected by a 10-amp circuit breaker on the electronic circuit breaker panel.

Controls:

The control panel is located on the sliding console and consist of the following switches: frequency select, squelch, volume and mode select.

Operation:

1. On operator's interphone panel, set RECEIVER 1 to ON position and TRANS switch to POSITION 1.

NOTE

When pilot's or copilot's TRANS switch is set to POSITION 1, FM receiver is connected to headset regardless of receiver 1 switch position.

2. Set mode selector to the T/R position.

NOTE

Allow two minutes for set to warmup.

3. Select desired frequency.
4. Adjust squelch.
5. Adjust volume to desired audio level.
6. Depress MIC switch (control wheel or foot mike switch) for transmission.
7. Set mode selector to OFF position.
8. Set TRANS switch, on interphone panel to INT position.

NOTE

When KY-28 seek silence unit is not installed, be sure the selector switch on front of KY-28 control is in the PLAIN position.

RADAR ALTIMETER (AN/APN-22).

NOTE

Aircraft modified in accordance with T.O. 1C-7A-608, the AN/APN-22 Radar Altimeter system has been removed.

An AN/APN-22 radar altimeter (figure 1-15) is installed to indicate absolute altitude (AGL). Altitude is indicated in feet on an indicator located on the pilot's instrument panel. The radar altimeter is powered by 27.5 v dc and 115 v ac. The 115 v ac is obtained from the TACAN/RADAR ALTIMETER inverter. The equipment is protected by circuit breakers on a power distribution panel located on the bulkhead next to the heating control panel.

course indicator (vor / ils only)




Figure 4-8

WARNING

The terrain clearance indications received from the radar altimeter are unreliable when operating over large depths of snow and ice, since the radar waves will actually penetrate the surface and indicate greater terrain clearances than actually exist.

Radar Altimeter Control.

The only control for the radar altimeter is the on-limit knob. Rotating the on-limit knob moves the preset altitude pointer above zero, turns the radar altimeter on and sets the clearance altitude. A red light on the indicator plus a repeater light on the pilot's instrument panel will glow whenever the aircraft is below the preset altitude. To put the radar altimeter into operation:

1. Turn on the TACAN/RADAR ALTIMETER inverter.
2. Turn the ON-LIMIT control clockwise and set the desired altitude reference. The equipment will start operating approximately three minutes after the control is turned on.

NOTE

Allow at least 12 minutes warm-up time after starting the equipment to insure

final accuracy. If the temperature is below -40°C , 25 minutes should be allowed.

3. Read directly from the single pointer on the indicator face. When the equipment is operating with the aircraft resting on the ground, the height indicator pointer will move to some point slightly above zero and will fluctuate 2 to 3 feet while taxiing.

COURSE INDICATORS.

Two course indicators of a type not usually found in USAF aircraft are installed (figure 4-8), for use with the VOR or ILS navigational receivers. The course deviation indicator (CDI) is pivoted at the top to swing left or right and course deviation is read on the course deviation scale (horizontal dots). Each dot represents approximately 2° of VOR course displacement of $1/2^{\circ}$ of ILS localizer displacement. The glide slope indicator (GSI) displays ILS glide slope position relative to the aircraft. It is pivoted at the left to swing up or down and glide slope deviation is read on the glide slope deviation scale (vertical dots). A full scale GSI shows that the aircraft is at least $1/2^{\circ}$ from the ILS glide slope. The course and glide slope warning flags indicate that the instrument is not receiving signals suitable for navigation. The TO-FROM indicator indicates whether the course selected, if intercepted and flown, will lead to and from the station. The compass card is fixed and the course set knob is used to set the course pointer to the desired course. Power for the course indicator is from the VOR receiver through a 5-ampere circuit breaker labeled VOR No. 2. The glide slope indicator power is from the glide slope receiver through the 5-ampere marker beacon circuit breaker and the one ampere glide slope fuse.

An additional USAF type course indicator is installed on the pilot's flight instrument panel to display only TACAN course information. This instrument and its use is fully explained in AFM 51-37.

WARNING

The glide slope indicator (GSI) of the TACAN course indicator is inoperative at all times and is not connected to the ILS glide slope receiver.

NOTE

During TALAR operation on airplanes modified by T.O. 1C-7A-588, the GLIDE SLOPE indicator of the TACAN course indicator is connected to the TALAR electronic control amplifier to display glide slope information.

RADIO MAGNETIC INDICATORS (RMI).

Two radio magnetic indicators (figure 1-15) are installed to indicate VOR/ADF magnetic bearings. One is provided for the pilot and one for the copilot. Each indicator consists of a rotating compass card and two bearing pointers. The compass cards are connected to the J-2 compass system. A two-position gyro compass mode switch located on the pilot's instrument panel is marked SLAVE and D.G. In the SLAVE position, the compass system is slaved to magnetic north and the compass card indicates aircraft magnetic heading under the top index. In D.G. position, the compass system functions as a directional gyro indicator and the compass card is set by use of the synchronization knob. In D.G. the card will require periodic resetting to compensate for gyro precession. A two-position switch labeled ADF and VOR is provided on some RMI's and functions only in aircraft having VOR converters. The switch is used to select VOR or ADF bearing information on the Number 1 bearing pointer from either the pilot's VOR or the ADF receiver. In aircraft where the copilot does not have an ADF/VOR switch, his RMI display is a repeat of the pilot's.

NOTE

In aircraft without VOR converters, VOR bearings are not displayed on the RMI. VOR bearings in these aircraft are determined by the use of the VOR/ILS course indicator.

Power for the RMI is supplied from the 26-volt and 115-volt, 400 cycle ac bus. The circuits are protected by three 2 ampere fuses, marked GYRO COMPASS ϕ A, ϕ C and 26v.

Two additional RMI's are installed to display TACAN bearings in aircraft modified with TACAN. One indicator is provided for each pilot.

NOTE

The VOR/ADF switch is disconnected and has no function in TACAN modified aircraft.

TACAN (AN/ARN-21).

An AN/ARN-21 TACAN navigation system is installed to provide bearing and distance to a selected TACAN station. The system is controlled by means of a TACAN control panel on the sliding console (3, figure 4-9). Bearing information is presented on a radio magnetic indicator on each pilot's flight instrument panel. Course deviation, and to-from information is available only to the pilot on the TACAN course indicator, ID 249. TACAN distance information is presented on a range indicator, ID310, on the pilot's instrument panel. TACAN identification signals can be adjusted by the volume control on the TACAN control panel. The TACAN system is powered by 27-5 v dc and 115 v ac power. The ac power is supplied by the TACAN/RADAR ALTIMETER inverter. The equipment is protected by circuit breakers on a power distribution panel located on the bulkhead next to the heating control panel. A three position (OFF, REC, T/R) power switch selects the mode of operation. With the switch in REC position, only bearing information and station identification is received; with the switch in T/R position, bearing, range and identification are received. The channel selector tunes the equipment to any of 126 channels. The TACAN is operated by setting power switch to T/R. Approximately 90 seconds are required for the equipment to automatically complete a warm-up cycle.

WARNING

Because of malfunctioning ground or airborne TACAN equipment, it is possible for the TACAN to lock-on to a false bearing. The error will be ± 40 degrees or any multiple of 40 degrees. When using TACAN for instrument departures, navigation, or approaches, verify bearing information with other NAV equipment or radar when possible.

NOTE

The glide slope indicator (GSI) of the TACAN course indicator is inoperative at all times and is not connected to the ILS glide slope receiver.

TACAN RANGE INDICATOR.

On TACAN modified aircraft, a range indicator is provided on the pilot's flight instrument panel. The range indicator displays line of sight, slant range to a TACAN station. A range warning flag appears when indications are unreliable.

TALAR (AN/ARN-97) (ON AIRPLANES MODIFIED BY T.O. 1C-7A-588).

An AN/ARN-97 TALAR landing approach aid, installed on airplanes modified by T.O. 1C-7A-588, provides an accurate means of guiding aircraft on an instrument approach under all weather conditions. The system receives relatively low level microwave signals from a ground-based transmitter, amplifies and detects them, and converts the result for display as glide slope and localizer information on the pilot's ID-351 course indicator (TACAN, figure 1-15). The range of the set varies from 10 nautical miles in wet weather with 10 mm of rainfall per hour to 28 nautical miles in clear weather. The system is supplied with 27.5 vdc through the TALAR circuit breaker on the ELECTRONICS circuit breaker panel (figure 1-10). The single operating control, the INST(rument) SELECT switch, is located on the sliding console (17, figure 4-9). Placing the switch in the TALAR position makes the TALAR system operative if the TALAR circuit breaker is on. To disable the system, the circuit breaker is turned off or the INST SELECT switch is set to TACAN. Either method removes the 27.5-volt power.

NOTE

On airplanes modified by T.O. 1C-7A-588, the TALAR and Tacan systems share the TACAN indicator (figure 1-15). When the INST SELECT switch is in the TACAN position and the Tacan system is operative, course deviation is displayed on the vertical (LOC. OR RANGE) pointer. The Tacan system does not use the horizontal (GLIDE SLOPE) indicator.

VOR/ILS LOCALIZER RECEIVER (AN/ARN-30D OR 30E).

The VOR/ILS receiver provides bearing information to selected VOR stations or localizer information to ILS localizer transmitters, depending on the frequency selected. The receiver is operated by means of a VOR/ILS control panel located on the sliding console (4, figure 4-9). VOR bearing information is displayed on each pilot's radio magnetic indicator in aircraft equipped with VOR converters. On aircraft without VOR converters, bearing information is determined by use of the VOR/ILS course indicator. ILS localizer information is displayed on the VOR/ILS course indicator. Power for the receiver is 27.5 volts dc supplied through the VOR No. 1 or VOR No. 2 circuit breakers from the main or emergency bus. If two receivers are installed, one is on each bus. To operate the receiver proceed as follows:

1. On INT panel, set monitor NAV switch to ON (up); adjust volume control.
2. Turn VOR/ILS panel power switch ON and allow for a 1 minute warm-up.
3. Check course warning flag out of view on the VOR/ILS course indicator.

COURSE INTERCEPTION PROCEDURES WITHOUT VOR CONVERTERS (COURSE INDICATOR ONLY).

To intercept a course you must first determine the radial of the station selected that the aircraft is on. To do this rotate the course set knob until the course deviation indicator (CDI) centers with a TO indication on the TO-FROM indicator. The course pointer will then indicate the magnetic bearing to the station and the reciprocal course pointer, which is 180 degrees from the course pointer, indicates the radial (figure 4-8).

Inbound.

1. Maintain present heading.
2. Center the CDI with a TO indication on the TO-FROM Indicator and leave centered. (The course pointer indicates the bearing to the station.)
3. Locate the desired inbound course on the course indicator compass card.

4. Proceed from the desired inbound course along the card in the nearest direction to the course pointer, then continue in the same direction beyond the course pointer (normally 30 degrees) and read the intercept heading.

5. Turn the aircraft in the nearest direction to and maintain the intercept heading.

6. Reset the course pointer to the desired inbound course.

7. When within 10 degrees of the selected course the CDI will start to move toward center. Interpret its rate of movement to determine the lead point to start the turn to roll out on course.

Outbound.

1. Maintain present heading.

2. Center the CDI with a FROM indication on the TO-FROM indicator and leave centered. (The course pointer will then indicate the radial the aircraft is presently on.)

3. Proceed from the course pointer along the card in the nearest direction to the desired outbound course, then continue in the same direction beyond the desired outbound course (normally 45 degrees) and read the intercept heading.

4. Turn the aircraft in the nearest direction to and maintain the intercept heading.

5. Reset the course pointer to the desired outbound course.

6. When within 10 degrees of the selected course the CDI will start to move toward center. Interpret its rate of movement to determine the lead point to start the turn to roll out on course.

GLIDE SLOPE RECEIVER (R-746/ARN-18) (SOME AIRCRAFT).

This glide slope receiver has a control panel (not shown) with a dual control power switch and frequency selector. The frequency selected is displayed in the selector window. The receiver is supplied 27.5 volts dc power through the GLIDE SLOPE circuit breaker on the electronic circuit

breaker panel from the main bus. To operate the receiver, proceed as follows.

1. On GLIDE SLOPE control panel, turn power switch ON (clockwise) and set frequency selector to correspond with the localizer frequency set on VOR/ILS control panel.

2. On the VOR/ILS course indicator, check the GLIDE SLOPE alarm flag out of view.

GLIDE SLOPE RECEIVER (AN/ARA-54) (SOME AIRCRAFT).

This glide slope receiver has a MKR G/S control panel (not shown) with a power ON-OFF switch marked G/S. The receiver is supplied 27.5 volts dc through the GLIDE SLOPE circuit breaker on the electronic circuit breaker panel from the main bus. To operate the set proceed as follows:

1. On MKR G/S control panel, set G/S power switch to ON position.

2. On VOR/ILS control panel, set frequency selector to localizer frequency. This automatically sets glide slope receiver frequency.

3. On VOR/ILS course indicators check the GLIDE SLOPE alarm flag out of view.

GLIDE SLOPE AND MARKER BEACON RECEIVER (AN/ARN-58) (SOME AIRCRAFT).

This glide slope and marker beacon receiver has a MKR G/S control panel (6, figure 4-9) that contains an HI-LO SENS switch and a dual purpose power and volume control for the marker beacon. It also contains an ON-OFF G/S power switch for the G/S receiver. The receiver is supplied with 27.5 volts dc through the G/S & MKR circuit breaker panel from the main bus. To operate the equipment proceed as follows:

1. On MKR G/S control panel, turn G/S switch to ON.

2. On VOR/ILS control panel, set frequency selector to localizer frequency.

3. On GLIDE SLOPE receiver panel (5, figure 4-9) set localizer frequency.

4. On the VOR/ILS course indicators, check the warning flags out of view.

5. To receive the marker beacon, set monitor NAV switch ON.

6. On MKR G/S control panel set SENS switch to HI, turn VOL control clockwise to raise audio level.

7. Press to test MKR indicator light on pilot's flight instrument panel. When aircraft is over marker beacon, MKR indicator light will illuminate and identification signal will be heard in headset.

MARKER BEACON RECEIVER AN/ARN-32 OR R-1041 (ARN) (SOME AIRCRAFT).

These marker beacon receivers have a marker beacon control panel (not shown) that contains a HK-LO SENS switch and a dual purpose power and volume control. The receiver is supplied 27.5 volts dc through the MKR BEACON circuit breaker from the main bus. To operate the receiver proceed as follows:

1. On INT panel, set monitor MB switch to ON, turn VOL control clockwise.

2. On MARKER BEACON control panel, turn VOL-OFF control fully clockwise.

3. Place SENS switch to HI.

4. Press-to-test MKR beacon light on pilot's flight instrument panel. When aircraft is flown over marker beacon, the light will come on and audio identification will be heard in headset.

ADF RECEIVER (AN ARN-59).

The ADF receiver provides ADF bearing information to stations in the 0.19 to 1.75 megacycle (or 190 to 1750 kilocycle) range. Operation of the receiver is provided by the ADF REC control panel on the sliding console (14, figure 4-9). Bearing information is displayed on the pilot and copilot radio magnetic indicator. The power supply for the receiver is 27.5 volts dc supplied through ADF No. 1 and ADF No. 2 (if installed) circuit breaker(s) on the electronic circuit breaker panel from the main bus, and 115 v ac through the 1-ampere fuse labeled ADF or ADF

2 (if installed). To operate the receiver proceed as follows:

1. On INT panel, set monitor NAV switch to ON.

2. On ADF REC control panel, turn VOL-OFF control clockwise to apply power to receiver. Allow 30 seconds for warm-up, then adjust volume.

3. Place the function switch in ANT position.

4. Select the desired frequency.

5. Set function switch to COMP position.

6. To use the receiver for aural - null:

a. Move the function switch to the LOOP position; set BFO switch to ON.

b. Rotate the loop with the LOOP L-R control switch.

HF LIAISON RADIO (AN/ARC-59).

The HF liaison radio set provides transmitting and receiving facilities for high frequency communication in the 2.0 to 18.5 megacycle range. Two-way voice communication is possible on any one of 20 channels. Complete tuning is automatically accomplished whenever the desired channel is selected. The control panel located on the sliding console (not shown) provides all the controls necessary for operation and frequency selection of the transceiver. These include a function selector, BFO control, volume control, frequency selector and power switch. The set is supplied 27.5 volts dc power through the HF POWER, HF XMTR and HF RCVR circuit breakers on the electronic circuit breaker panel from the main bus. To operate the equipment proceed as follows:

1. On INT panel, set monitor 2 (or 4) switch to ON, and set VOL control.

2. On UHF-HF select panel (when installed), switch to HF position.

3. On HF control panel, set power switch to ON position. Allow 10 minutes for warm-up.

4. Set function switch to phone PH position (CW position not connected).

NOTE

Allow approximately 10 seconds for channel change mechanism to operate.

5. To transmit, place TRANS switch on INT panel to position 2 (or 4).

HF-SSB LIAISON RADIO (AN/ARC-102).

The HF-SSB liaison radio installation provides two-way voice and code communications in the 2 to 30 megacycle frequency range, and is capable of providing communication on any one of 28,000 channels. The control panel on the sliding console (12, figure 4-9) contains all the controls necessary for selection of any of the 28,000 available channels. A six-position (OFF-USB-AM-DATA-CW) rotary switch is used to turn the set on and off and to select sideband (Upper or Lower) operation or AM Operation. The data and CW positions are not connected. This switch controls the selection of two filters, one of which will pass only the upper sideband signal and the other only the lower sideband signal. When the set is operated in the AM mode, the upper sideband filter is also selected automatically. The operating frequency, selected by use of four knobs on the control panel, is shown in an indicator in the upper center of the control panel. A RF SENS control switch, located on the right side of the panel, controls the radio frequency gain of the transceiver. The set receives 27.5 volts dc power through the HF POWER circuit breaker on the electronic circuit breaker panel from the main bus and 115 volts ac, 400 cps single phase power from the aircraft inverter system. To operate the transceiver proceed as follows:

1. On INT panel, set monitor 2 (or 4) switch to ON.
2. On UHF-HF select panel, switch to HF position.
3. On HF-SSB control panel, set function switch to desired mode of operation.
4. Adjust RF SENS control fully counterclockwise, then clockwise until background noise is barely audible.

5. To transmit, place TRANS switch on INT panel to position 2 (or 4) and depress MIC switch to tune transmitter.

CAUTION

Do not transmit when flying aircraft near stall speeds, as this will prevent stick shakers and short-field approach speed indicator from functioning accurately.

NOTE

Antenna loading, characterized by a high pitched tone, starts immediately after the MIC button is depressed. Maximum antenna loading time is 55 seconds, 25 seconds being the average. If the maximum loading time is exceeding, it may be stopped by turning the set OFF, then ON.

IFF (AN/APX-44).

The IFF set provides automatic radar identification of the aircraft in which it is installed, when challenged by surface or airborne radar sets using coded pulse transmissions. Three modes of interrogation are used in the IFF system and the set will reply to any or all of these depending on how the mode switches are set. The IFF set can also be used to send a distress signal or a prearranged intelligence message. The set incorporates a coder group control (SIF) which provides the capability for additional codes. The equipment receives 27.5 volts dc through the main bus to the IFF APX-44 circuit breaker. The IFF set is operated from the XPDR control panel on the sliding console (1, figure 4-9). On the control panel are located six switches: the master selector switch, an audio switch, an I/P-OFF-MIC switch, a function NORMAL - MOD - CIVIL switch, and MODES 2 and 3 switches. The function of these controls are as follows:

Master Selector Switch.

The master selector switch is a five position rotary switch: OFF, STBY, LOW, NORM and EMER. In STBY, all primary power is turned on and the pilot light should come on. If the light does not come on, it is either burned out or power is not reaching

the transponder. Allow three to five minutes for warm-up. In LOW, the receiver is partially sensitive and responds only to strong interrogations. In NORM, the receiver provides maximum performance. The receiver operates at full sensitivity in the EMER position. A push button dial stop must be depressed before the selector can be rotated to EMER.

Audio Switch.

The audio switch is inoperative in this installation.

I/P-OFF-MIC Switch.

This is a three position switch spring loaded to OFF from the I/P position. When held in the I/P position, the set transmits double identification pulses and will continue this type of transmission for 30 seconds after the switch is released. When set to the MIC position, the double identification replay is transmitted when the microphone switch, selected to a command radio, is depressed.

CAUTION

Operation in the MIC position is not generally reliable, for under certain conditions no identification signal is generated or signals are inadvertently transmitted.

NORMAL-MOD-CIVIL Function Switch.

In the NORMAL position, the SIF feature is inoperative. In the MOD position, the SIF code is connected to the IFF. The CIVIL position is not used.

AIMS/IFF TRANSPONDER SYSTEM (AN/APX-72) (Aircraft Modified by TCTO 599).

The AIMS/IFF (identification friend or foe) transponder system provides automatic radar identification and altitude information of the aircraft to all suitably equipped challenging ground facilities, aircraft, and surface ships within line-of-sight. Mode 1, 2, 3/A, C, or 4 interrogation signals on a frequency of 1030 ± 1.5 megacycles are received by the system and decoded. The received signals are checked for valid code and proper mode, and if the proper interrogating signal has been received, a coded reply is transmitted on

1090 ± 3.0 megacycles. In addition to these normal identification and altitude reply signals, specially coded identification of position (I/P) and emergency signals may be transmitted in response to interrogating signals. The I/P reply signal is used to distinguish between aircraft displaying identical coding, and the emergency reply signals indicate an emergency or distress condition of the aircraft in flight. Normal identification operation, as well as transmission of the I/P and emergency reply signals, is accomplished in operating modes 1, 2, and 3/A. Mode 1 provides 32 code combinations, any one of which may be selected in flight. Mode 2 provides 4096 code combinations, only one of which is normally used in flight, since the code selection dials on the receiver-transmitter are preset before flight. Mode 3/A provides 4096 possible code combinations, any one of which may be selected in flight. Altitude interrogations and replies are accomplished in mode C operation. The code for mode C is determined by the altitude of the aircraft and is encoded in 100-foot increments. Mode 4 operation provides a secure (encrypted) IFF capability through the use of a transponder computer with the AN/APX-72 transponder. The code for mode 4 must be preset into the computer prior to flight.

The AIMS/IFF transponder system includes a test set that provides for go/no-go self-testing of the system in modes 1, 2, 3/A, and C. System self-testing for mode 4 operation is performed automatically by the transponder computer. The major components of the AIMS/IFF system are Transponder Control C-6280(P)/APX, Radio Receiver-Transmitter RT-859/APX-72, Antennas AT-741/A, Antenna Switching Unit SA-1474/A, Altimeter-Encoder AAU-21/A, Altimeter AAU-27/A, Transponder Set Test Set TS-1843/APX, an IFF antenna switch, and Mount MT-3949()A/U with connector for Transponder Computer KIT-1A/TSEC.

Primary power to operate the AIMS/IFF equipment is supplied from the aircraft main ac and main dc buses and is controlled by three circuit breakers on the ELECTRONICS circuit breaker panel. Ac power (115 volts, 400 cycles, 1 phase) is applied through IFF AC 5-ampere circuit breaker (figure 4-8A) to the altimeter-encoder and the receiver-transmitter. The receiver-transmitter provided switches 115-volt ac power to the antenna switching unit and the transponder computer. The IFF DC 5-ampere circuit breaker (figure 4-8B)

aims/iff ac power distribution




Figure 4-8A

aims/iff dc power distribution




Figure 4-8B

provides 27.5-volt dc power to the altimeter-encoder and altimeter vibrators, the receiver-transmitter, the transponder control, and the IFF CAUTION light. The TEST SET 5-ampere circuit breaker provides 27.5 volts dc to the test set.

Transponder Control C-6280(P)/APX.

The transponder control (figure 4-8C) contains all of the controls normally required to operate the AIMS/IFF transponder system except for mode 2 code selections. The MASTER control turns the AIMS/IFF system on and off, places it in warmup (STBY), controls the sensitivity of the receiver (low or normal), and initiates the emergency reply operation. The IDENT-OUT-MIC switch selects I/P operation. The I/P operation is selected when the switch is held in the momentary IDENT position. With the switch set to the MIC position, I/P operation is initiated by keying the UHF command

transceiver. The operating modes are selected by the M-1, M-2, M-3/A, and M-C mode enabling switches. These are three-position toggle switches providing ON and OUT (off) positions plus a momentary position for test signal selection. The TEST light illuminates when the receiver-transmitter responds properly to a mode 1, 2, 3/A, or C self-test. MODE 1 and MODE 3/A thumbwheel switches select and digitally display the reply code numbers. The RAD TEST-OUT-MON switch in the RAD TEST position permits the receiver-transmitter to be interrogated by selected mode signals from external test equipment. The MON position turns on test set monitoring circuits. In the MON position, the TEST light will illuminate to indicate replies are being transmitted in modes 1, 2, 3/A, or C. The OUT position disables the RAD TEST and MON function. Mode 4 controls and indicator are grouped together along the left side of the control panel. The MODE 4 switch enables or disables

aims/iff transponder control panel




Figure 4-8C

mode 4 operation. The CODE switch provides for the selection of either the A or B mode 4 code. When momentarily placed in the HOLD position, it prevents the transponder computer from zeroizing (cancelling) the mode 4 codes when power is removed from the system. In the ZERO position, the mode 4 codes are zeroized. The AUDIO-OUT-LIGHT switch in the AUDIO position selects both audio and reply-light monitoring of mode 4 operation. An audio tone in the pilot's headset indicates that valid interrogations are being received, and illumination of the REPLY light indicates replies are being transmitted. To hear the audio tone, the VOR mixing switch on the interphone control panel must be on. The LIGHT position selects REPLY light monitoring only. The OUT position turns the monitoring circuits off. The transponder control is located on the right-hand side of the sliding console.

Receiver-Transmitter RT-859/APX-72.

The receiver-transmitter (figure 4-8D) contains the primary receiving and transmitting circuits of the IFF transponder system. It receives, decodes, and replies to the characteristic interrogations of operational models 1, 2, 3/A, C, and 4. Absence of the transponder computer and the altimeter-encoder does not affect the operation of the receiver-transmitter except in modes 4 and C respectively. The mode 2 four-digit reply code select switches on the front panel select and indicate the mode 2 reply codes. Other than these switches, the receiver-transmitter is controlled by the positions of the switches and controls on the transponder control. The receiver-transmitter responds only to interrogating signals that correspond to the preset modes and codes. The receiver-transmitter is located in the right-hand radio equipment rack.

Antenna AT-741/A.

Two antennas are provided with the AIMS/IFF transponder system. The antennas receive interrogation signals from other stations and radiate the reply signals generated in the receiver-transmitter. The antennas are mounted on the top and bottom of the fuselage. Either or both antennas may be connected to the receiver-transmitter through the antenna switching unit, which is controlled by the IFF antenna switch.

Antenna Switching Unit SA-1474/A.

The antenna switching unit is connected in the radio frequency path between the antennas and the test set, or between the antennas and the

receiver-transmitter when the test set is replaced with the bypass cable. The antenna switching unit is controlled by the IFF antenna switch and is located in the right-hand radio equipment rack.

IFF Antenna Switch.

The IFF antenna switch panel contains a three-position toggle switch with switch positions TOP, BOTH, and BOT (bottom). In the TOP position the antenna switching unit connects the receiver-transmitter to the top antenna and to the bottom antenna in the BOT position. When set to BOTH, the antenna switching unit alternately connects the receiver-transmitter to the top and bottom antennas approximately 38 times per second. The IFF antenna switch panel is located on the sliding console.

NOTE

Set the IFF antenna switch to BOTH for normal operation.

AAU-21/A Altitude Encoder/Pneumatic Altimeter.

The AAU-21/A pneumatic counter-drum pointer altimeter (figure 4-8E) installed in the pilot's instrument panel is a self-contained unit which consists of a precision pressure altimeter combined with an altitude encoder. The display indicators and the encoder transmits, simultaneously, pressure altitude reporting. Altitude is displayed on the altimeter by a 10,000-foot counter, a 1,000-foot counter and a 100-foot drum. A single pointer indicates hundreds of feet on a circular scale. Below an altitude of 10,000 feet a diagonal warning symbol will appear on the 10,000-foot counter. A barometric pressure setting knob is provided to insert the desired altimeter setting in inches of Hg. A dc-powered vibrator operates inside the altimeter whenever aircraft power is on. A warning flag placarded CODE OFF will appear in the upper left portion of the instrument face to indicate that the altitude encoder is inoperative.

NOTE

If the altimeter's internal vibrator is inoperative, the pause-and-accelerate effect may be exaggerated. Pilots should be especially watchful for the behavior when their minimum approach altitude lies within the "8" to "2" sector of the scale, e.g., 800-1200 feet, 1800-2200 feet, etc.

aims/iff receiver-transmitter




Figure 4-8D

The AAU-21/A and AAU-27/A altimeters employ a unique operating feature. The 10,000 foot and 1,000 foot counter remain in a fixed position during altitude changes while the 100 foot drum and pointer rotate continuously. When each 1,000-foot increment is nearly completed, the counter(s) abruptly index to the next correct digit making reading simpler to observe. However, the altimeter mechanism which provides the feature also causes a characteristic behavior of the pointer. This is a noticeable pause or hesitation of the pointer caused by the additional intermittent friction and inertia loads applied to the mechanism in order to turn over the counter wheel at the thousand foot intervals as the pointer completes each revolution. This momentary pause is followed by a noticeable acceleration as the altimeter mechanism overcomes the counter wheel load and rolls the dial over to the next thousand-foot digit.

This effect will be more pronounced at ten-thousand-foot intervals where both counters are turned over simultaneously. The pause occurs during the "9" to "1" portion of the scale. The pause-and-accelerate behavior is more pronounced at high altitudes and high rates of ascent and descent. During normal rates of descents at low altitudes the effect will be minimal.

The AAU-21/A altimeter indicates pneumatic altitude referenced to barometric pressure and provides coded altitude information (Mode C) to the IFF transponder via the altitude encoder. The CODE OFF flag monitors only the encoder function of the altimeter. It does not indicate transponder condition. The AIMS altitude reporting function may be inoperative without the AAU-21/A CODE OFF flag showing, in case of transponder failure or improper control setting. It is

aims/iff altimeters




Figure 4-8E

also possible to get a "good" Mode C test on the transponder control with the CODE OFF flag showing. Display of the CODE OFF flag only indicates an encoder power failure or a CODE OFF flag failure. In this event, check that AC power is available and that the circuit breakers are in. If the flag is still visible, radio contact should be made with a ground radar site to determine whether the AIMS altitude reporting function is operative, and the remainder of the flight should be conducted accordingly.

NOTE

The appropriate altimeter correction (position error) for the current aircraft configuration must be used to fly corrected altitude for traffic separation.

AAU-27/A Pressure Altimeter.

One altimeter (figure 4-8E) is installed in the copilot's flight instrument panel. The instrument is similar to the altimeter-encoder except it does not have an altitude encoder or the CODE OFF display mechanism. The AAU-27/A is a precision pressure altimeter with a counter-drum-pointer display.

The display indicates pressure altitude from -1000 to +50,000 feet. Altitude is displayed on the altimeter by a 10,000-foot counter, a 1,000-foot counter, and a 100-foot drum. A single pointer also indicates hundreds of feet on a circular scale. Below an altitude of 10,000 feet, a diagonal warning symbol will appear on the 10,000-foot counter. A barometric pressure setting knob is provided to insert the desired altimeter setting in inches of Hg. A dc powered vibrator operates inside the altimeter whenever aircraft power is on. The altimeter is intended primarily as a companion altimeter to the AAU-21/A altitude encoding altimeter. The AAU-27/A altimeter indicates pneumatic altitude referenced to barometric pressure.

NOTE

The appropriate altimeter correction (position error) for the current aircraft configuration must be used to fly corrected altitude for traffic separation.

NOTE

If altimeter AAU-27/A is not installed as part of T.O. 1C-7A-599 modification the copilot's existing altimeter will be retained.

Transponder Set Test Set TS-1843/APX.

The test set provides the capability of testing the AIMS/IFF transponder system on a go/no-go basis in all modes except mode 4. The test set is in the radio frequency path between the receiver-transmitter and the antenna switching unit. When one of the mode 1, 2, 3/A, or C switches is placed in the TEST position, interrogation pulse pairs for the selected mode are generated. These interrogations are applied to the receiver-transmitter to check for proper receiver frequency, sensitivity, and decoding. The test set analyzes the resulting transmitter replies for proper frequency, power, bracket spacing, and antenna circuit vswr. If all tests are within specified limits, the test set causes the TEST light on the transponder control to illuminate, providing a go indication. Failure of a single test prevents the TEST light from illuminating, providing a no-go indication. The test set is located in the right-hand radio equipment rack. A bypass cable may be used in lieu of the test set with subsequent loss of go/no-go testing capability for modes 1, 2, 3/A, and C. The bypass cable is mounted in clips above the test set.

Mount MT-3949()A/U.

The transponder computer is mounted in the MT-3949()A/U, which also provides electrical connections to the AN/APX-72. The mount is located in the right-hand radio equipment rack. The transponder computer is classified, and is mounted prior to each flight. The A and B codes for mode 4 are inserted into the computer at this time.

IFF CAUTION Light.

The IFF CAUTION light illuminates when the IFF caution light circuit detects an inoperative mode 4 capability, provided the transponder computer is installed, aircraft power is on, and the IFF MASTER control is not off. Specific discrepancies monitored by the IFF CAUTION light are: mode 4 codes zeroized, transponder failure to reply to a proper mode 4 interrogation, or the automatic self-test function of the transponder computer reveals a faulty transponder computer. The IFF CAUTION light is located on the pilot's flight instrument panel to the left of the altimeter-encoder.

Operation.**1. Starting Procedure.**

- a. Turn on electrical power.
- b. Set transponder control MODE 1 and 3/A code select switches to the required operational codes.
- c. Set receiver-transmitter mode 2 code select switches to the required operational code.
- d. Set transponder control mode enable switches M-1, M2-, M3-/A, and M-C to ON (unless operational requirements specify that only certain modes are to be used, then set all other mode switches to OUT).
- e. Set the transponder control MODE 4 ON-OUT switch to ON and CODE switch to A or B (as required) when equipped with the transponder computer and flying into a known mode 4 interrogating environment.
- f. Set transponder control RAD TEST-OUT-MON switch to OUT, AUDIO-OUT-LIGHT switch to LIGHT, and IDENT-OUT-MIC switch to OUT.
- g. Set the prevailing atmospheric pressure on the barometric displays of the altimeter-encoder and altimeter. The altimeters should include local altitude.
- h. Set transponder control MASTER switch to STBY for 1 minute (normal ambient temperature) or 5 minutes (extremely low ambient temperatures), then set to NORM.

2. Self-Test Procedure.

- a. Press to test the REPLY and TEST lights. The lights should illuminate.
- b. Press to test the IFF CAUTION light. The lamp should illuminate.

NOTE

If the mode 4 codes are zeroized the IFF CAUTION light will be on before and after this test.

c. Set transponder control mode enable switches M-1, M-2, M-3/A, and M-C in sequence to TEST. The TEST indicator should illuminate when each switch is in the TEST position indicating a system go condition for the particular mode being tested. Reset the mode enable switches to ON or OUT as required.

d. The transponder computer automatically performs a self-test of the mode 4 circuits. Observe that the IFF CAUTION light is off. The IFF CAUTION light will illuminate when a mode 4 no-go condition is detected.

3. Normal Operating Procedures.

a. Mode 4 monitoring. Set the transponder control AUDIO-OUT-LIGHT switch to AUDIO to provide aural and visual (REPLY light) monitoring of valid mode 4 interrogations and replies. To hear the audio tone for mode 4 interrogations, set the VOR mixing switch on the interphone panel to the on position. Set the AUDIO-OUT-LIGHT switch to LIGHT to enable REPLY light monitoring only, if desired.

b. Monitoring modes 1, 2, 3/A, and C. Set the transponder control RAD TEST-OUT-MON switch to MON for monitoring replies to the selected 1, 2, 3/A, and/or C operating modes.

c. Antenna selection. Set the IFF antenna switch to TOP, BOT (bottom), or BOTH as required.

d. Identification of position (I/P) operation. The receiver-transmitter will transmit specially coded I/P reply signals to mode 1, 2, or 3/A interrogations when the IDENT-OUT-MIC switch on the transponder control is energized. Transmission of the I/P reply signals requires the appropriate mode enable switches to be in the ON position. Use one of the following methods to control the transmission of the I/P reply signals.

(1) Momentarily hold the IDENT-OUT-MIC switch in the IDENT position (spring-loaded return to OUT) and then release it. This action will cause the receiver-transmitter to transmit the I/P reply signals for 15 to 30 seconds in response to mode 1, 2, or 3/A interrogations. Repeat as required.

(2) Place the IDENT-OUT-MIC switch in the MIC position. I/P reply signals can now be transmitted by momentarily keying the UHF command transceiver. When the need for transmitting further I/P reply signals ceases, return the IDENT-OUT-MIC switch to the OUT position.

4. Emergency Operating Procedures. During an aircraft emergency or distress condition, the system may be used to transmit specially coded emergency reply signals to mode 1, 2, or 3/A

interrogations. These emergency reply signals will be transmitted as long as the MASTER control on the transponder control remains in the EMER position, regardless of the position of the mode enable switches. For emergency operation, set the MASTER control as follows:

a. Lift the MASTER control knob and rotate to EMER position.

b. When the emergency is over, return the MASTER control to the NORM or LOW position.

5. Inoperative Mode 4 Operation. When illuminated, the IFF CAUTION light signifies that the AIMS/IFF equipment will not respond to mode 4 interrogations, and that operation in a known mode 4 interrogating environment should be avoided. To attempt correction, place the MASTER control to NORM (if in STBY or LOW), check that the mode 4 ON-OUT toggle switch is ON and check that the proper A or B code has been selected for the current code time period. If the IFF CAUTION light remains illuminated, the applicable flight procedures should then be employed that are operationally directed for an inoperative mode 4 condition.

6. Stopping Procedure.

a. Set the transponder control CODE switch to HOLD or ZERO as required.

b. Set the transponder control MASTER switch to OFF. Set the IDENT-OUT-MIC, M-1, M-2, M-3/A, M-C, MODE 4, AUDIO-OUT-LIGHT, and RAD TEST-OUT-MON switches to OUT.

c. Turn off electrical power.

RADAR AN/APN-158.

Radar set AN/APN-158 is a lightweight, airborne, pulse-modulated radar system that provides a continuous picture of weather conditions in the general sky area ahead of the aircraft. The wave length has been selected for optimum results in depicting severe weather; however, satisfactory ground mapping can be obtained where large contrast gradient exists, such as land and water, large cities, etc. It provides visual indication of targets in a 120 degree arc ahead of the aircraft, and an arc of 15 degrees above and below the horizontal.

For weather operations a contour (CNTR) mode of operations is provided which enables the operator to identify turbulent areas by blanking out areas of heavy rainfall within a cloud mass. This is sometimes known as iso-echo or contour effect. The area of greatest turbulence is indicated on the scope by the narrowest bright line encircling the cell as it is displayed, the center of this target will be blanked out indicating that there is heavy rainfall in the cell.

The radar set operates from 27.5 v dc (main bus) and 115 v ac from a radar inverter through circuit breakers on a panel to the right of the main circuit breaker panel. Some aircraft have a separate radar inverter switch located on the sliding console.

WARNING

Do not operate the radar set while personnel or combustible materials are within 18 feet of the antenna reflector. This can have harmful effects on the human body and can ignite combustible materials. Do not operate the set within 50 feet of highly reflective objects. The high level of the reflected energy may damage the receiver.

Operation.

The radar is normally left in the STBY mode for ground operations.

1. The starting procedure is as follows:

a. Turn the following controls to the position indicated:

SWITCH	POSITION	LOCATION
Master	Off	Sliding console (2, figure 4-9)
Background	Min (ccw)	Indicator (figure 1-4)
Range	30 miles (ccw)	Indicator
Tilt	Centered (0°)	Sliding console
Gain	Min (ccw)	Sliding console

SWITCH	POSITION	LOCATION
Red tab	As Desired	Indicator
Dim tab	As Desired	Indicator

b. Turn the master switch to STBY for 3 to 5 minutes for warm-up. There will be no visual or aural indication when the warm-up time has elapsed.

c. Check the operation of the radar set as follows:

(1) Turn the master switch to OPR - scope face should flash very briefly and just once.

(2) Turn the background control slowly clockwise until a sweep is just discernible and range marks are visible. (Do not use excessive contrast.)

(3) Turn the gain control clockwise until targets can be defined and range, azimuth and relative size can be determined. If bright flashes, consistently bright or dark areas or target blooming occurs, the system is malfunctioning and requires maintenance and should be deenergized immediately. The most serious malfunction is manifested when the entire scope face is fully painted or illuminated and the background control will not reduce it, this occurrence requires the set to be deenergized also.

(4) Turn the tilt control up and down slowly and observe that the target appears and disappears with excessive tilt control.

(5) Set the range switch at 60 miles detent (15 mile range marks) and 150 miles detent (25 mile range marks) and note the proper range marks, targets and scan at each range. Return to 30 miles detent (10 miles range marks). Background and gain should not vary appreciably between range settings.

(6) Turn the red tab and dim tab carefully up and down and note the change in color and brilliance of scope presentation.

(7) Turn master switch to CNTR.

(8) Turn gain control to maximum (cw).

(9) Set tilt as needed to paint clouds on scope. If there is any rainfall in the cloud formations within the range and scan of the radar, the display should indicate by contouring the targets.

NOTE

Best results will be obtained with CNTR, 60 mile range, and 150 mile range after the set has been in operation approximately 10 minutes.

2. Deenergize the radar as follows:

a. Turn background control to min (ccw).

b. Turn master control switch off.

CAUTION

Damage to the swivel or yoke of the radar antenna due to no stabilization results from hard landings if the radar is not on OPR or CNTR.

NOTE

• To prevent inadvertently turning off the set and initiating another 3 to 5 minute time delay, an internal barrier is provided between STBY and OFF. The function switch must be depressed when selecting the OFF position.

• The copilot's attitude indicator (figure 1-16) supplies signals for stabilization of the radar antenna when the radar is in OPR or CNTR. Power failure is indicated by the radar gyro power failure indicator.

OPERATION OF ELECTRONICS EQUIPMENT IN CONJUNCTION WITH OTHER ITEMS.

J-2 Compass System.

The J-2 gyro magnetic compass system provides a visual indication of the aircraft's magnetic heading

on the pilot's course indicator (C6A or ID 998/ASN). The magnetic heading is transmitted from the pilot's course indicator to the copilot's radio magnetic indicator (ID 250/AN). Two modes of operation, slaved or free gyro, are provided. The normal mode of operation is the slaved mode in which the directional gyro is slaved to the earth's magnetic field by a flux valve. The free gyro mode is used in latitudes where magnetic heading information is unreliable, in which case, relative headings are provided. The emergency bus supplies 28 volt dc power through a 5-ampere circuit breaker on the miscellaneous electrical circuit breaker panel. The main or spare inverter supplies 115 volt ac power through 2-ampere fuses on the gyro compass fuse panel.

Magnetic Heading Signals. When the inverter switch is turned on and the gyro compass switch is set to SLAVE, 28 volt dc power is applied to the slaving relay in the compass amplifier, and flux valve excitation from the compass amplifier is applied to the flux valve. From the flux valve, slaving synchro signals are fed to the course indicator. The magnetic heading is transmitted from the course indicator to the radio magnetic indicator. The course indicator and the radio magnetic indicator thus register the magnetic heading sensed by the flux valve.

Free Gyro Signals. When the gyro compass switch is set to DG, the slaving voltage is removed from the compass amplifier and the system operates as a free gyro without automatic correction. The directional gyro establishes a fixed reference position within the aircraft, so that when the aircraft heading is changed, the aircraft effectively moves about the gyro. The reference position is transmitted as a heading signal to the course indicator. From the course indicator, the reference position is transmitted to the radio magnetic indicator.

LIGHTING SYSTEMS.

EXTERIOR LIGHTING SYSTEM.

The exterior lighting system consists of navigation, anti-collision, wing inspection, taxiing and landing lights. Formation lights are provided on some aircraft. All exterior lighting systems except the formation lights are powered from the main bus. Formation lights are powered from the secondary bus. The circuits are controlled by individual

switches on the electrical switch panel and overhead console. Circuit protection is afforded by circuit breakers on the EXTERIOR LIGHTS section of the circuit breaker and fuse panel on the forward face of the flight compartment rear bulkhead.

Navigation Lights.

The navigation lights are located in the wing tips, red in the left and green in the right, and the white tail position light is located in the trailing edge of the rudder. The lights are controlled by a switch on the electrical switch panel and the circuits are protected by a 5-ampere circuit breaker marked WING & TAIL on the circuit breaker panel.

Navigation Lights Switch.

The navigation lights two-position toggle switch is on the copilot's side of the electrical switch panel and is marked WING & TAIL with ON and OFF at its up and down positions.

Anticollision Lights.

The two anticollision lights are located one on top of the rudder and the other below the fuselage and are powered from the main bus. Both lights are controlled simultaneously by a switch on the electrical switch panel, and the circuits are protected by the two 5-ampere circuit breakers marked ANTI-COLL., UPPER and LOWER on the circuit breaker panel. Each light is rotated by a dc motor within the beacon light housing and, due to blanking between the two lamps in the housing, a rotating beam of lights is emitted at a predetermined angular separation which can be seen at 15° above to 10° below the horizontal plane of the aircraft.

Anticollision Lights Switch.

The anticollision lights two-position toggle switch is on the copilot's side of the electrical switch panel and is marked ANTI-COLL. with ON and OFF at its up and down positions.

Wing Inspection Lights.

The two wing inspection lights are mounted one on the outboard side of each engine nacelle and are directed towards the wing tip. Both lights are controlled simultaneously by a switch on the

electrical switch panel, and the circuits are protected by the 5-ampere circuit breaker marked WING INSPECT on the circuit breaker panel.

Wing Inspection Lights Switch.

The wing inspection lights two-position toggle switch is on the copilot's side of the electrical switch panel and is marked WING INSPECT with ON and OFF at its up and down positions.

Taxiing Light.

The taxiing light is mounted on the nosewheel door fairing and is directed forward. The light is controlled by a switch on the overhead console and the circuit is protected by a 7-ampere circuit breaker marked TAXI on the circuit breaker panel.

Taxiing Light Switch.

The taxiing light two-position toggle switch is on the overhead console immediately forward of the wing flap selector lever and is marked TAXI LT with ON at its up position.

Landing Lights.

The two 250-watt landing lights are located, one in the leading edge of each wing, outboard of the nacelles and set at a fixed angle. The lights are controlled by two individual switches on the overhead console and the circuits are protected by two 10-ampere circuit breakers marked LANDING LEFT and RIGHT on the circuit breaker panel.

NOTE

Landing lights should not be left on for prolonged periods of time during ground operation.

Landing Lights Switches.

The two landing lights two-position toggle switches are on the overhead console immediately forward of the ignition switch unit and are marked LANDING LTS, LH and RH with ON at the up position.

Formation Lights.

Formation lights are provided on some aircraft. Three of the lights are mounted on the top surface

of the fuselage; two in tandem forward of the cargo compartment doors and one aft of the cargo compartment doors; and three lights are mounted in the rear upper surface of each outer wing panel. The lights are powered from the secondary bus through the 5-ampere circuit breaker marked FORM on the exterior lights circuit breaker panel, and are controlled by a switch on the electrical switch panel marked LIGHTS.

Formation Lights Switch.

The formation lights three-position toggle switch is on the copilot's side of the electrical switch panel and is marked FORM with DIM, OFF, and BRT at the up, middle, and down position.

INTERIOR LIGHTING SYSTEM.

The interior-light system consists of flight compartment, utility, magnetic standby compass, cargo compartment, doors unlocked, cargo loading and rear entrance lights. These lights are powered from the battery, emergency or main bus, the circuits being controlled by individual switches on switch panels in the flight compartment and rear cargo compartment. The circuits are protected by circuit breakers marked INTERIOR on the LIGHTS section of the circuit breaker and fuse panel on the forward face of the flight compartment bulkhead. In addition, an emergency lighting system for the aircraft exits, is installed.

Flight Compartment Dome Light.

The flight compartment dome light is located on the overhead console, aft of the carburetor heat control levers, and contains a red and a white lamp in the housing. The light is controlled by a guarded switch on the overhead console. The circuit is powered from the battery bus and protected by the 5-ampere circuit breaker marked COCKPIT on the circuit breaker panel.

Flight Compartment Dome Light Switch.

The flight compartment dome light three-position toggle switch is at the left of the light on the overhead console and is marked RED, OFF, and WHITE, with a guard which must be displaced before the WHITE position can be selected.

sliding console -typical




Figure 4-9

Flight Compartment Bottom Hatch Light.

The flight compartment bottom hatch light mounted on the lower forward face of the flight compartment rear bulkhead illuminates the compartment bottom hatch, and is powered from the emergency bus. The light is controlled by a microswitch at the hatch which deenergizes the circuit when the hatch is closed. The circuit is protected by the 5-ampere circuit breaker marked UTILITY on the circuit breaker panel.

Utility Lights.

Four utility lights are installed in the flight compartment; one each for the pilot and copilot stowed in brackets on the bulkhead behind each seat, one for the radio rack stowed on the bulkhead at the rack, and one for the cargo doors forward panel stowed near the flight compartment dome light. The lights are fixed to mounting brackets by ball and spring fixtures which engage a groove in a shaft attached to the light assembly. When required, the lights may be pulled from their brackets and a flexible coiled cable permits movement to the desired position. The pilot's and copilot's light may be moved to sockets on either side of the overhead console. The front section of the light assembly can be rotated to four positions to give spotlight or diffused light in either of two colors, red or white for the radio rack light, and red or amber for the remaining lights. A spring catch on the side of the light must be pulled back to change over from red, but the catch is automatically overridden when changing to red. This feature prevents inadvertent selection of white and safeguards night vision. The rear section of each light has an intensity switch marked OFF, DIM, and BRT and also contains a push button for momentary illumination. The light for the cargo doors forward panel is supplied from the battery bus and the circuit is protected by the 5-ampere INTER LIGHTS - COCKPIT circuit breaker (which also protects the flight compartment dome light). The remaining utility lights are supplied from the emergency bus through the 5-ampere INTERIOR LIGHTS - UTILITY circuit breaker. This circuit breaker also protects the flight compartment floor hatch light and the emergency hydraulic selector panel lights.

Magnetic Standby Compass Light.

The magnetic standby compass light is contained in the compass assembly attached to the windshield

center post and is powered from the emergency or main bus. The light is controlled by a switch on the center electrical switch panel, and the intensity of the light, when powered from the main bus is controlled by the setting of the SWITCH, EMERG & ROOF switch on the overhead console PANEL LIGHTS panel. The circuit is protected by either of the 5-ampere circuit breakers marked STANDBY COMPASS, and SW EMERG & ROOF on the circuit breaker panel, depending on switch position.

Magnetic Standby Compass Light Switch.

The magnetic standby compass light two-position toggle switch is located on the copilot's side of the center electrical switch panel and is marked STBY COMP, with EMERG and NORM at its up and down positions respectively. In the NORM position the light is powered by the main bus and the intensity is controlled by the setting of the switch marked SWITCH, EMERG & ROOF, on the PANEL LIGHTS switch panel on the overhead console. In the EMERG position power is supplied from the battery through the emergency bus switch to the light in the compass and to supply the pilot's altimeter, airspeed indicator and turn and slip indicator eyebrow lights. The intensity of the light is then dependent on battery strength.

Cargo Compartment Dome Lights.

The seven cargo compartment dome lights are located in two rows in the cargo compartment roof, four in one row and three in the other, and staggered to provide even distribution of illumination. Each dome light assembly contains a red and a white lamp. The lights are controlled by a guarded switch on the flight compartment rear bulkhead. The circuits are powered from the main bus and are protected by the 15-ampere circuit breaker marked CABIN on the circuit breaker panel.

Cargo Compartment Dome Light Switch.

The cargo compartment dome light three-position toggle switch is mounted on a panel on the forward face of the flight compartment rear bulkhead aft of the pilot's seat and is marked RED, OFF, and WHITE, with a guard which must be displaced before the WHITE position can be selected.

Doors Unlocked Light.

The doors unlocked amber light is located outboard of the take-off check list above the copilot's flight instrument panel. The light will come on if either the flight compartment bottom hatch, passenger doors, cargo door or ramp are not securely closed. The microswitches for the circuit of each door mechanism are powered from the main bus and the intensity of the light is dependent on the setting of the warning lights intensity switch on the center electrical switch panel. The circuit is protected by the 5-ampere circuit breaker marked DOORS WARN on the circuit breaker panel.

Cargo Loading Light and Switch.

The cargo loading light is a spotlight with a white lamp and a mechanically operated red shutter. The light is normally stowed in a mounting in the cargo compartment roof aft of the rear entrance light, and is directed to shine on the cargo loading doors. It can be removed from its mounting and used as a portable light. A two-position slide switch marked ON and OFF is incorporated on the side of the light. The circuit is powered from the main bus and is protected by the 5-ampere circuit breaker marked CARGO on the circuit breaker panel.

Rear Entrance Light.

The rear entrance light is located in the cargo compartment roof directly above the cargo ramp. The circuit is powered from the main bus and the light is controlled by a switch on the interior lights panel at the aft end of the cargo compartment. A ramp actuated switch automatically extinguishes the lights when the ramp is closed. The circuit is protected by the 5-ampere circuit breaker marked CARGO on the circuit breaker panel.

Rear Entrance Light Switch.

The rear entrance door light two-position toggle switch is on the panel marked INTERIOR LTS mounted at the aft end of the cargo compartment and is marked REAR ENTRANCE and LIGHT at the up (ON) and down (OFF) position respectively. An intensity switch controlling the panel lights is marked PANEL LIGHTS, with OFF and BRIGHT at the ends of its control range.

EMERGENCY LIGHTING SYSTEM.

The emergency lighting system is provided to illuminate the aircraft exits in the event of crash landing or complete electrical failure at night. White lights are beamed at the flight compartment roof hatch, the cargo compartment emergency door, the passenger doors and cargo door. The system also includes a control unit mounted in the left side of the cargo compartment roof aft of the rear spar, and a guarded toggle switch marked EXIT LTS on the cargo compartment lights switch panel on the flight compartment bulkhead. The toggle switch is used for manual operation and testing of the lights. The control unit incorporates an inertia switch which will automatically energize the circuit during crash landing, and a 6.6-volt 4-ampere-hour battery. The battery will power the lights for a minimum period of one hour.

PANEL LIGHTS.

Panel and warning lights are discussed in the following paragraphs.

Passenger Warning Signs.

The passenger warning signs are located above the doorway of the forward cargo compartment bulkhead facing aft. The NO SMOKING sign and the FASTEN BELTS sign each contain five lamps. The lamps are powered from the main bus and are controlled by individual switches on the flight compartment rear bulkhead. The circuits are protected by the 15-ampere circuit breaker marked CABIN on the INTERIOR LIGHTS section of the circuit breaker panel.

Passenger Warning Sign Switches.

The two passenger warning sign two-position toggle switches are located on a panel mounted on the forward face of the flight compartment rear bulkhead behind the pilot's seat. The up (ON) position of the left and right switches are marked NO SMOKING and FASTEN BELTS respectively, being the indication of the warning sign they control.

Emergency Hydraulic Selector Panel Lights.

The two lights on the emergency hydraulic selector panel under the hinged access door in the floor of

the flight compartment are powered from the emergency bus and are controlled by a microswitch in the access door opening. When the door is opened the lights will come on provided the emergency bus is energized. The circuit is protected by the 5-ampere circuit breaker marked UTILITY on the circuit breaker panel.

Panel Lights Intensity Switches.

The edge and eyebrow type lighting on all panels is powered from the main bus and, excepting the interior lights control panel at the rear of the cargo compartment, the intensity can be adjusted by means of four rheostats on the overhead console. The circuits are protected by the 5-ampere circuit breakers marked SW EMERG & ROOF on the circuit breaker panel. The four switches are marked PILOT'S & ENGINE; SWITCH, EMERG & ROOF; RADIO CONSOLE; COPILOT'S; and each has a range from OFF to BRT to control the intensity of the lighting of these circuits. The emergency and roof panel lights switch controls the lights on the emergency panel, electrical switch panel, overhead console, and the magnetic standby compass light when it is powered from the emergency bus. The interior lights control panel at the rear of the cargo compartment has an independent switch which controls the intensity of the edge type lighting on that panel.

Warning Lights Intensity Switch.

The warning lights on the various panels are powered from the main bus and are adjusted for intensity by the setting of the two-position toggle switch marked WARN in the section of the electrical switch panel marked LIGHTS. The switch is marked DIM and BRT at the up and down positions respectively.

Pilot's and Engine Panel Lights Switch.

The pilot's and engine panel lights intensity switch is located on the electrical switch panel and is marked PILOT'S & ENGINE, with OFF and BRT at the left and right end respectively of its range. The switch controls the eyebrow type lighting of the instrument, engine instrument, voltammeter, pilot's pedestal and fuel gage panels. The switch simultaneously controls the edge type lighting on the deicing, AC-DC power, elevator trim pedestal, left switch, and fuel control panels.

Copilot's Panel Lights Switch.

The copilot's panel lights intensity switch is located on the electrical switch panel and is marked COPILOT'S, with OFF and BRT at the left and right end respectively of its range. The switch controls the eyebrow type lighting of the instruments on the copilot's panel.

OXYGEN SYSTEM.

CONSTANT FLOW SYSTEM.

The oxygen system supplies the pilot, copilot, and flight mechanic. An oxygen cylinder, a main shutoff valve (marked SUPPLY VALVE - TURN ON FOR OXYGEN) and a charging point (marked OXYGEN CHARGING - CHARGING PRESSURE 1800 + 50 PSI) and gage are located in the cargo compartment roof left side near the flight compartment bulkhead, access being by way of a zippered panel. A plug-in point for each pilot is provided on the side panel adjacent to his seat; the flight mechanic's plug-in point is located in the cargo compartment roof adjacent to the oxygen cylinder installation. Three oxygen masks, are stowed in a container marked OXYGEN MASKS, and are located on the right side of the copilot's seat. A regulator control panel is mounted adjacent to the copilot's plug-in point and contains a system pressure gage, an altitude flow meter and a manual control valve (marked ADJUST TO ALTITUDE). By use of the control valve in conjunction with the altitude flow meter, the copilot is able to adjust the oxygen flow to coincide with the existing flight altitude. The system pressure gages should indicate 1800 ± 50 psi when the system is fully charged. An oxygen duration table is shown in figure 4-10. When oxygen is required, the copilot's regulator control valve must first be closed (fully counterclockwise) before the main shutoff valve is slowly opened. After use, the system must be shut off at the main shutoff valve, then the regulator control valve must be turned fully OFF (counterclockwise).

DILUTER DEMAND SYSTEM (Aircraft Not Modified by T.O. 1C-7A-597).

The oxygen system supplies the pilot, copilot, and flight mechanic. See figure 4-11. The supply of gaseous oxygen is stored in two interconnected cylinders; at stations 46.00 and 54.00. The cylinders are recharged through a filler valve at station 33.2 and the nose RH access door, and a

constant flow oxygen duration chart

OXYGEN DURATION IN HOURS					
THREE CREW MEMBERS					
CYLINDER: 1-TYPE AN6025 AX646-18			CONSTANT FLOW SYSTEM		
GAGE ALTITUDE (FEET)	GAGE PRESSURE - PSI				
	1800	1600	1400	1200	1000
8,000	8.1	7.2	6.4	5.4	4.5
10,000	6.7	5.9	5.3	4.5	3.7
12,000	5.6	5.0	4.5	3.8	3.2
14,000	4.6	4.0	3.6	3.0	2.5
15,000	4.3	3.8	3.4	2.9	2.4
20,000	3.2	2.9	2.6	2.2	1.9
25,000	2.6	2.3	2.1	1.7	1.5
30,000	2.2	1.9	1.7	1.5	1.2

Figure 4-10

check valve on each cylinder line. An adjacent oxygen cylinder pressure gage indicates the pressure in the cylinders; the nominal charging pressure is 1800 ± 50 psi. A shutoff valve is provided on the flight compartment floor aft of the copilot's seat, and is turned counterclockwise for oxygen flow from the cylinders to the oxygen regulator pressure demand panel at each of the three crew positions, where the pressure is reduced to a breathable level. An oxygen hose connection for each crewmember is located adjacent to the crewmember's position for connection of Type A13A oxygen masks. When the system is in operation, and with the diluter switch set at NORMAL OXYGEN, air is drawn into the breathing system and is automatically mixed with oxygen from the supply cylinder to give the total needed oxygen up to approximately 30,000 ft, above this altitude 100% oxygen is delivered automatically. Refer to figure 4-12 for duration of oxygen supply at various altitudes with the diluter switch at NORMAL OXYGEN, and at the 100% OXYGEN position.

Oxygen Regulator Panels.

A panel marked OXYGEN REGULATOR PRESSURE DEMAND, is provided adjacent to each crewmember position. The pilot's and copilot's regulator panel is located at the lower inboard corner of their respective flight instrument panels (figure 4-11), and the flight mechanic's regulator panel is on the left aft face of the cargo compartment forward bulkhead. The three regulator panels are identical and each has an eyebrow type light in the center for panel illumination, a gage marked OXYGEN PSI calibrated from 0 to 2000 psi, with a white arc from 0 to 300 (low level) and FULL at 1800 psi. In addition, a blinker indicator marked FLOW which shows that oxygen is flowing on demand to the user's mask, and three individually colored switches for controlling the oxygen supply flow are provided as follows:

Supply Switch (Green Color). The supply two-position switch on the right of the panel is marked SUPPLY with ON and OFF at the up and down position respectively. The switch is used to control the supply of oxygen at each panel.



Diluter Switch (Black Color). The diluter two-position switch on the lower center of the panel is marked 100% OXYGEN and NORMAL OXYGEN at the up and down position respectively. With the switch at NORMAL OXYGEN position the oxygen passes through a diluter demand route for normal operation. At 100% OXYGEN position the air-valve of the diluter demand route is closed and pure oxygen only is fed to the user's mask; this position should be selected if any doubt exists regarding the oxygen supply.

NOTE

When 100% oxygen is used, the oxygen duration will be reduced.

Pressure Supply Switch (Red Color). The pressure supply three-position switch on the left of the panel is marked EMERGENCY and NORMAL at the up and center position respectively, and TEST MASK at the down (momentary) position which is selected against a spring tension. The switch should be at NORMAL position for routine operation to allow regulated oxygen pressure to be supplied to

diluter demand oxygen system



OXYGEN REGULATOR PANEL AT EACH CREW POSITION

Figure 4-11

the user. At EMERGENCY position a continuous positive pressure of oxygen is supplied to the user regardless of altitude, to prevent hypoxia or unconsciousness. When the switch is held at TEST MASK position, oxygen at positive pressure is supplied to test the user's mask for leaks.

CAUTION

When positive pressures are required, it is mandatory that the oxygen mask be well fitted to the face. Unless special precautions are taken to insure no leakage, then continued use of positive pressure under these conditions will result in the rapid depletion of the oxygen supply.

Oxygen Shutoff Valve.

The oxygen shutoff valve on the flight compartment floor aft of the copilot's seat is used to stop the flow of oxygen from the cylinders to the three oxygen regulator panels. The valve is marked OXYGEN SHUT OFF VALVE and OFF, and arrowed clockwise.

Cylinder Filler Valve and Pressure Gage.

The cylinder filler valve and pressure gage are mounted to the right of the oxygen cylinders. The gage dial is marked OXYGEN CYLINDER PRESSURE and graduated from 0 to 2000 psi. A label below the gage is marked OXYGEN CHARGING, and below the filler valve it is marked CHARGING PRESSURE 1800 $\pm$ 50 PSI.

To Turn On Equipment.

Before entering the aircraft check the oxygen cylinder pressure gage reading to insure there is sufficient oxygen for the mission. On entering the flight compartment turn the oxygen shutoff valve fully counterclockwise to allow the oxygen to flow to the oxygen regulator panels. When seated in position place the regulator panel supply switch to ON and check the oxygen supply pressure gage reading is within normal supply limits. Fit and connect mask then check oxygen flow and supply with diluter switch at 100% OXYGEN then at NORMAL OXYGEN with the pressure supply switch at NORMAL. Check supply with the pressure supply switch at EMERGENCY and at TEST MASK.

oxygen duration chart - diluter demand system

OXYGEN DURATION IN HOURS THREE CREW MEMBERS					
CYLINDERS: 2-TYPE AN6025 AX386			DILUTER DEMAND SYSTEM		
ALTITUDE (FEET)	GAGE PRESSURE - PSI				
	1800	1600	1400	1200	1000
8000	0.8	0.7	0.6	0.5	0.4
	3.3	2.9	2.6	2.2	1.8
10,000	0.8	0.7	0.6	0.6	0.5
	3.6	3.2	2.8	2.4	2.0
12,000	0.9	0.8	0.7	0.6	0.5
	4.0	3.6	3.1	2.7	2.2
14,000	1.1	1.0	0.9	0.7	0.6
	4.4	3.9	3.5	3.0	2.5
15,000	1.2	1.1	0.9	0.8	0.7
	4.6	4.1	3.6	3.0	2.5
20,000	1.5	1.3	1.2	1.0	0.8
	4.2	3.8	3.3	2.8	2.4
25,000	2.0	1.8	1.6	1.3	1.1
	2.4	2.1	1.9	1.6	1.3
30,000	2.6	2.4	2.1	1.8	1.5
	2.6	2.4	2.1	1.8	1.5
NOTE: UPPER FIGURES INDICATE DILUTER SWITCH AT "100% OXYGEN" LOWER FIGURES INDICATE DILUTER SWITCH AT "NORMAL OXYGEN"					

Figure 4-12

To Turn Off Equipment.

Move regulator panel supply switch to OFF. Before leaving the flight compartment turn the oxygen shutoff valve fully clockwise to OFF, and the regulator panel pressure supply switch to NORMAL.

DILUTER DEMAND SYSTEM (Aircraft Modified by T.O. 1C-7A-597).

The oxygen system supplies the pilot, copilot and flight mechanic. The supply of gaseous oxygen is stored in two interconnected cylinders. The cylinders are recharged through a filler valve at the nose RH access door. An adjacent oxygen cylinder pressure gage indicates the pressure, normally 1800 $\pm$ 50 psi. A duplicate gage to the right of the

copilot also indicates cylinder pressure. A shutoff valve is provided on the flight compartment floor aft of the copilot's seat, and is turned counterclockwise for oxygen flow from the cylinders to the PRESSURE REDUCTION VALVE where the pressure is reduced to a breathable level and then to crew oxygen regulators. An oxygen hose connection for each crewmember is located adjacent to the crewmember's position. When the system is in operation, and with the diluter switch set at NORMAL OXYGEN, air is drawn into the breathing system and is automatically mixed with oxygen from the supply cylinder to give the total needed oxygen up to approximately 30,000 ft;

above this altitude 100% oxygen is delivered automatically. Refer to figure 4-12 for duration of oxygen supply at various altitudes with the diluter switch at NORMAL OXYGEN, and at the 100% OXYGEN position.

Oxygen Regulator Panels.

A panel marked OXYGEN REGULATOR PRESSURE DEMAND is provided adjacent to each crewmember position. The pilot's and copilot's regulator panels are located outboard of their respective seats, and the flight mechanic's regulator panel is on the left face of the rear cockpit bulkhead. The three regulator panels are identical

Altitude (ft)	Duration (min)	Duration (min)	Duration (min)	Duration (min)
0-10,000	120	120	120	120
10,000-15,000	100	100	100	100
15,000-20,000	80	80	80	80
20,000-25,000	60	60	60	60
25,000-30,000	40	40	40	40
30,000-35,000	20	20	20	20
35,000-40,000	10	10	10	10
40,000-45,000	5	5	5	5
45,000-50,000	2	2	2	2
50,000-55,000	1	1	1	1
55,000-60,000	0.5	0.5	0.5	0.5
60,000-65,000	0.2	0.2	0.2	0.2
65,000-70,000	0.1	0.1	0.1	0.1
70,000-75,000	0.05	0.05	0.05	0.05
75,000-80,000	0.02	0.02	0.02	0.02
80,000-85,000	0.01	0.01	0.01	0.01
85,000-90,000	0.005	0.005	0.005	0.005
90,000-95,000	0.002	0.002	0.002	0.002
95,000-100,000	0.001	0.001	0.001	0.001

Figure 4-12

To Turn On Equipment.

Move regulator panel supply switch to OFF. Before leaving the flight compartment turn the oxygen shutoff valve half clockwise to OFF and the regulator panel pressure supply switch to NORMAL.

OXYGEN DEMAND SYSTEM (Aircraft Modified by T.O. 1C-7A-887).

The oxygen system supplies the pilot, copilot, and flight mechanic. The supply of gaseous oxygen is stored in two interconnected cylinders. The oxygen is released through a filter valve at the rear bulkhead door. An oxygen oxygen regulator pressure gauge indicates the pressure, normally 1200 ± 50 psi. A duplicate gauge is the right of the

result in the rapid depletion of the oxygen supply.

Oxygen Shutoff Valve.

The oxygen shutoff valve on the flight compartment floor aft of the copilot's seat is used to stop the flow of oxygen from the cylinders to the three oxygen regulator panels. The valve is marked OXYGEN SHUT OFF VALVE and OFF, and turned clockwise.

Cylinder Filter Valve and Pressure Gauge.

The cylinder filter valve and pressure gauge are mounted to the right of the oxygen cylinder. The gauge dial is marked OXYGEN CYLINDER PRESSURE and graduated from 0 to 2000 psi. A label below the gauge is marked OXYGEN CHARGING, and below the filter valve it is marked CHARGING PRESSURE 1200 ± 50 PSI.

To Turn On Equipment.

Before entering the aircraft check the oxygen cylinder pressure gauge reading to insure there is sufficient oxygen for the mission. On entering the flight compartment turn the oxygen shutoff valve half counterclockwise to allow the oxygen to flow to the oxygen regulator panels. When seated in the flight compartment the regulator panel supply switch is pushed back the regulator panel supply switch to ON and check the oxygen supply pressure gauge reading is within normal supply limits. If not, reading is within normal oxygen flow and supply with diluter switch at 100% OXYGEN then at NORMAL OXYGEN with the pressure supply switch at NORMAL. Check supply with the pressure supply switch at EMERGENCY and at TEST MASK.

and each has an eyebrow type light in the center for panel illumination, a gage marked OXYGEN PSI (calibrated from 0 to 500 psi, with a white arc from 0 to 50 psi to show low level), a blinker indicator marked FLOW (which shows that oxygen is flowing on demand to the user's mask) and three individually colored switches for controlling the oxygen flow as follows:

SUPPLY SWITCH (GREEN). The two-position switch on the right of the panel is marked SUPPLY with ON and OFF at the up and down position respectively. This switch is used to control the supply of oxygen at each panel.

DILUTER SWITCH (WHITE). The two-position switch on the lower center of the panel is marked 100% OXYGEN and NORMAL OXYGEN at the up and down position respectively. With this switch at NORMAL OXYGEN position the oxygen passes through a diluter for normal operation. At 100% OXYGEN position the air-valve of the diluter is closed and pure oxygen only is fed to the user's mask.

NOTE

When 100% oxygen is used, the oxygen duration will be reduced.

PRESSURE SUPPLY SWITCH (RED). The three-position switch on the left of the panel is marked EMERGENCY and NORMAL at the up and center position respectively, and TEST MASK at the down (momentary) position. This switch should be at NORMAL position for routine operation to allow regulated oxygen pressure to be supplied to the user. At EMERGENCY position a continuous positive flow of oxygen is supplied to the user regardless of altitude. When the switch is held at TEST MASK position, oxygen at positive pressure is supplied to test the user's mask for leaks.

CAUTION

When positive pressures are required, it is mandatory that the oxygen mask be well fitted to the face. Unless special precautions are taken to insure no leakage, continued use of positive pressure under these conditions will result in the rapid depletion of the oxygen supply.

Oxygen Shutoff Valve.

The oxygen shutoff valve on the flight compartment floor aft of the copilot's seat is used to stop the flow of oxygen from the cylinders to the three oxygen regulator panels. The valve is marked OXYGEN SHUTOFF VALVE and OFF, and arrowed clockwise.

Cylinder Filler Valve and Pressure Gage.

The cylinder filler valve and pressure gage are mounted to the right of the oxygen cylinders. The gage dial is marked OXYGEN CYLINDER PRESSURE and graduated from 0 to 2000 psi. A label below the gage is marked OXYGEN CHARGING, and below the filler valve it is marked CHARGING PRESSURE 1800 ± 50 psi. A second gage in the cockpit to the right of the copilot also indicates crew oxygen cylinder pressure.

To Turn On Equipment.

Check the oxygen cylinder pressure gage reading to insure there is sufficient oxygen. On entering the flight compartment turn the oxygen shutoff valve fully counterclockwise to allow the oxygen to flow to the regulator panels. Place the regulator panel supply switch to ON and check that oxygen supply pressure gage reading is within normal supply limits. Fit and connect mask then check oxygen flow and supply with diluter switch at 100% OXYGEN then at NORMAL OXYGEN with the pressure supply switch at NORMAL. Check supply with the pressure supply switch at EMERGENCY and at TEST MASK.

To Turn Off Equipment.

Move regulator panel supply switch to OFF. Before leaving the flight compartment turn the oxygen shutoff valve fully clockwise to OFF, and the regulator panel pressure supply switch to NORMAL.

CARGO LOADING EQUIPMENT.

CARGO COMPARTMENT.

The cargo compartment of the aircraft, which extends from arm 193.0 to arm 538.0 is uniform in height and width and has a volume of 1150 cubic feet. It has two passenger doors at the aft end, one on each side of the cargo compartment, with a removable access ladder which fits into either door

opening. A cargo door, aft of the cargo compartment, consists of a large door which hinges upwards from the rear, and a ramp which is an extension of the cargo compartment floor. A heating duct extends along each side of the cargo compartment at floor level. Well type troop seats, comprising eight units per side, may be installed to accommodate 32 troops (includes FM) or 26 combat equipped troops (includes FM). With ten aft seat units removed, 14 litters may be installed. On some aircraft the cargo compartment is adapted for 20 litters and 1 troop seat unit. Fixed fittings are provided for the installation of air delivery equipment. For loading instructions refer to T.O. 1C-7A-9.

Cargo Compartment Floor.

The cargo compartment floor is of aluminum alloy honeycomb sandwich construction. Removable plywood panels, with aluminum alloy skid strips to facilitate cargo handling, are provided for floor protection. The floor supporting structure is a grid with three continuous longitudinal keels which occupy the space between the floor and the outside section. The keels will act as skids in the event of a wheels-up landing. Tie-down rings rated at 5000 pounds are provided in the floor, and studs are installed for the attachment of seats and litter supports.

Cargo Compartment Floor Strength-Bulk Cargo.

The cargo compartment floor will not withstand the same load over its entire area. The honeycomb paneling is designed to withstand a load of 40 psi at any point; this is an expression of the inherent strength of the paneling, and while the paneling itself will withstand this load, the strength of other parts of the fuselage may be exceeded. For this reason, there are other factors which limit the load which may be placed on the cargo compartment floor. The local footprint pressure of individual load items must not exceed 1000 pounds per square foot, while at the same time a loading of 1200 pounds per running foot must not be exceeded. A running foot is measured fore-and-aft, parallel to the longitudinal axis of the aircraft. In other words, a running foot is a one-foot strip the full width of the cargo compartment floor. If bulk cargo will exceed either of these limits, shoring must be used to spread the weight over a larger area.

Cargo Compartment Floor Strength-Vehicle Loads.

Refer to T.O. 1C-7A-9 for proper aircraft loading or offloading and for take-off, flight, and landing. Loads on the vehicle treadways must not exceed 2000 pounds per wheel during loading and offloading. This is also the maximum wheel loading on the treadways forward of arm 397.6 during take-off, flight, and landing. On the treadway areas aft of arm 397.6 during take-off, flight, and landing, and the remainder of the floor area under all conditions, the loading must not exceed 1000 pounds per wheel.

CAUTION

These limits are based on a vehicle tire pressure of not more than 40 psi. Before loading a vehicle into the aircraft insure that tire pressures do not exceed this value.

CARGO TIE-DOWN RINGS.

Cargo tie-down rings are installed in the cargo compartment floor, and in the cargo compartment wall at floor level. Each floor tie-down ring fits into a recessed sheet-metal pan, which allows the ring to be clear of the cargo compartment floor. The rings will swivel through 360°, and each ring and its attachment is capable of withstanding a load of 5000 pounds ultimate. The rings are arranged in five rows, each outside row has eight rings, while each of the three center rows has eighteen rings, making a total of seventy rings rated at 5000 pounds ultimate. Four of the recessed pans contain studs to which litter supports may be attached. The wall tie-downs consist of six removable rings, three on each side of the cargo compartment at floor level, and are rated at 10,000 pounds ultimate. A recess in the floor at each ring allows clearance for the tie-down device. All tie-down rings are coded to enable ring positions to be located. Each ring labeled with a letter and a numeral; the letter indicating the row and the numeral indicating the ring position in the row.

MONORAIL CRANE PROVISION.

A corrugated web structure supporting an extruded carrier member runs the length of the cargo compartment at the roof. It extends from the flight compartment bulkhead to fuselage Frame

No. 2, just aft of the passenger doors. The structural provisions are for a monorail crane assembly, with a 2000 pound capacity, for loading or offloading of cargo. At present the carrier member is used to provide a guide for the cable of the extraction parachute manual release control.

RAMP EXTENSIONS.

Two ramp extensions, 120 inches long and 15 inches wide, are supplied with each aircraft. When not in use the extensions may be stowed in special racks above the cargo door. The ramps are reversible and both sides have a non-skid surface. One side is provided with edge members for use of wheeled vehicles, while the opposite side has a flat surface to facilitate cargo movement when using rollers, etc. Each end of the ramp extensions are provided with a projecting edge lip and two spring-loaded plungers. The edge lip fits into the groove along the aft end of the ramp and the plungers engage with any two holes along the ramp aft face; the holes are spaced every two inches. The ramp extensions should be installed so that the distance between them matches, as closely as possible, the width of the tread of any vehicle to be driven over them. In addition, they should be equal distance on both sides of the centerline of the aircraft.

Ramp Extensions Stowage.

Two stowage racks are provided, one for each ramp extension, in the rear fuselage between Frames No. 5 and 12. The racks are pivoted at their aft ends, and when lowered rest on integral legs supported by the closed cargo door. The ramp extensions must be stowed in the racks in one position only; an instruction is marked on both sides of the extensions as follows: STOW WITH THIS END FORWARD AND UP, and an arrow shows the side to be uppermost. The extension cannot be hooked to the support rod in any other position. When the racks are raised and locked in the stowed position, the cargo door may be fully opened without interference. The racks themselves must be raised and locked in the stowed position if the extensions are not to be carried. A T-shaped locking handle, secured by a spring clip, is fitted centrally in each rack crossbar. Releasing the clip and pulling the handle forward will allow the support rod to pivot and the hooks may then be disengaged and the rack lowered. The forward part of the rack consists of an end plate welded to a telescopic tube, which

is secured by a pip-pin attached to a chain. To install an extension in a stowage rack, the pip-pin is removed and the end-plate moved forward slightly to allow engagement of the two plunger pins, at the end of the ramp extension, with two holes in the plate. Two hooks on the end plate support the rack only when the rack is stowed minus a ramp extension. When a rack is stowed with an extension, the projecting end lip of the extension hooks over the pivoted support rod. When the rack is raised, the locking handle is pushed aft and bears on the end plate or ramp extension, preventing any movement.

CARGO DOOR AND RAMP SYSTEM.

The cargo door and ramp are used primarily for loading and offloading cargo, troops or casualties, or for air delivery operations. The door and ramp may be opened or closed independently by electrical or mechanical actuation.

NOTE

The cargo door may be used as an emergency exit, both in the air or on the ground. In the air the door should be opened, while on the ground it may be opened or jettisoned.

CARGO DOOR OPERATION.

The cargo door is attached at its aft end to the rear fuselage by two ball and socket type hinges. The door is raised and lowered by a chain and cable system, driven by a 24-volt motor powered from the main dc bus. The motor is mounted to a frame on the left side of the rear fuselage and its dc electrical power is controlled by a CARGO DOORS MASTER switch on the circuit breaker panel, behind the pilot. With the master switch on, the cargo door may be opened or closed from either of two locations; by the CARGO DOOR, OPEN-OFF-CLOSE switch in the flight compartment on the circuit breaker panel (figure 4-13), or by the CARGO DOOR OPEN-CLOSE switch located in the cargo compartment roof, inboard of the left passenger door (figure 4-14). Limit switches are fitted which cut-out the motor when the cargo door is in the fully open or fully closed position. An amber warning light on the right side of the emergency panel in the flight compartment, marked DOORS UNLOCKED, will

illuminate and indicate if the cargo door, ramp, bottom hatch, or either passenger door is not fully secured. Manual operation of the cargo door is achieved by means of a handcrank aft of the left passenger door on the side of the fuselage. The handcrank is connected via a torque tube to the motor, and the handle is held by a spring in the manual-disengage position. Pushing the handle to the rear against the spring disengages the motor, and turning the handle clockwise will open the door, counterclockwise will close it.

WARNING

The cargo door must be visually checked fully open before an air drop, as no indication is given in the flight compartment should the door not be completely open.

RAMP OPERATION.

The ramp is hinged to the aft end of the cargo compartment and is raised or lowered by two screw jacks driven by 24-volt motor through a system of torque tubes, shafts, and gears. The motor, powered from the main dc bus, is mounted on the right side of the roof in the rear fuselage. The ramp dc power is controlled by the CARGO DOORS MASTER switch in the flight compartment on the circuit breaker panel. With the master switch on and the aircraft resting on its wheels, the ramp may be lowered or raised from either of two locations; by the RAMP DOOR, OPEN-OFF-CLOSE switch in the flight compartment on the circuit breaker panel (figure 4-13), or by the RAMP DOOR, OPEN-CLOSE switch located in the cargo compartment roof, inboard of the left passenger door (figure 4-14). Limit switches are fitted which cut-out the motor when the ramp is in the fully up or fully down position, when the aircraft is on the ground. When the aircraft is airborne, a weight switch on the nose landing gear limits the ramp lowering position to 15° below the horizontal. The ramp 15° position is required for air drop operations, and is indicated in the flight compartment by the illumination of a green press-to-test light on the circuit breaker panel marked 15° POSITION, RAMP DOOR. A guarded override switch spring-loaded to off, is provided on the same panel, marked OVERRIDE, with switch positions RAMP DOWN and OFF. Raising the

guard and selecting and holding the switch to RAMP DOWN will override the 15° limit switch, then selection of the RAMP DOOR, OPEN-OFF-CLOSE switch to OPEN will enable the ramp to be lowered as desired.

Manual operation of the ramp is by means of a detachable handcrank, clipped to the cargo compartment wall aft of the left passenger door and marked STOWAGE RAMP DOOR HANDLE. Before attempting to lower the ramp manually the motor must first be disengaged by means of a knob on the motor. The crank handle may then be positioned in the socket, provided in the cargo compartment roof adjacent to the door switch panel, marked MANUAL CONTROL RAMP DOOR. Turning the handle counterclockwise will lower the ramp, clockwise will raise it.

CARGO DOOR OPERATION PROCEDURES.

Procedural steps for operating the cargo door are as follows:

Electrical Operation.

The cargo door is opened and closed electrically as follows:

1. If an external power supply is to be used, check that the battery master switch and the generator switches are OFF.
2. Check that the interior of the rear fuselage is clear of obstructions and that the ramp extension stowage racks are locked in their stowed position. Check that the side anchor line is in the stowed position.
3. Pull back on the cargo door manual crank handle to insure that the brake and clutch of the motor are engaged.
4. Select the CARGO DOORS master switch to CARGO DOORS.
5. Select the CARGO DOOR operating switch, on either the fore or the aft panel, to OPEN. Return switch to the center position when doors are fully open.
6. To close the door, select the CARGO DOOR operating switch to CLOSE. Return the switch to the center position when the operation is completed.

cargo door and ramp switches (forward panel)




Figure 4-13

cargo door and ramp switches (aft panel)




Figure 4-14

7. Select the CARGO DOORS master switch off.

8. Disconnect the external power supply, if used.

Manual Operation.

The cargo door is opened and closed manually as follows:

1. Check that the interior of the rear fuselage is clear of obstructions and that the ramp extension stowage racks are locked in their stowed position. Use the aircraft lighting and ramp loading light, if necessary.

2. Push the MANUAL CONTROL CARGO DOOR handle to the rear against the spring until the handle is at 90° to the torque tube.

3. Turn the handle clockwise until the door is open.

4. To close the door, maintain the handle position at 90° to the torque tube, and turn handle counterclockwise.

5. When the manual operation is completed, pull handle fully back to insure engagement of the brake and motor clutch.

RAMP OPERATION PROCEDURES.

Procedural steps for operation the ramp are given in the following paragraphs.

Electrical Operation.

The ramp is opened and closed electrically as follows:

CAUTION

The ramp is not to be operated when supporting a load.

1. If an external power supply is to be used, check that the battery master switch and the generator switches are OFF.

2. Check the ground clearance below the ramp and remove any obstructions.

CAUTION

With the aircraft on level ground, with normal payload, the fully open ramp may have a ground clearance of only one inch. The amount of ground clearance depends upon the setting of the limiting switch, which can be adjusted to provide up to six inches clearance.

3. Check that the ramp floor is clear. Use the aircraft lighting and ramp loading light, if necessary.

4. Check that the ramp motor is engaged with the drive. When engaged, the knob on the motor is protruding slightly from the unit and is springloaded out.

CAUTION

Do not engage or disengage while the motor is running.

5. Select the CARGO DOORS master switch to CARGO DOORS.

6. Select the RAMP operating switch, on either the fore or the aft panel, to OPEN. Return switch to the center position when the ramp is in the required position.

7. To raise the ramp, select the RAMP operating switch to CLOSE. Return the switch to the center position when the operation is completed.

8. Select the CARGO DOORS master switch off.

9. Disconnect the external power supply, if used.

Manual Operation.

The ramp is opened and closed manually as follows:

1. Check the ground clearance below the ramp and remove any obstruction.

2. Check that the ramp floor is clear. Use the aircraft lighting and ramp loading light, if necessary.

3. Disengage the motor from the drive by pushing in the knob on the motor and turning it approximately 180° until the knob locks in.

4. Remove the RAMP DOOR HANDLE from its STOWAGE and engage it in the MANUAL CONTROL RAMP DOOR socket.

5. Turn the handle counterclockwise until the ramp is in the required position.

6. To raise the ramp, turn the handle clockwise.

7. Reengage the motor by turning the knob approximately 180° until it springs to the out position.

AIR DROP SYSTEM.

The aircraft is equipped for the air dropping of supplies and equipment, rigged on platforms or in containers, by the extraction, gravity, or manual ejection methods. Parachutists may also air-drop from the aircraft. Refer to T.O. 1C-7A-9.

PENDULUM SYSTEM.

A pendulum release system is provided for extraction or gravity release of loads. The installation consists of an ejector rack (MK VIII bomb shackle), a pendulum hook at Frame No. 2 and a release clip at the aft end of the ramp. The ejector rack is located at the aft end of the cargo compartment roof between Arm 515 and Frame No. 2. The extraction or release parachute is released from the rack electrically by actuation of the PENDULUM RELEASE switch in the flight compartment (figure 4-15). Power is taken from the emergency bus through a 5-ampere circuit breaker, marked TROOP JUMP on the EXTERIOR LIGHTS section of the circuit breaker panel.

The extraction or release parachute may be released manually by means of a handle located in the forward part of the cargo compartment roof. For use of the system for air dropping, refer to T.O. 1C-7A-9.

BLACKOUT CURTAINS.

Sixteen blackout curtains are provided for the cargo compartment windows for use during night operations. Each curtain has Velcro tape around the edges and four equally spaced webbing tabs. Each window has Velcro tape cemented around the window frame, and four equally spaced black index marks. The curtains are installed by positioning the curtain tabs to line up with the index marks on the window frame, and pressing the Velcro tape. The curtains are removed by using the webbing tabs to separate the Velcro tape.

TROOP JUMP LIGHTS.

Two troop jump lights are installed on a panel on the aft frame of each passenger door. Each pair of press-to-test lights consists of a GREEN JUMP and a RED CAUTION light, and are controlled from the TROOP JUMP panel on the copilot's instrument panel. Power is taken from the emergency bus, and a 5-ampere circuit breaker, on the EXTERIOR LIGHTS section of the circuit breaker panel, is marked TROOP JUMP.

Troop Jump Panel.

The TROOP JUMP panel (figure 4-15), located below the AC/DC power panel in the flight compartment, has a three-position troop jump switch, a red and a green press-to-test light and a dim-bright switch. The panel layout differs slightly between aircraft as shown in figure 4-15. The troop jump switch controls the jump lights in the cargo compartment, and also the lights adjacent to the switch. The dim-bright switch controls the intensity of the jump lights in the cargo compartment. The intensity of the jump lights in the flight compartment is controlled by the WARN lights intensity switch on the LIGHTS panel.

INSTALLATION OF EQUIPMENT.


The installation of air dropping equipment is contained in T.O. 1C-7A-9.

MISCELLANEOUS EQUIPMENT.


TIE-DOWN DEVICE STOWAGE.

Two stowage boxes are provided, one is installed on each side of the forward part of the cargo

troop jump-pendulum release panel



SOME AIRCRAFT



OTHER AIRCRAFT

Figure 4-15

compartment, for the stowage of the cargo tie-down equipment. The box covers are hinged and are secured by Velcro tape hooks.

BLACKOUT CURTAINS STOWAGE.

The sixteen blackout curtains for the cargo compartment windows are stowed in a canvas bag, marked **BLACKOUT WINDOW CURTAINS**, secured to the aft face of the flight compartment bulkhead, on the left side. The bag is secured with Velcro tape.

COMFORT PROVISIONS.

The aircraft is provided with three relief tubes, one each for the pilot and copilot clipped just below

their respective seats, and one for passenger use clipped to the side of the cargo compartment just aft of the right passenger door.

DRAFTPROOF DOOR.

A retractable draftproof semi-rigid door separates the cargo compartment from the tail of the aircraft and cargo door. Turning the handle on the lower portion of the upper panel to the door clockwise will release latches and allow springs to fold and retract the door into its stowed position in the roof. A strap and a cable are provided as hand grips to be used for extending the door and for reducing the spring assist during retraction. The draftproof door will automatically retract when the cargo door is jettisoned.

Draftproof Door Restraining Straps.

The draftproof door is secured in its stowed position by attaching the clip ends of two straps (one strap is suspended from a bracket on each side of Frame No. 3), to their respective special screws provided near the edge of the door bottom panel. Separate the Velcro tape, which holds each strap doubled to itself, and connect the clip to the screw on the door, then press the Velcro tape together again.

PORTABLE OXYGEN EQUIPMENT.

A portable oxygen unit, consisting of an oxygen bottle, sling, and a face mask, is located on the bulkhead behind the pilot's seat. The unit is mainly for use in the event of a fire in the fuselage, or for use by a crewmember having to go to the rear of the aircraft while at oxygen height.

ALARM BELL SYSTEM.

On some aircraft a guarded spring-loaded toggle switch marked **ALARM BELL** is located on the **TROOP JUMP - AIR SUPPLY** panel, below the fuel control panel. On other aircraft the switch is located on the circuit breaker panel on the flight compartment bulkhead. Lifting the guard and holding the switch up will complete the circuit to a bell located on the right cargo compartment wall. The bell is of the vibrator type and will continue ringing until the switch is released. Power is supplied from the emergency bus.

IGNITION ANALYZER.

An electrical connector is located on the forward face of the pilot's bulkhead, and is marked IGNITION ANALYZER. The connector is covered by a dust cap when not in use. A portable airborne-type ignition analyzer unit may be carried in the aircraft and, when operating, is used to detect, locate, and classify any malfunction in the ignition system.

WINDSHIELD WIPER SYSTEM.

A windshield wiper system is installed for both the pilot's and copilot's windshield panels. The system consists of two interconnected windshield wipers, one for each panel, driven by a dc motor powered from the secondary bus through a 10-ampere circuit breaker. It is controlled by a rotary switch on the center switch panel.

Windshield Wiper Switch.

The windshield wiper rotary switch located on the left of the electrical switch panel is marked WIPER. The switch has six marked positions; PARK, OFF, FAST, 3/4, 1/2, and SLOW. To park the wipers, the switch is held momentarily in the PARK position and then released, when it will return to the OFF position.

CAUTION

An excessive load is imposed on the wiper motor if the wipers are operated on a dry windshield, and scratching of the windshield surface may result.

NOTE

If the switch is held in the PARK position for a prolonged period, the wipers will start to oscillate.

MOORING POINTS.

On some aircraft, shackles are installed on the landing gear for the purpose of mooring the aircraft to the ground. On each main landing gear unit a shackle is bolted to the front of the shock

strut at the drag strut attachment point. On the nose landing gear a shackle is bolted to the lug on the front of the shock strut.

FUSELAGE STEADY STRUT.

As a safety measure against the aircraft tipping when loading and unloading cargo, an adjustable strut is supplied as part of the ground equipment. When loading items of cargo weighing more than 3500 pounds, the steady strut should be used. The strut consists of a base plate, a locking nut, and a tube assembly incorporating a screw thread. A pin, normally stowed in a clip at the fork end of the strut, is used to attach the strut to the anchor fitting on the center underside of the fuselage, just forward of the passenger doors. Angular adjustment of the base plate may be made up to approximately 15° to suit uneven ground, and the plate can be locked in position by turning the lock nut in the direction indicated by an arrow on the plate. Adjustment for height is made by turning the upper portion of the tube assembly, and should normally be adjusted so that the base plate is approximately 3 inches off the ground. Should the pilot inadvertently taxi the aircraft with the strut in position, the strut will pull away from a light spring retainer clip and release from the aircraft.

HOT FUEL PRIME SYSTEM.

A hot fuel prime system can be installed to facilitate engine starting in ambient temperatures below 32°F (0°C). Below ambient temperatures of 0°F (-18°C) engine preheat may be necessary in addition to hot fuel priming. The hot fuel priming system consists of hot fuel prime units, one in each engine nacelle, which heat the priming fuel enroute to the engines from the selected fuel tank. Each hot fuel prime unit is a compact heater unit, operating similar to the cargo compartment heater, but with the electrical power being supplied from the main bus through the up position of the hot fuel prime switch on the left electrical switch panel. After the circuit has been powered for a few seconds to allow the heaters to reach operating temperature, the heated fuel is fed to the engine by actuating the engine primer switch as appropriate. When both engines are running smoothly, the hot fuel prime switch should be moved to OFF.

Hot Fuel Prime Switch.

The hot fuel prime toggle switch is adjacent to the battery master switch on the left electrical switch panel and is marked HOT FUEL PRIME and OFF

at the up and down position respectively. The switch selects the electrical power to the heater circuit of the hot fuel prime units, and should be moved to the OFF position as soon as both engines have been primed and started through actuation of the engine primer switch.

As a safety measure against the aircraft tipping when loading and unloading cargo, an adjustable limit is supplied as part of the ground equipment. When loading heavy cargo weighing more than 2500 pounds, the steady state should be used. The limit consists of a base plate, a locking nut, and a pin. The assembly incorporating a spring loaded pin is normally stored in a clip at the lock end of the limit. It is used to attach the limit to the anchor fitting on the center console of the fuselage, just forward of the passenger door. Adjust the adjustment of the base plate by means of an adjustment screw. The limit should be set to approximately 15° to suit various ground loads. The pin can be locked in position by turning the lock nut in the direction indicated by an arrow on the plate. Adjustment for height is made by turning the upper portion of the base assembly, and should normally be adjusted so that the base plate is approximately 2 inches off the ground. The limit should be locked in position with the steady state. The limit will pull away from a tight position when the aircraft tips and release from the steady state.

HOT FUEL PRIME SYSTEM

A hot fuel prime system can be installed to facilitate engine starting in ambient temperatures below 32°F (0°C). Below ambient temperatures of 32°F (0°C) engine preheat may be necessary in addition to hot fuel priming. The hot fuel priming system consists of hot fuel prime units, one for each engine nacelle, which heat the incoming fuel before it enters the engine from the selected hot fuel tank. Hot fuel prime unit is a compact heater unit, operating similar to the cargo compartment heater, but with the electrical power being supplied from the main bus through the up position of the hot fuel prime switch on the left electrical switch panel. After the circuit has been powered for a few seconds to allow the heaters to reach operating temperature, the heated fuel is fed to the engine by actuating the engine primer switch as operating. When both engines are running smoothly, the hot fuel prime switch should be moved to OFF.

SECTION V OPERATING LIMITATIONS

TABLE OF CONTENTS

INTRODUCTION	5-1	PROHIBITED MANEUVERS	5-6
MINIMUM CREW REQUIREMENTS	5-1	ACCELERATION LIMITATIONS	5-6
INSTRUMENT MARKINGS	5-1	AIRDROP LIMITATIONS	5-7
ENGINE AND PROPELLER LIMITATIONS	5-1	CENTER OF GRAVITY LIMITATIONS	5-7
ALTERNATE GRADE FUEL	5-6	RAMP LOADING LIMITATIONS	5-7
AIRSPED LIMITATIONS	5-6	WEIGHT LIMITATIONS	5-7
		GROUND PRESSURE	5-11

INTRODUCTION.

This section covers all important limitations that must be observed during normal operation of the aircraft. Certain other limitations that are characteristic only of a specialized phase of operation will be found in their appropriate sections.

NOTE

For ferry configuration limitations refer to Section VII.

MINIMUM CREW REQUIREMENTS.

The minimum crew required to operate this aircraft is a pilot, copilot, and flight mechanic. Additional crew members may be added, as required, at the discretion of the commander.

INSTRUMENT MARKINGS.

Instrument markings are shown in figure 5-1 and give limitations which are not necessarily repeated elsewhere in this manual. Limitations for a specific phase of operation will be found in the text under the appropriate heading.


COLOR CODE CHART.

GREEN	—	NORMAL/AUTO RICH
YELLOW	—	CAUTION
BLUE	—	AUTO LEAN
RED	—	PROHIBITED

ENGINE AND PROPELLER LIMITATIONS.

1. Cylinder head temperatures:
 - a. 80° C minimum for operation above 1200 rpm.
 - b. 150° to 217° C auto lean operation.
 - c. 217° to 245° C auto rich operation (bayonet type thermocouples).
 - d. 80° to 180° C prior to initiating a take-off.
 - e. 180° C maximum for engine shutdown.

instrument markings



AIRSPEED INDICATOR


█ 73-165 KNOTS
(FLAPS 0 /GEAR UP)

█ 208 KNOTS



DE-ICING SUCTION

█ 4-8 IN. Hg NORMAL
█ { 4 IN. Hg MINIMUM
9 IN. Hg MAXIMUM




DE-ICING PRESSURE

█ 14 - 16 PSI NORMAL
█ { 10 PSI MINIMUM
18 PSI MAXIMUM


Figure 5-1 (Sheet 1 of 3)

**OIL PRESSURE**

- █ 45 - 90 PSI. NORMAL RANGE (15 PSI MINIMUM AT IDLE)
- █ { 45 PSI MINIMUM (AT 1400 RPM);
110 PSI MAXIMUM (AT TAKE-OFF)


**OIL TEMPERATURE**

- █ 60° C - 75° C. NORMAL RANGE
- █ { 40° C MINIMUM;
93° C MAXIMUM (AT TAKE-OFF OR DURING CLIMB)

**CARBURETOR AIR TEMPERATURE**

CARBURETOR AIR TEMPERATURE RESTRICTIONS
DO NOT APPLY TO FILTER POSITION WITH HEAT
NOT APPLIED

- █ -10° C + 15° C. UNDESIRABLE CONDITION MAY EXIST
DEPENDING ON ATMOSPHERIC CONDITIONS
- █ -30° C + 38° C. BEST OPERATING CONDITION,
DEPENDING ON ATMOSPHERIC CONDITIONS
(MAXIMUM 38° C. WHEN USING CARBURETOR HEAT)

**FUEL PRESSURE**

- █ 16 - 18 PSI NORMAL RANGE
- █ { 16 PSI MINIMUM;
18 PSI MAXIMUM

FUEL TANK BOOST PUMP
STATIC (NO FLOW) PRESSURE
NORMAL 11 - 17 PSI
HIGH 21 - 27.5 PSI

FUEL GRADE 115/145

Figure 5-1 (Sheet 2 of 3)

TACHOMETER

- SEE 15-20 15APRTS
- 1500 - 2200 RPM AUTO LEAN PERMITTED
 - 2245 - 2310 RPM AUTO RICH REQUIRED
 - 2510 - 2550 RPM AUTO RICH REQUIRED
 - 2195 - 2245 RPM PROHIBITED - EXCEPT PASSING THROUGH
 - 2310 - 2510 RPM PROHIBITED - EXCEPT PASSING THROUGH
 - 2700 RPM MAXIMUM TAKE-OFF (5 MIN LIMIT)




NOTE

UNDER CERTAIN WIND CONDITIONS THE RPM MAY FLUCTUATE ± 25 RPM.

MANIFOLD PRESSURE

- 15 - 33 IN. Hg AUTO LEAN PERMITTED
- 33 - 42.5 IN. Hg AUTO RICH REQUIRED
- 50 IN. Hg MAXIMUM TAKE-OFF AT SEA LEVEL (5 MIN LIMIT)



CAUTION

REDUCE MAXIMUM MANIFOLD PRESSURE 1.0 IN. Hg FOR EACH 10° C BELOW STANDARD CARBURETOR AIR TEMPERATURE

CYLINDER HEAD TEMPERATURE

- BELOW 217° C AUTO LEAN PERMITTED
- 217° C - 245° C AUTO RICH REQUIRED
- 245° C MAXIMUM



SYSTEM HYDRAULIC PRESSURE



3000 $\pm$ 100 PSI

Accumulator Preload
800 - 850 PSI
Emergency Air Bottle Preload
1500 PSI

BRAKE HYDRAULIC PRESSURE



3000 $\pm$ 100 PSI

FUEL GRADE 115/145

Figure 5-1 (Sheet 3 of 3)

2. Oil pressure:
 - a. Idling 15 psi minimum.
 - b. 1400 rpm — 45 psi minimum.
 - c. 2700 rpm — 80 to 110 psi.

ENGINE OVERSPEED.

When engine speed exceeds 3100 rpm the aircraft should be landed as soon as possible and the engine inspected. Removal of the engine is mandatory when rpm exceeds 3300.

NOTE

Momentary overspeed or surge within the 2700 to 3100 rpm range, as a result of abnormally fast throttle movement is permissible without inspecting the engine.

EXCESS MANIFOLD PRESSURE (OVERBOOSTING).

When overboost occurs, combustion temperatures rise. If overboost of sufficient magnitude exists, detonation and pre-ignition may result and cause physical damage to the engine, possibly in a matter of seconds. If at maximum, except Take-Off (METO) RPM or below, any MAP above METO power MAP limit (see Overboost Chart, figure 5-1A) is considered an overboost. If at Take-Off RPM (2700), any MAP above the take-off MAP limit (see Overboost Chart) is considered an

overboost. The time limits for METO or Take-Off overboost are the same and are shown in the Overboost Chart. Overboost conditions represented by the yellow and red areas of the Overboost Chart require maintenance actions and must be carefully recorded on AFTO Form 781 noting (if possible) the manifold pressure, RPM, carburetor air temperature, mixture setting, altitude and duration of the overboost.

ENGINE IDLING.

Engines should idle at a speed of 650 ± 25 rpm.

NOTE

Spark plug fouling will result from prolonged idling below 1000 rpm.

RPM RESTRICTION.


Operation of the engines in the range 2310 to 2510 rpm should be avoided. Climb should be at or below 2300 rpm except where operational conditions require the use of 2550 rpm. Avoiding this rpm range will lessen the possibility of crankshaft failures.

STARTER LIMITATIONS.

First attempted start - 30 seconds on, 60 seconds cooling.

Second attempted start - 30 seconds on, 5 minutes cooling.

OVERBOOST CHART



- NO ACTION REQUIRED.
- MAINTENANCE ACTION REQUIRED MAKE FORM 781 ENTRY.
- MAINTENANCE ACTION REQUIRED, MAKE FORM 781 ENTRY. ENGINE REMOVAL PROBABLE.

REMARKS

IF OVERBOOST CONDITIONS REPRESENTED BY THE YELLOW AND RED AREAS OF THE OVERBOOST CHART OCCUR, DO NOT TAKE OFF, OR IF AIRBORNE, LAND AS SOON AS PRACTICABLE. SHOULD MISSION REQUIREMENTS AND FLIGHT SAFETY DICTATE, CONTINUE OPERATION OF OVERBOOST ENGINE; CONSIDERATION SHOULD BE GIVEN TO REDUCE POWER AND A CLOSE SURVEILLANCE MAINTAINED.

NOTE

THE ABOVE OVERBOOST LIMITS ARE NOT INTENDED IN ANY WAY TO ALLOW OR CONDONE OPERATION OF THE ENGINE AT ANY COMBINATION OF HORSEPOWER, RPM MAP IN EXCESS OF THOSE AUTHORIZED IN THE TABLES AND POWER PERFORMANCE CHARTS OF T.O. 1C-7A-1-1.

WARNING

Figure 5-1A

Third attempted start - 30 seconds on, 30 minutes cooling.

REVERSE LIMITATIONS.

Do not exceed 2700 rpm in reverse range.

ALTERNATE GRADE FUEL.

The recommended alternate fuel is MIL-G-5572, Grade 100/130. The engine operating limits do not change when using alternate fuel.

AIRSPEED LIMITATIONS.

The instrument limit markings (figure 5-1), and other speeds noted in this section, show indicated airspeed values. They are applicable to an airspeed indicator without instrument error.

FLAP LOWERING SPEED LIMITATIONS.

To avoid imposing excessive airloads on the aircraft structure, the following speeds must not be exceeded. These speeds are marked on the limitations label in the flight compartment.

FLAP SETTING (all Engine Powers)	MAXIMUM AIRSPEED IAS - KNOTS
0 - 15°	105
20°	95
30°	85
40°	80

MANEUVERING AIRSPEED.

Maneuvers which involve full application of rudder or aileron must be confined to speeds below 119 knots IAS.

WARNING

The optimum thunderstorm and/or turbulent area penetration speed of 110 knots should be set up prior to entering any suspected storm zone.

NORMAL OPERATING AIRSPEED.

The normal operating airspeed limitation below 10,000 feet is 165 knots IAS. Above 10,000 feet the IAS limitation must be reduced by 3 knots for each 1000 feet increase in altitude.

MAXIMUM AIRSPEED.

The maximum airspeed below 10,000 feet is 208 knots IAS. Above 10,000 feet the maximum IAS must be reduced by approximately 1-knot for each 1000 feet increase in altitude.

LANDING GEAR OPERATING AIRSPEED.

The maximum airspeed for extending or retracting the landing gear, or flying with the gear down, is 120 knots IAS.

RAMP AND CARGO DOOR LIMITATIONS.

DOOR OPEN	120 knots IAS
RAMP DOWN 15°	120 knots IAS

PROHIBITED MANEUVERS.

All aerobatic maneuvers are prohibited. Other prohibited maneuvers are:

1. Steep turns above 60° bank angle.
2. Stall turns.
3. Stalls - Except under certain conditions (refer to Section VI).
4. Abrupt maneuvers involving full control deflection at airspeeds above 119 knots IAS.

ACCELERATION LIMITATIONS.

An operating VG diagram is shown in figure 5-2 and applies from sea level to 10,000 feet. The boundary lines show airspeeds and load factors which must not be exceeded under any circumstances. The maneuver speed line is marked at 119 knots IAS, and is the limit airspeed for maneuvers involving full control deflection. At or below this speed it is impossible to exceed the limit load factors, as the aircraft will stall. Above this speed maneuvers may be performed which do not involve full control movements, provided the limit load factors are not exceeded. Further, it must be remembered that turbulent air or gusts impose g loading on the aircraft structure even in straight and level flight, and this is additional to any loading the pilot is imposing through maneuvers. For this reason, on a gusty day, the aircraft should be slowed down to maneuver speed and pilot

imposed g must be kept to a minimum. Refer to Section VI, for thunderstorm penetration. The dotted area on the VG diagram is the unsafe area, but if entered inadvertently it does not mean that the aircraft will fail structurally at this point. However, operation in this area involves an increasing risks of structural damage.

MAXIMUM ALLOWABLE SINK RATE ON LANDING.**UP TO:**

26,000 lb gross weight - 14 feet per second - 840 feet per minute.

28,500 lb gross weight - 13 feet per second - 780 feet per minute.

31,300 lb gross weight - 10 feet per second - 600 feet per minute.

34,000 lb gross weight - 6 feet per second - 360 feet per minute.

AIRDROP LIMITATIONS.

Airdrop operations are limited by maximum gross weight, center of gravity limits, and floor strength limitations. No unusual flight characteristics will be noted during personnel or equipment drops. By definition, the drop package weight includes the cargo, pallets, parachutes, and all associated equipment that is ejected from the aircraft during the flight.

CAUTION

Airdrops in severe turbulence are not recommended because of the possibility of exceeding structural limits.

Multiple package drops may be made so long as the following limitations are observed:

1. The combined drop package weights must not exceed the maximum allowable single package weight for the particular drop condition under consideration.

2. Subsequent to the drop of any one or more of the packages, the position of the packages remaining in the aircraft must not cause the aircraft CG to move outside of the CG envelop shown in figure 5-3.

CENTER OF GRAVITY LIMITATIONS.

When loading the aircraft, particular attention should be paid to keeping the center of gravity within the prescribed limits, shown on Chart E,

T.O. 1C-7A-5. With the CG at its forward limit the stalling speed of the aircraft is at its highest value. The stalling speeds given in Section VI are with the CG at its forward limit with power for zero thrust. With the CG at its aft limit there is some deterioration in the stall characteristics, although the actual stalling speed is slightly lower. There is no effect on taxiing with the CG at either the fore or aft limits.

RAMP LOADING LIMITATIONS.

Due to the design and size of the ramp operating motor, the ramp is not to be operated while supporting a load.

The total weight bearing capacity of the ramp in any stationary position is as follows:

Ultimate load - 8000 lb
Load per axle - 4000 lb
Distributed load - 6000 lb

For weights exceeding 3500 lb, the steady strut will be used.

NOTE

When the steady strut is not installed, two individuals (one loadmaster plus one additional body) are the maximum number allowed in the cargo compartment aft of loading arm 393 while loading or off loading a single cargo item weighing 3500 pounds. All rolling stock (jeeps, trailers, vans, guns, etc) will be loaded and off loaded with the steady strut installed.

WEIGHT LIMITATIONS.

For maximum permissible weight at which the aircraft can be operated varies, depending on certain weight controlling criteria. The following paragraphs show how the maximum permissible weight is dependent on this criteria.

OPERATING WEIGHT.

The operating weight is the weight which includes the aircraft basic weight plus three crew, full oil, and 780 equipment. Since individual aircraft basic weights vary, it will be necessary to adjust the chart for specific aircraft as shown in the sample problems.

vg diagram

GROSS WEIGHT 28,500 LB ALTITUDE 0-10,000 FT




Figure 5-2

cg limits




Figure 5-3

GROSS WEIGHT.

The maximum permissible gross weight is 28,500 lb. At this weight all airworthiness requirements are met with a margin of safety.

MARGIN OF SAFETY AND LOAD FACTORS.

As an aircraft is loaded to higher weights its ability to withstand additional loads, resulting from turbulent air or maneuvers, decreases proportionately. The amount of additional loading that the aircraft will withstand before failure occurs is termed the margin of safety. If the mission requires excessive maneuvering in turbulent air, a larger margin of safety should be maintained. Load factors are used as an indication of the margin of safety that is available.

PERFORMANCE LIMITATIONS.

In some instances, it may be found necessary to limit the maximum permissible gross weight of the aircraft, not because of structural considerations but because of reduced performance due to the higher weight. (Refer to T.O. 1C-7A-1-1.)

Description and Use of Weight Limitations Chart.

The Weight Limitations chart (figure 5-5) is constructed to provide pilots with useful planning

information. It may be used to determine the maximum cargo that may be carried when the required fuel load is known. It may be used to determine the maximum fuel which may be carried for a given cargo payload and remain within the structural limits of the aircraft. In all instances it must be emphasized that information provided by the Weight Limitation chart does not take into consideration aircraft performance.

WARNING

The Weight Limitations chart is designed to enable the pilot to determine a safe cargo/ fuel loading plan to stay within the structural limitations of the aircraft. For maximum gross weights versus aircraft performance, refer to T.O. 1C-7A-1-1.

Recommended Loading Area.

The green area on the chart represents the loading conditions that present no structural problems in regard to strength of the aircraft. The green area on the chart is defined by the 28,500 lb line (2.6G line) and the 0 fuel line.

ground pressure data

AIRCRAFT WEIGHT	CENTER OF GRAVITY	GROUND PRESSURE PSI*	
		MAIN WHEEL	NOSE WHEEL
OPERATING WEIGHT 21,000 LB	FWD (26% MAC)	39	46
	AFT (39% MAC)	40	45
GROSS WEIGHT 26,000 LB	FWD (31% MAC)	42.5	48
	AFT (39% MAC)	43	48
GROSS WEIGHT 28,500 LB	FWD (31% MAC)	43.5	48
	AFT (39% MAC)	44	48
*BASED ON TIRE PRESSURES OF 35 TO 40 PSI			

Figure 5-4

Cautionary Loading Area

The amber area represents the cautionary loading conditions where the safety margin is reduced. An excess of 2.0 g's can result in possible structural damage if subjected to a gust or maneuver load. Caution must also be exercised because of single engine performance.

Loading Not Recommended.

The red area represents loadings which are not recommended and are to be avoided. Structural limitations of the aircraft are exceeded in this area.

Example Problem No. 1 Aircraft operating weight - 21,500 lb, cargo load required - 4,000 lb. Find maximum wing fuel for 28,500 lb gross weight.

Enter chart with aircraft operating weight, proceed vertically to the 4,000 lb cargo weight line, parallel the guide lines to the base line, proceed horizontally to the right, and intersect the 28,500 lb weight line (2.6G). Proceed vertically down to the wing fuel scale and read the maximum fuel which may be carried to stay within the recommended area, 3,000 lb. If the wing fuel load is known then the Weight Limitations chart can be used to find the maximum cargo load that will not exceed the Zero Fuel Weight Limitation of 28,000 lb.

Example Problem No. 2. Aircraft operating weight - 22,000 lb cargo load required - 7,000 lb.

Find maximum wing fuel for 28,500 lb gross weight.


Enter chart with the aircraft operating weight, proceed vertically to the 7,000 lb. cargo weight line. Notice that this point falls within the red area of the chart; therefore, the Zero Fuel Weight Limitation has been exceeded. The load should be avoided or the cargo weight should be lowered to 5,000 lb. to fall within the green area of the chart.

ZERO FUEL WEIGHT.

The zero fuel weight is defined as the design maximum weight with no disposable fuel, and determines the maximum weight which can be carried in the fuselage. The zero fuel weight is 28,000 lb maximum, and all weight in excess of this figure up to the maximum gross weight of 28,500 lb must consist of fuel for structural reasons. Fuel must be distributed equally on both sides of the aircraft center line.

GROUND PRESSURE.


The ground pressure of the aircraft's wheels on the runway is given in figure 5-4. This data is based on the assumption that the aircraft's tires are inflated to the normal operating pressures.



Note - The speed limitations applicable to an aircraft gross weight of 28,500 lb apply. Limit maneuver load factors between Maximum Speed & Normal Operating Limit Speed are 2.0G and 1.0G. (See also note on limiting of this gross weight) is not recommended. Note - 28,500 lb Design Gross Weight. A speed load factors are described in Fig 5-2. Max fuel on landing - 13,500 (13,500 FPM).

Figure 5-3

WEIGHT LIMITATIONS



- Note - 31,000 lb - The airspeed limitations applicable to an aircraft gross wt of 28,500 lbs apply. Limit maneuver load factors between Maneuvering Speed & Normal Operating Limit Speed are 2.6G and -1.0G. Max sink rate on landing at this gross weight is not recommended.
- Note - 28,500 lb Design Gross Weight. Airspeed load factors are described in Fig 5-2. Max sink on landing -13 FPS (780 FPM)

Figure 5-5

SECTION VI FLIGHT CHARACTERISTICS

TABLE OF CONTENTS

INTRODUCTION	6-1	LEVEL FLIGHT CHARACTERISTICS	6-3
STALLS	6-1	MANEUVERING FLIGHT	6-3
SPINS	6-2	DIVING	6-3
FLIGHT CONTROLS	6-2		

INTRODUCTION.

The aircraft has the following widely diversified mission capabilities: long range ferry, transportation of personnel, cargo, or equipment to remote bases; aerial delivery facilities for personnel, cargo, or equipment airdrops; and short-field take-off and landing characteristics for support and utility operations from small fields and emergency airstrips. In these and other areas of flight operations, including formation and instrument flying, the aircraft has satisfactory flight characteristics.

The aircraft is stable in all configurations. Handling of the aircraft is unaffected when flying with the ramp horizontal and cargo door open. Control is adequate over the entire speed range and the aircraft is controllable down to speeds approaching the stall. Relatively large control surfaces are used to attain this control at low speed. A stall warning system is installed which operated control column shakers at a predetermined margin above the stalling speed in any configuration. The artificial warning system has been incorporated because prestall buffet, in most cases, is not evident.

STALLS.

High lift wings provide very low stalling speeds. As a result, the handling characteristics approaching the actual stall are not identical for all combinations of center of gravity, flap, and power settings. With flaps at 0 or 7 degrees, a fairly heavy buffet occurs about 15 knots above stall, becoming stronger as the stall is approached. Actual stall cannot be obtained with these two configurations when the center of gravity (cg) is

near the forward limit. Stall approaches made under these conditions are characterized by heavy buffet, heavy longitudinal control forces and an increasing sink rate. Aerodynamic buffet is very slight with flaps set at 15 degrees or more, and can only be felt if the stick shaker stall warning system is inoperative. A low intensity stick shaker stall warning system is installed which vibrates both control columns at a predetermined margin above the stalling speed. Should a stall be entered, it is recommended that recovery be made as follows:

1. When a stall is encountered, immediately lower the nose, level the wings, and apply power to limit loss of altitude. Avoid diving the aircraft and abrupt or accelerated pull-up after recovery.

2. Heavy gross weight cruise configuration stalls may be accompanied by lightening of rudder and elevator control forces. Recovery should be made by applying nose down elevator and applying power.

PRACTICE STALLS.

Stall entry and recovery should not be practiced with cargo or passengers aboard. Practice at a minimum altitude of 5000 feet above the ground. Do not delay recovery beyond the point of artificial warning. Avoid abrupt control movements, and avoid any control action that may result in sudden attitude change or in excessive

acceleration or buffeting. For practice stall entry, position gear and flaps as desired and set power for zero thrust.

NOTE

A deliberate approach to the stall for training or demonstration purposes will be terminated at the onset of artificial warning, in all flap and power configurations. The aircraft should be loaded to maintain a mean or forward cg when practice stalls are anticipated.

STALL CHARACTERISTICS.

The aircraft will normally stall straight ahead with little tendency to yaw. Aerodynamic indications of an approaching stall are very slight with flaps set at 15 degrees or higher. However, with flaps up or set at 7 degrees, heavy buffet, heavy longitudinal control forces and a sink rate will be experienced if the center of gravity is near its forward limit. In the mid or aft center of gravity loadings stall can be obtained in all configurations. With power on, there may be a slight rolling tendency at the point of stall. Artificial stall warning is provided by an electrically operated stick shaker system. See figure 6-1 for stall speeds.

SPINS.

Intentional spins are prohibited. If a spin is entered inadvertently, normal recovery procedure for a two-engine aircraft is recommended, i.e., close the throttles, apply full opposite rudder, and ease the control column forward until the spin stops. If the spin does not stop, apply power to the inner engine.

FLIGHT CONTROLS.

Aileron, elevator, rudder, and trim tab control is normal throughout the speed range of the aircraft. The controls are light and effective at all aircraft gross weights, down to the very low speeds at which the aircraft can be flown. The ailerons are effective down to the stall, and lateral control is adequate; larger control movements being required as speed is reduced. With the flaps up, the range of movement of the outer ailerons is 21° up and 16.5° down, while that of the inboard ailerons is only 9.5° up and 5° down. As the flaps are lowered the ailerons droop with the flaps and, in addition, the available range of aileron movement increases. With full flap lowered, the outer ailerons

range is 22.5° both up and down; while the range of the inboard ailerons increases considerably, to 20° up and 14.5° down. This has the effect of heavying-up the aileron controls as the flaps are lowered. However, lateral control is augmented by having the increased aileron surface available at low speeds. At high speeds, with the flaps up, the aileron forces are light and comfortable. The hinged tab on the inboard right aileron is actuated by rudder movement and has the effect of increasing the dihedral and raising the low wing in a sideslip. The geared tabs, one on each outboard aileron, reduce the force which the pilot requires to move the aileron control. The trim tab, on the right outboard aileron, is used to trim the aircraft laterally in flight. The elevator is effective throughout the speed range of the aircraft and to below the stall. Two trim tabs and two spring tabs are fitted to the elevator. The trim tabs are used to trim the aircraft longitudinally during all flight conditions. In addition, longitudinal trim is automatically maintained by an interconnect between the flap mechanism and the horizontal stabilizer when the flaps are operated. The horizontal stabilizer angle of incidence is altered during flap operation to compensate for trim changes incurred by flap movement. The spring tabs move by the initial pilot effort at the control column and lighten the elevator loads. The amount the tabs move, for a given pilot force, varies with airspeed so that less assist is given at the higher speeds. The rudder, due to its relatively large area, is particularly effective at very low speeds and also during asymmetric flight. A geared trim tab and a spring tab are fitted to the rudder. The geared trim tab is used to trim the aircraft about the normal axis, particularly during asymmetric flight. In addition, this tab is geared to the rudder control and reduces the force the pilot requires to move the control. The spring tab operates in a similar manner to the spring tab fitted to the elevator.

WARNING

When operating close to stall speeds with gear extended and flaps full down, such as during short field landings, slipping the aircraft through excessive use of rudder must be avoided. Under these conditions, with the aircraft in a bank, application of top rudder can cause the angle of bank to increase rapidly and uncontrollably unless immediate corrective action is taken to neutralize the rudder and/or increase airspeed.

LEVEL FLIGHT CHARACTERISTICS.

Provided the center of gravity is within the prescribed limits and the aircraft is correctly trimmed, level flight characteristics are smooth and normal throughout the speed range of the aircraft. At 28,500 pounds gross weight with the landing gear extended and 30° flaps, the aircraft can be flown level at 55 knots IAS. When flying the aircraft at slow speeds a large application of the aileron control will be required to maintain wings level. In addition, any lateral displacement should be corrected rapidly, particularly in gusty conditions. If a wing is allowed to drop beyond corrective action of full aileron, power should be increased immediately to regain level flight.

CAUTION

Should the roof hatch open in flight, it can possibly be closed and locked when at a safe altitude by lowering flaps and reducing airspeed. A gentle side slip maneuver will assist in closing the hatch.

MANEUVERING FLIGHT.

Turns should be entered, sustained, and completed with coordinated movements of flight controls. A turn should be entered with sufficient airspeed to insure that an inadvertent stall will not occur. See Stall Speed Chart, figure 6-1. Steep turns, up to 60° bank angle, can be completed without loss of height provided sufficient power and airspeed are attained before entering the turn. Maneuvers which involve full movement of a flight control should be entered at or below an airspeed of 119 knots IAS.

DIVING.

During a dive all flight control pressures increase with airspeed. Use normal recovery methods from a dive and do not exceed the airspeed limitations given in Section V. Avoid abrupt pull-ups at all times.

STALL SPEED CHART STALL SPEEDS VS ANGLE OF BANK

MODEL: C7-A
DATE: APRIL, 1970
DATA BASIS: ESTIMATED

- CONDITIONS:
1. POWER OFF
2. CG-FORWARD LIMIT
3. OUT OF GROUND EFFECT

ENGINE(S): (2) R-2000
FUEL GRADE: 115/145
FUEL DENSITY: 6.0 LB/GAL




Figure 6-1

SECTION VII SYSTEMS OPERATION

TABLE OF CONTENTS

INTRODUCTION	7-1
POWER PLANT AND RELATED SYSTEMS	7-1
PROPELLER REVERSING	7-3

FUEL MANAGEMENT.....	7-4
WHEEL BRAKES	7-12

INTRODUCTION.

The descriptions and operating instructions contained in this section are for systems which are peculiar to this aircraft or systems that require emphasis. In some cases the information given overlaps that given in the general description of the system concerned. In other cases, instructions are given which do not appear elsewhere in the manual.

POWER PLANT AND RELATED SYSTEMS.

EXHAUST SYSTEM AND ENGINE COOLING.

The exhaust gases from each engine pass from two groups of four exhaust pipes into augmentor tubes and are directed rearward over the upper surface of the root flaps. An open space exists between the exhaust stacks and the mouth of the augmentor tubes. When the engine is operating, exhaust gas is ejected from the stacks into the augmentors and the force of the exhaust creates a partial vacuum at the mouth of each augmentor, causing air that has entered the engine section around the propeller hubs to rush into the augmentors. This action continuously draws cooling air across the engine, in addition to the normal ram airflow. The augmentor cooling air is automatically proportioned to the power setting at all times, and this is an advantage when climbing with high power and low forward speed. The action of the high velocity exhaust gases through the augmentors gives a jet thrust effect which provides some positive thrust power at low airspeeds and high power settings. The thrust is considered sufficient to eliminate cooling drag.

DETONATION.

Common causes of detonation are: low octane fuel, lean fuel/air mixture, excessive manifold pressure, excessively high carburetor air temperature, excessive cylinder head temperature, advance timing, or operating with only one spark plug firing in a cylinder. Detonation may result in damage to the engine such as overheated, burned, stuck, or broken pistons, rings or valves; scored pistons and cylinder; overstressed or broken cylinder hold down studs. When detonation is suspected, the operator should immediately reduce manifold pressure and rpm, enrich the fuel air mixture and reduce carburetor air temperature to the lowest temperature possible within the operating range.

POWER SETTINGS.

It is important to cushion the high inertia loads on the master rod bearings which occur at conditions of high rpm and low manifold pressure. If a large reduction in power is necessary during descent, reduce rpm as well as manifold pressure. It is recommended that for each 100 rpm at least 1 in. Hg manifold pressure be maintained. Operation at high rpm and low manifold pressure should be kept to a minimum.

CARBURETOR TEMPERATURE.

The carburetor air temperature gages register the temperature of the air in the carburetor air intake ducts of the engines. The instrument markings shown in Section V for these gages do not attempt to show a definite temperature at which carburetor

heat should be used. Atmospheric conditions conducive to carburetor icing, together with the air temperature, must be taken into account when deciding upon the use of carburetor heat. The following paragraphs discuss icing conditions, and will aid in this decision.

CARBURETOR ICING.

The following atmospheric conditions contribute to carburetor icing:

1. Visible freezing or subfreezing moisture which forms ice in the air intake, and in and on the carburetor metering elements.
2. High atmospheric humidity with a carburetor air intake temperature below $+3^{\circ}\text{C}$ forms ice on the throttle valve at partial throttle opening.
3. High atmospheric humidity with a carburetor air intake temperature below $+10^{\circ}\text{C}$ forms ice in the region between the carburetor and the impeller.
4. Severe low temperature conditions, when the aircraft is exposed for many hours, can lower the fuel temperature to a point where it will cause icing in the internal passages of the carburetor during subsequent operation in a high humidity atmosphere. This condition is not likely to occur when the temperature of the fuel entering the carburetor is at or above 0°C .

Indications of carburetor icing generally appear as follows:

1. Decrease in thrust is evidenced by a drop in manifold pressure and/or thrust indicator readings.
2. Erratic engine operation due to ice on the metering elements.
3. Drop in cylinder head temperature.
4. In some cases jamming of the throttle valve is evidenced by erratic response of manifold pressure to throttle lever positioning.

If carburetor icing conditions are anticipated or suspected, apply carburetor heat to maintain $+15^{\circ}\text{C}$. The use of carburetor heat for the

prevention of ice, and the consequent loss of power in a high-moisture atmosphere, is most effective if applied and maintained in advance of encountering these conditions.

Carburetor heat can be applied with mixture control in AUTO LEAN.

If it is suspected that ice has already formed in the carburetor, move the mixture lever to auto rich and apply full carburetor heat for 30 seconds, but do not exceed $+38^{\circ}\text{C}$ carburetor air temperature. Slowly return the carburetor heat lever toward COLD to see if manifold pressure has been restored to nearly its former indication. Adjust preheat to maintain $+15^{\circ}\text{C}$ carburetor air temperature.

If the temperature of the fuel is well below freezing during icing conditions, a rapid loss of power due to mixture control bleed icing may occur. The use of maximum heat and a lean mixture, if in the cruise range, should restore the normal power condition.

SPARK-PLUG FOULING.

Spark-plug fouling is usually caused by a build-up of lead or carbon deposits which cause shorting at the plugs. Grade 115/145 fuel contains a relatively high lead content and under certain conditions of temperature and pressure the lead will condense out on the spark-plug electrodes. In the presence of excess carbon as a reducing agent, the lead may form metallic particles which cause misfiring, or prevent firing, across the plug electrodes. In general, spark-plug fouling involves a build-up of deposits through prolonged operation under a fixed set of conditions. If action is taken to vary these conditions, improved ignition will result. The following preventive measures may be taken:

1. After each ten minutes of ground running, the engine should be run at field barometric manifold pressure for one minute.
2. Cylinder head temperature should be below 180°C prior to the take-off in order to take advantage of the increased bhp. There will also be less tendency for misfiring with a relatively cool cylinder head temperature during take-off.
3. During cruising flight a periodic change in engine conditions should be made. This may be done at hourly intervals by either using auto-rich

mixture for five minutes, changing manifold pressure by 3 to 5 in. Hg, or changing propeller speed by 100 to 130 rpm. A reduction in power level, followed by an increase, is recommended.

4. If practicable, use cruise power settings during descent.

DEFOULING (CLEANOUT) PROCEDURE.

If and unacceptable magneto check occurs and the spark plugs are known or suspected to be in a fouled condition, the following spark plug cleanout procedure is recommended.

1. Mixture - RICH.
2. Propeller - FULL INCREASE.
3. Slowly advance throttle levers to obtain field barometric pressure.
4. Maintain this setting for one minute.

CAUTION

During this time do not allow cylinder head temperature to exceed 245°C.

5. Recheck magneto.

NOTE

If above procedure is not effective repeat one time with mixture in LEAN position.

PROPELLER REVERSING.

The reversible pitch propeller is a valuable feature which, when properly used, increases safety and utility of the aircraft. However, it is important to point out the undesirable consequences which result from improper use of this device. When the throttles are placed in the reverse pitch range, the engine continues normal operation, but with this significant exception; the direction of airflow to the engine cooling passages is reversed, the augmentors no longer regulate the airflow through the engine as effectively as in forward thrust operation, and increased temperatures develop around the engine.

The undesirable effects of continued reverse pitch operation does not register immediately on the engine instruments. The cylinder head temperature does not rise alarmingly as the reverse heat capacity permits the bulkier portions of the engine to absorb heat without appreciable temperature increase. The use of propeller reversing to brake the landing roll does not result in critical temperature conditions. the cooling-off during approach, the forward motion of the aircraft, and the relatively short interval of reverse pitch operation serve to keep the temperature below the damaging level. Reverse pitch operation will not damage the engine unless it is sustained over extended periods. It is recommended that reverse thrust be employed for braking and only such other conditions as are absolutely required.

PROPELLER CHECK FOR REVERSE PITCH OPERATION.

Occasionally, propellers do not return to forward pitch after reversing. To insure that the propellers have returned to forward pitch after reverse thrust operation, watch for a surge in rpm as propellers are unreversed, and an indication of positive thrust on the thrust indicators. If there is any doubt that the propellers have returned to forward thrust, immediately depress the propeller feathering button and watch for a drop in rpm. A rise in rpm indicated that the propeller is still in reverse pitch. If rpm begins to rise, the propeller may be returned to forward pitch by waiting until the rpm subsequently begins to fall before returning the feathering button to the neutral position.

If the propeller is in reverse and cannot be returned to forward pitch due to increase pitch solenoid failure proceed as follows:

- a. Return throttle to forward range.
- b. Move propeller lever for the affected engine to "Full DECREASE".
- c. Disengage gustlock and check carburetor air in filter position.
- d. Slowly add power on affected engine.
- e. Monitor the thrust meter on that engine. At approximately 1500 to 1800 rpm, the propeller will move to forward pitch, evidenced by

a sudden increase in thrust meter reading up to approximately 6.5.

FUEL MANAGEMENT.

The fuel system crossfeed may be used to supply both engines from either tank or, during single-engine operation, one engine from either tank. During flight on one engine, fuel should be used alternately from each tank in order to maintain the weight of fuel on each side approximately equal. However, in the event of a fuel malfunction, the aircraft can be trimmed with a full tank on one side and minimum fuel on the other side. Prior to making crossfeed selection the boost pump of the selected tank should be switched to HIGH, the fuel pressure gage on that side should then read approximately 20 psi. The boost pump in the tank not to be used should be turned off.

After the crossfeed selection has been made, if supplying both engines, both fuel pressure gages should read approximately 20 psi. Two minutes should be allowed for the system to rid itself of any trapped air and the boost pump then switched to NORMAL. Whenever crossfeeding fuel, the boost pump of the selected tank should remain in the NORMAL position.

Prior to returning to the normal fuel selection, the boost pump of the tank not being used should be switched to NORMAL. After tank selection has been made, two minutes should be allowed for the system to rid itself of trapped air. At the pilot's discretion, boost pumps may then be switched off.

In addition to using the boost pumps for engine starts, take-offs, climbs, landings, and fuel crossfeeding, they should also be used in flight whenever fuel pressure fluctuates within normal operating limits (16 to 18 psi), for flights above 10,000 feet, and in the event of engine-driven fuel pump failure.

WARNING

Loss of the main dc bus when a boost pump is being used to replace an inoperative engine driven fuel pump will result in fuel starvation of that engine.

NOTE

Maximum fuel differential between wings is 600 pounds (excluding ferry mission).

LONG RANGE FERRY FUEL AND OIL SYSTEM.

Additional fuel and oil necessary for long range ferry flights may be carried in special tanks installed in the cargo compartment. The package assembly consists of one or two auxiliary fuel tanks, and one auxiliary oil tank. Each fuel tank has a capacity of approximately 480 gallons and the oil tank has a usable capacity of 18 gallons. Each fuel tank is secured in position by tiedown straps. The oil tank is bolted to the floor on the right side of the cargo compartment. A fuel control panel is secured to the left side of the cargo compartment forward of the emergency hatch. A fuel level control valve is incorporated in cell No. 5 of each wing tank.

AUXILIARY FUEL TANKS.

The two auxiliary fuel tanks are constructed of flexible 4-ply rayon tire cord reinforced rubber, with an inner liner of Buna N compound. They are 68 inches long and 58 inches in diameter. Inside the tank are two flexible hoses, one a vent hose and the other a fuel hose. A float is attached to the vent hose, and a filler screen assembly is clamped to the fuel hose. The filler assembly will remain on the bottom of the fuel tank during and after refueling.

During operation the tanks are pressurized to a regulated 5 psi, the pressure is supplied by the deicer boot pumps or by a manually operated pump which must be carried aboard the aircraft. This pressure is used to transfer the fuel from the auxiliary fuel tanks to the wing fuel tanks (see figure 7-2). A sight gage, consisting of transparent tubing marked from 50 to 500 gallons, on each fuel tank gives an approximate visual indication of fuel in each tank. The auxiliary tanks are connected by flexible hose directly to the control panel for purposes of refueling, defueling, and transfer to the main tanks. Any excess pressure in the tanks can be vented manually to atmosphere through the control panel. An additional pressure relief valve is installed to automatically relieve pressure at 6 psi.

AUXILIARY OIL TANK.

The auxiliary oil tank is clamped in a metal cradle and the cradle is bolted to the cargo compartment floor utilizing 5000 pound cargo tie-down rings at positions D3 and D5, and the lower seat support rail on the right side of the aircraft. The oil tank has a sight gage, marked with a red line indicating the half full condition. The two low oil level amber lights, one for each engine oil tank, are used to indicate when oil transfer should be made. A hand-operated rotary pump and a transfer valve assembly with positions marked OFF, LH, and RH controls oil transfer to the appropriate side engine. The auxiliary oil tank is vented to atmosphere.

FUEL MANAGEMENT PANEL.

The auxiliary fuel management panel (figure 7-1) incorporates a pressure regulator, a pressure gage, and a total of eight valves. The valves are: rear tank selector valve, forward tank selector valve, left and right wing tank shut-off valves, de-icer pressure shut-off valve, vent shut-off valve, pressure relief valve, and refuel vent valve. The two auxiliary tank selector valves have the following positions:

CAUTION

When cross-feeding fuel from one auxiliary tank to both main tanks insure that the tank selector valve of the empty auxiliary tank is OFF. Loss of air pressure and failure to transfer will result if the selector valve of the empty tank is in any other position.

1. OFF.
2. TRANS - Allows fuel to flow from the auxiliary tank to the associated wing tank, i.e., forward auxiliary tank fuel flows to the right wing tank, rear auxiliary tank fuel flows to the left wing tank.
3. XFEED - Allows fuel to flow to both wing tanks from one auxiliary tank (other auxiliary tank OFF).
4. REFUEL - Allows the auxiliary tank to be refueled.

The appropriate wing tank shutoff valve must be open during fuel transfer to the particular wing tank, and closed at all other times.

A short length of transparent flexible tubing is located beneath each fuel selector valve. The tubing allows visual indication of fuel flow, but only when air bubbles are present in the line.

NOTE

Because fuel is transferred from the auxiliary tanks to the wing tanks, and not directly to the engines, the standard wing tank gages in the flight compartment, are used for fuel management.

AIR PRESSURE CONTROL.

Air pressure to the auxiliary tanks is controlled at the auxiliary fuel control panel in the cargo compartment when the wing and tail mode switch (figure 4-5) on the copilot's deicing panel is on and pressure is available. The following controls are shown on figure 7-1.

Deicer Pressure Shut-off Valve.

This valve must be ON during fuel transfer to supply air pressure to the auxiliary fuel tanks, and during descent, to preclude collapse of the auxiliary tanks. At all other times the valve must be OFF. When fuel is not being transferred the valve should be OFF.

Vent Shut-off Valve.

This valve is used to relieve excess air pressure in the auxiliary tanks.

Pressure Regulator.

This regulator is normally preset on the ground to obtain a 5 psi reading on the pressure gage. It may be adjusted in flight to obtain this pressure, if necessary.

Pressure Gage.

This gage registers the air pressure delivered to the auxiliary tanks from the pressure regulator.

ferrying system control panels -typical





Figure 7-1

long range ferry fuel system - schematic



NOTE: NORMAL FUEL TRANSFER SHOWN

Figure 7-2

Pressure Relief Valve.

This valve will relieve air pressure in excess of 6 psi, to atmosphere.

Refuel Vent Valve.

This valve has positions marked OFF, FWD, BOTH and REAR. When refueling the auxiliary tanks the valve must be selected to the appropriate tank or tanks being refueled. This will allow the displaced air to escape to atmosphere. At all other times the valve must be OFF.

FUEL LEVEL CONTROL VALVE.

A fuel level control valve is installed in cell No. 5 of each wing tank to prevent overfilling when fuel is transferred from the auxiliary tanks. Before fuel is transferred, the level of fuel in that wing tank must first be lowered below the control valve level, i.e., 1550 pounds (258 gallons).

FIRE EXTINGUISHER.

A hand-operated fire extinguisher of sufficient capacity to combat a petroleum fire is attached to the auxiliary oil tank.

REFUELING THE AUXILIARY TANKS.

The auxiliary fuel tanks should be refueled from a pressurized fuel supply to assure complete servicing. The hose is routed from outside through the emergency hatch.

FERRY TANK OPERATION.

The following procedures should be followed when using the long range ferry system. The checks and procedures are additional to those given in Section II.

Preflight Checks.

WARNING

Smoking is not allowed in the aircraft at any time when ferry system is installed.

The following checks should be considered as additional items to the normal interior inspection:

1. Check for any sign of fuel leakage in the ferry system and the cargo compartment.

WARNING

Fuel sight-gages give only approximate quantity readings. Consequently, the refueling operation must be monitored closely so that the actual amount of fuel pumped into the tanks can be verified.

2. Check the sight gages for approximate quantity of fuel in each auxiliary fuel tank and oil in the auxiliary oil tank.

NOTE

The top of the sight gage, between the vent connection in the tank and the top of the tank, should be full of air with the remainder of the sight gage full of fuel. Tapping the tank with a blunt object will also locate the level of fuel in the tank.

3. Check that the oil transfer valve is OFF.
4. Check all auxiliary fuel tank tie-down straps for security and tension.
5. Check that the air pressure in the auxiliary fuel tanks, is between 1 and 2 psi. Pressure in excess of 2 psi should be vented. When the required pressure is obtained, turn the vent shutoff valve OFF.
6. Check all auxiliary fuel and oil valves are OFF or CLOSED, as applicable.
7. Check propeller and wing and tail deicing mode switches are OFF.

Engine Start.

1. Start the engines normally, using the wing tanks.
2. Check the deicing suction gage for normal suction of 4 in. Hg.

NOTE

A deicer pump is operated by each engine, and each pump supplies enough pressure for simultaneous deicing and fuel transfer. The above check, with

both engines operating, does not constitute a check of both pumps. Each pump must be checked individually, preferably by checking one pump during engine shut down and the other during engine start.

Take-Off.

The take-off is made using the normal wing tank selection. The deicing mode switch should be OFF unless wing deicing is required.

INFLIGHT FUEL CONTROL.

For inflight fuel transfer, proceed as follows:

1. After level-off feed both engines from left tank in accordance with fuel management procedures this section. When fuel in LH tank reaches 1000 pounds, change fuel selector to feed both engines from right hand tank in accordance with fuel management procedures.

NOTE

Since accurate fuel gages are not available for auxiliary tanks, engines should be operated from one main tank while the opposite main tank is being filled. This will enable the pilot to determine the amount of fuel transferred and will provide the best means of keeping track of fuel consumption and remaining fuel onboard. Transfer fuel from forward auxiliary tank first to obtain the most favorable CG for cruising flight. Check rear tank transfer on second sequence to assure proper operation prior to depleting forward tank.

2. Select the deicing mode switch (figure 4-5) to MAN. Check deicing pressure.

3. Select the controls on the ferrying system fuel management panel (figure 7-1) as follows:

- a. Rear tank selector valve - OFF.
- b. Forward tank selector valve - XFEED.

c. Right wing tank shut-off valve - CLOSED.

d. Left wing tank shut-off valve - OPEN.

e. Vent shut-off valve - OFF.

f. Refuel vent valve - OFF.

g. Deicer pressure shut-off valve - ON.

h. Pressure regulator - Adjusted to 5 psi.

4. When transfer stops at the fuel level control valve setting (approximately 1550), return deicing mode switch (figure 4-5) to OFF.

5. Continue feeding both engines from RH tank until fuel level is 1000 lb.

6. Feed both engines from LH tank.

NOTE

When adjusting fuel panel configuration from both engines RH tank to both engines LH tank, place the boost pump switch of the LH tank to NORMAL, place fuel tank selector switch to NORMAL and allow two minutes for the system to rid itself of trapped air. Proceed with fuel management procedures this section. Avoid proceeding directly from both engines RH tank to both engines LH tank without the two minutes delay with fuel tank selector switch in NORMAL for two minutes. This will preclude loss of power from both engines simultaneously in the event of trapped air in the system.

7. Reverse procedure by selecting the controls on the ferrying system fuel management panel (figure 7-1) as follows:

a. Rear tank selector valve - XFEED.

b. Forward tank selector valve - OFF.

c. Right wing tank shut-off valve -
OPEN.

d. Left wing tank shut-off valve -
CLOSED.

e. Vent shut-off valve - OFF.

f. Refuel vent valve - OFF.

g. Deicer pressure shut-off valve -
ON.

h. Pressure regulator - Adjusted to 5
psi.

8. When right main tank has filled to 1500 lb (or fuel level control valve shutoff point) repeat procedure to fill left tank while operating both engines on the right main tank. Alternate transfer from forward and aft bladders as necessary to maintain optimum CG.

NOTE

A designated crew member will maintain a log of fuel transferred for use in fuel log entries and in determining fuel consumption rate.

COMPLETION OF FUEL TRANSFER.

When transfer of fuel is completed from either or both auxiliary tanks, prevent buildup of air pressure in the wing tanks by selecting the controls on the fuel management panel (figure 7-1) as follows:

1. Wing tank shut-off valves - CLOSED.

2. Auxiliary tank selector valves - OFF.

3. Deicer pressure shut-off valve - OFF.

4. Deicing mode switch (figure 4-5) - OFF (unless required for deicing.)

FUEL CROSSFEED.

To crossfeed fuel from one auxiliary tank to both main tanks, select the controls on the ferrying

system fuel management panel (figure 7-1) as follows:

1. Left and right wing tank shut-off valves - OPEN.

2. Forward tank selector valve - XFEED
rear tank selector valve - OFF (if transferring from fwd tank).

OR

Rear tank selector valve - XFEED
forward tank selector valve - OFF (if transferring from rear tank).

3. When both auxiliary fuel tanks are empty, or ferry fuel ceases to be a requirement, select the switches and controls as directed in completion of fuel transfer.

AIR PRESSURE CONTROL.

While descending from altitude, maintain 2 psi air pressure in the auxiliary tanks to prevent the flexible tanks from collapsing. After landing, select the deicing mode switch (figure 4-5) to OFF.

INFLIGHT OIL SUPPLY.

The normal engine oil supply is used until a low oil level warning light, illuminates steadily. This indicates that approximately 11.4 gallons of oil remain in that oil tank. Transfer oil from the auxiliary tank as follows:

1. Auxiliary oil tank valve - Select appropriate tank.

2. Turn the handpump approximately 175 turns until the oil level reaches red line on the auxiliary oil tank sight gage.

3. When the other engine low oil level warning light comes on, transfer the remaining oil in the auxiliary tank to the affected main tank.

NOTE

Additional oil may be carried aboard the aircraft to reservice the auxiliary oil tank.

OPERATING LIMITS.

When long range ferry tanks are installed in the aircraft the following operating limitations must be observed, in addition to the applicable limitations specified in Section V.

NOTE

Operation above a gross weight of 28,500 pounds is permissible only for ferry operations and required Major Air Command approval. The maximum gross weight for ferry configuration is 34,000 pounds for take-off.

CAUTION

Avoid high speed taxi operation and unsymmetric braking to prevent excessive side loads on the nose gear.

Weight.

The gross weight at which the aircraft may be operated with Major Air Command authority is as follows:

1. Gross weight

Ramp weight 34,000 lb.
Take-off (sea level) 34,000 lb.
Landing (sea level) 31,300 lb.

NOTE

Take-off gross weight may be further limited by operational factors such as temperature, altitude, and available runway length. The extent of the limitation required may be determined by the responsible authority in the light of performance data contained in T.O. 1C-7A-1-1.

2. Zero wing fuel weight - 29,200 lb.

Center of Gravity.

At weights above 28,500 pounds the aircraft CG must be maintained between 31% and 39% MAC (wheels down).

Take-Off.

Take-off at gross weights above 28,500 pounds requires a smooth paved runway and zero wing flaps.

Emergency Operation.

Emergency Procedures. At a gross weight of 34,000 pounds the airplane will climb at 17 feet per minute at sea level, 0° flaps, maximum power, and propeller feathered on inoperative engine.

Should an engine failure occur during take-off or in flight an emergency landing should be made at once, straight ahead. No attempt should be made to burn off fuel. The aircraft structure and landing gear are adequate to sustain a carefully executed landing at 34,000 pounds.

WARNING

There is no provision for jettisoning auxiliary tanks or fuel.

A go-around should not be attempted, since the aircraft performance is extremely marginal at 34,000 pounds. The airspeed should be maintained at 92 knots IAS, and the flaps should not be lowered until the airplane is on the ground. The landing gear should be lowered at the pilot's discretion and only when the landing is assured. After landing use aerodynamic braking during the initial ground roll and use brakes as sparingly as possible.

WARNING

Since the aircraft performance is extremely marginal at 34,000 pounds, the crew should prepare for a crash landing or bail-out, if an engine failure occurs during take-off or in flight.

Allowances should be made for non-standard conditions of temperature and humidity, turbulence, and variations in the performance of individual aircraft.

Oil Dilution System. (Refer to Section IX.)

WHEEL BRAKES.

The proper use of the wheel brakes is emphasized in order to reduce accidents due to brake failure and cut down maintenance work. To minimize brake and tire wear, the following precautions should be observed:

1. Use extreme care when applying brakes immediately after touchdown, or at any time when there is considerable lift on the wings, to prevent skidding the tires and causing flat spots. A heavy brake pressure can result in locking the wheels more easily if brakes are applied immediately after touchdown than if the same pressure is applied after the full weight of the aircraft is on the wheels. A wheel once locked in this manner immediately after touchdown will not become unlocked as the load is increased, as long as brake pressure is maintained. Proper braking action cannot be expected until the tires are carrying heavy loads.

2. If maximum braking is required after touchdown, lift should be decreased as much as possible by raising the flaps and lowering the nosewheel to the ground before applying brakes. This procedure will improve braking action by increasing the friction between the tires and the runway.

3. For short landing rolls the most effective braking is obtained by repeated intermittent use of maximum brake for periods not to exceed one full second, followed by a momentary release period.

4. It is recommended that a minimum of 15 minutes elapse between landing, where the landing gear remains extended in the slipstream, and a minimum of 30 minutes between landings where the landing gear has been retracted, to allow for cooling if brakes are used for steering, crosswind taxiing operation, or if a series of landings are performed.

5. The full landing roll should be utilized to take advantage of aerodynamic braking and brakes should be used as little and as lightly as possible.

6. After the brakes have been used excessively for an emergency stop and are in a heated condition, the aircraft should not be taxied into a crowded parking area or the parking brake set. Peak temperatures occur in the wheel and brake assembly from 5 to 15 minutes after a maximum braking operation.

7. The brakes should not be dragged when taxiing, and should be used as little as possible for turning the aircraft on the ground.

EFFICIENCY OF BRAKES.

Brakes themselves can merely stop the wheels from turning, but stopping the aircraft is dependent upon the friction of the tires on the runway. It has been found that optimum braking occurs with approximately a 15 to 20 percent rolling skid, i.e., the wheel continues to rotate but has approximately 15 to 20 percent slippage on the surface so that the rotational speed is 80 to 85 percent of the speed which the wheel would have were it in free roll. As the amount of skid increases beyond this amount, the coefficient of friction decreases rapidly so that with a 75 percent skid the friction is approximately 60 percent of the optimum and, with a full skid, becomes even lower. There are two reasons for this loss of braking effectiveness with skidding. First, the immediate action is to scuff the rubber, tearing off small pieces which act almost like rollers under the tire. Second, the heat generated starts to melt the rubber and the molten rubber acts as a lubricant, NACA figures have shown that for an incipient skid with an approximate load of 11,000 pounds per wheel, the coefficient of friction on dry concrete is as high as 0.8, whereas the coefficient is in the order of 0.5 or less with a 75 percent skid. Therefore, if one wheel is locked during application of brakes there is a definite tendency for the aircraft to turn away from that wheel and further application of brake pressure will offer no corrective action. Since the coefficient of friction goes down when the wheel begins to skid, it is apparent that a wheel once locked, will never free itself until brake pressure is reduced so that the braking effect on the wheel is less than the turning moment remaining with the reduced frictional force.

SECTION VIII CREW DUTIES

TABLE OF CONTENTS

INTRODUCTION	8-1	LOADMASTER	8-2
PILOT	8-1	LOADMASTER'S CHECKLIST	8-2
COPILOT	8-1	PASSENGER BRIEFING CHECKLIST	8-5
FLIGHT MECHANIC.....	8-1		

INTRODUCTION.

Each flight crew member has duties other than the main duties covered in NORMAL PROCEDURES, Section II. These additional duties are prescribed in this Section.

PILOT.

Insures that a thorough inspection of the aircraft and all equipment is properly conducted. (The checklists for the pilot are covered in detail in Sections II and III.) Plans the mission by analyzing information concerning its nature, the expected weather over the mission route, and special instructions. Prepares or supervises the preparation of the flight plan and clearance. Supervises and coordinates the activities of the crew members during flight planning and preparation. Inspects, or supervises the inspection of the aircraft. Determines that the weight and center of gravity are within prescribed limits. Insures that the troops and passengers have been briefed. Insures inspection of all items of bailout, ditching, and survival equipment. Assigns the employment of navigational and communications equipment to the copilot. Coordinates the activities of crew members and airborne personnel in paradrops of cargo or personnel. Insures that required flight logs, records, and maintenance forms are prepared.

COPILOT.

Assists pilot in planning mission by obtaining pertinent weather forecasts, intelligence reports,

maps, and other documents. Upon instructions from pilot, assists in plotting the mission route and calculating the route information and fuel requirements. Assists the loadmaster in determining the cargo distribution and in computing the center of gravity of the aircraft. Assists the pilot in insuring that the exterior and interior inspections of the aircraft are completed, and performs additional inspections when instructed to do so by the pilot. Assists the pilot in operating controls and equipment on the ground and in flight. Prepares the flight log and required records and maintenance forms. Operates the communications equipment and assists the pilot in navigating the aircraft.

FLIGHT MECHANIC

Operates system controls. Controls cabin air to provide proper cabin ventilation and temperature. Reports condition of engines and cargo compartment to the pilot after every take-off. Operates engine and control devices. Monitors tachometers and manifold pressure gages and reports unusual conditions to pilot. Monitors circuit breakers, temperature and pressure indicators, and electrical voltage and loads. Observes warning lights and fire detection indicators. Reports abnormal conditions to pilot and recommends corrective action. Computes aircraft weight and balance and performs preflight and postflight inspections. Inspects engines for general condition and for absence of fuel leaks. Ascertains that temperatures have not exceeded

limits. Assists the pilot in troubleshooting malfunctions. Visually checks gear down prior to every landing and reports any abnormal condition to the pilot. In the absence of qualified personnel, supervises the maintenance of the aircraft in general and performs servicing operations. Assigns repair work to ground crew members; reviews work for completeness and accuracy. Instructs subordinates in flight mechanic procedures.

LOADMASTER.

The duties in the checklist below will be delegated to the loadmaster by the pilot. The loadmaster will monitor the interphone as directed after the STARTING ENGINES checklist. When a loadmaster is not specifically designated as a crew member his duties will be accomplished by the flight mechanic.

LOADMASTER'S CHECKLIST.

PRIOR TO ENTERING

1. Wheel chocks
2. Static Ground Wire
3. External power
4. Gear locks

INITIAL PREFLIGHT

1. Form 781

Check the 781, for status of aircraft and aircraft discrepancies.

2. Weight and balance handbook

Check the last entry in chart C and use in preparation of DD Form 365F.

3. Load adjuster

CARGO COMPARTMENT

1. Crash axe
2. Static line retriever
3. Anchor cables
4. Stowage compartments
5. Pendulum release system
6. Tiedown devices

In place

In place

As required

Installed

Checked

Checked

Checked

Installed

Checked/Stowed

Installed/Checked

Checked for proper contents

Checked/As required

Quantity and condition

7. Seat and seat belts	Check condition/Installed, as required
8. Cargo floor/rollers	Checked/Rollers installed, as required
9. First aid kits	Checked
10. Entrance doors	Checked
11. Ramp door and controls	Checked
12. Utility light	Secured
13. Ground loading ramps	Checked/Secure
14. Fire extinguisher	Checked
15. Relief tube	Checked/Secure
16. Steady strut	Checked
17. Headset	Installed
POWER ON	
1. Interphone	Checked
2. Troop jump lights	Checked
3. Static line retriever	Checked
4. Pendulum release system	Checked
5. Ramp and door	As required
PRIOR TO LOADING	
1. Load planning	Completed
2. Cargo doors and ramp	As required
3. Steady strut	As required
4. Manifests	Checked
5. Cargo inspection	Complete
LOADING	
Refer to T.O. 1C-7A-9, AFM 71-4, and other appropriate publications for handling and loading instructions.	

AFTER LOADING

1. Steady strut
2. Cargo door and ramp
3. Loose equipment
4. Cargo
5. Load tie-down
6. Manifests and Form 365F

Removed/Stowed

As required

Stowed

Check for fumes or leaks

Completed/Checked

Submit to pilot

ENGINE START, TAXI, AND ENGINE RUNUP

1. Ramp and doors
2. Monitor cargo compartment for fluid leaks
3. Observe lower side of wings and engine nacelles for leaks, etc

Closed/As required

BEFORE TAKE-OFF

1. All exits
2. Tie-downs
3. Seat belts

Secure

Checked

Fastened

AFTER TAKE-OFF

1. Wings and nacelles
2. Cargo

Scanned

Checked for security

IN FLIGHT

1. Scan wings and nacelles and report any abnormal indications to the pilot.
2. At least once each hour check complete cargo compartment for leaks, securing of passengers, etc

DESCENT

1. Passengers
2. Cargo

Briefed

Checked

BEFORE LANDING

1. Visually check main landing gear
2. Seat belts

DOWN/Index marks aligned

Fastened

ENGINE SHUTDOWN

1. Exit clearance
2. Wheel chocks
3. Gear locks

On command of pilot

In place

Installed

OFF-LOADING

1. Cargo door and ramp
2. Steady strut

As required

As required

BEFORE LEAVING AIRCRAFT

1. Cargo compartment
2. Steady strut
3. Cargo door and ramp
4. Equipment
5. Form 781

Cleaned

Stowed

Closed

Stowed

Completed

PASSENGER BRIEFING CHECKLIST.

Prior to blocktime, a crew member will brief passengers on the following items as applicable to the mission being flown.

PRE DEPARTURE

1. Crew, route, times, weather, and altitude
2. Seats and safety belts

All passengers should have a seat with a complete seat belt and should be briefed on the use of the seat belt. Instruct passengers to observe fasten seat belt sign

3. Movement in aircraft

Passengers will be briefed to remain seated with seat belts fastened during take-off,

landing taxi operations, and at other times when directed by the pilot or other crew members

4. Smoking

Smoking will be at the discretion of the pilot (and the troop commander or jumpmaster when applicable). Smoking will not be permitted until after take-off and will be discontinued during letdown for landing. At no time will smoking be allowed on the ground within 50 feet of the aircraft. Instruct passengers to observe no smoking sign

5. Air sickness

Air sickness bags will be provided for passengers who request them. Passengers will be responsible for removing them from the aircraft after the flight

6. Electronic devices

Passengers having electronic devices such as transistor radios and other private or professional electronics gear will not use them during flight

7. Opening the doors

Doors will not be opened in the air or on the ground by anyone except an authorized crew member

8. Exit after flight

Passengers will remain seated after flight, with seat belt fastened, until directed to leave the aircraft by an authorized crew member

9. Emergency procedures

a. Use of parachute

When applicable, the fitting and use of the parachute will be explained

b. Bail-out (when applicable)

- (1) Signals - 3 short followed by one long
- (2) Exits - Cargo ramp and door and paratroop doors
- (3) Take emergency gear, exposure suits, boots, and warm clothing

c. Crash landing

- (1) Signals - 6 short followed by one long, one long if just after take-off
- (2) Remain seated until aircraft stops
- (3) Exits - Left side escape hatch, cargo ramp and door, entrance doors and cockpit roof hatches
- (4) Exit quickly without panic; take survival gear and warm clothing

d. Review all ground and air exits

e. Questions

OVER WATER BRIEFING

1. Signals - 6 short followed by one long; don life vests and exposure suits
2. Remain seated until aircraft stops; there may be two separate impacts
3. Exit routes - Left side escape hatch, entrance doors and cargo door
4. Inflate life vests and enter assigned rafts which will be released from the cargo compartment

ARRIVAL BRIEFING

1. Time
2. Observation of no smoking sign
3. Observation of seat belt sign
4. Remain seated

SECTION IX ALL WEATHER OPERATION

TABLE OF CONTENTS

INTRODUCTION	9-1
INSTRUMENT FLIGHT PROCEDURES.....	9-1
ICING CONDITIONS.....	9-3
TURBULENCE AND THUNDERSTORMS	9-7

NIGHT FLYING.....	9-8
COLD WEATHER PROCEDURES	9-8
HOT WEATHER PROCEDURES.....	9-12
DESERT PROCEDURES	9-13

INTRODUCTION.

This section contains only those procedures that differ from or are in addition to the normal operating instructions covered in Section II, except for some repetition necessary for emphasis, clarity, or continuity of thought.

INSTRUMENT FLIGHT PROCEDURES.

The aircraft may be provided with navigational equipment and instrumentation for using VOR, TACAN, ADF, GCA, and ILS navigational aids. It is the responsibility of the pilot to ensure that each crew member is thoroughly briefed on the exact procedures he is expected to follow during all phases of aircraft operation. If required to land under IFR conditions, additional fuel allowance must be made for letdown and holding procedures, and the maximum range is reduced accordingly. The aircraft has satisfactory instrument flight characteristics in all phases of operation. Steep turns and abrupt maneuvers should be avoided. All turns should be limited to bank angles not exceeding 30°. No special technique due to aircraft configuration or operation is required. The radio and navigational aids provide adequate coverage for practically all conditions of instrument flight.

WARNING

This aircraft contains various combinations of navigational receivers, course indicators, and radio magnetic indicators. Before flight, pilot's must determine the type of navigation equipment installed and its operation, the operation of controls and switches used to select navigation displays; the function of each RMI, bearing pointer, and course indicator; and the means of monitoring identification signals of navigation aids being used.

PRE-FLIGHT AND GROUND CHECKS.

Perform the preflight inspections, as outlined in the normal operating procedures in Section II.

INSTRUMENT TAKE-OFF AND CLIMB.

Preparation for an instrument take-off begins long before aligning the aircraft with the take-off runway. Be thoroughly familiar with the departure route, altitude restrictions, communication, and navigation aid frequencies, prior to take-off. Insure

that the aircraft can conform to the climb gradient specified on published departures.

1. Before take-off:

a. Communication and navigation aid frequencies, IFF, departure course, should be set prior to taking the runway.

b. Precipitation, low ceilings or visibility, or night takeoffs may require exclusive reference to the flight instruments before lift-off. Plan to have an instrument cross-check in progress before losing complete outside visual reference during the takeoff roll and/or subsequent departure.

c. Perform the before take-off checklist; align the miniature aircraft on both attitude indicators with the horizon bar and when cleared, taxi into take-off position.

d. Align the aircraft; recheck the heading indications, attitude indicator, and navigation and communication frequencies. Perform the line-up checklist.

CAUTION

Attitude indicators without an attitude warning flag should not be used for instrument flight until 15 minutes after electric power has been applied.

NOTE

The rotating beacon should be turned off during flight in clouds or fog to prevent distracting reflections that could cause spatial disorientation.

e. Turn on anti-icing and deicing systems as required and use carburetor heat as necessary.

2. Take-off:

a. Use the normal take-off procedures outlined in Section II. It is recommended that radar monitoring be used when available, in the event that return to the airfield becomes necessary. Visual references, if available, should be used to maintain alignment during the take-off roll.

b. As the airspeed approaches takeoff speed, the pilot will ease back on the control column to smoothly establish a 4 bar width nose high pitch change on the attitude indicator. Hold this attitude and allow the aircraft to fly itself off the ground.

c. When the aircraft is in a definite climb as indicated by the altimeter and vertical velocity indicator, retract the gear and flaps. Cross-check the turn needle and heading indicator to verify wings level.

d. Maintain a climbing attitude for the performance required and accomplish the after take-off checklist.

NOTE

Minor pitch trim changes should be expected during flap retraction and power reduction.

CRUISE.

Conduct instrument cruise flight using the normal operating procedures outlined in Section II. Use anti-icing and deicing equipment as required.

WARNING

When reference to the magnetic compass is necessary, the windshield heat switch must be OFF. With windshield heat ON, the cycling of electric power creates erratic magnetic deviation and causes unreliable compass indications.

HOLDING.

1. The recommended holding airspeed is 110 knots clean configuration, regardless of gross weight.

2. For extended holding or if fuel is a consideration, rpm should be reduced (refer to T.O. 1C-7A-1-1).

INSTRUMENT APPROACHES.

VOR, TACAN, ADF, radio range, ILS, or CGA instrument approaches may be flown. Flight characteristics during instrument approaches do

not differ from those encountered during visual flight. Normally 110 knots IAS is used for all maneuvering until final approach airspeeds are established. Final approach speeds and configuration will be established at or prior to final approach fix or glide slope. Descent and before landing checklists will be accomplished in accordance with Section II and will be performed as depicted in figures 9-1 and 9-2.

NOTE

Instrument approach patterns will vary and will not necessarily be flown as illustrated in figures 9-1 and 9-2.

Circling Approach.

If a circling approach is required, maintain 105 knots IAS until turning to base leg and proceed with a normal landing procedure.

Talar Approach.

A typical beam pattern for TALAR approach is shown in figure 9-3.

Missed Approaches.

In the event of a missed approach, immediately apply required power and simultaneously establish a climb attitude. Retract the landing gear and flaps as required when a definite climb is shown on the vertical velocity indicator and altimeter. Accelerate to climb speed and maintain until reaching desired missed-approach altitude. Execute the appropriate missed-approach procedure.

ICING CONDITIONS.

Avoid icing conditions whenever possible. The biggest danger caused by ice accumulation is reduced aerodynamic efficiency. Specifically, ice accumulation may have the following effects: Higher take-off, landing, and stall speeds; reduced rate of climb; increased power requirements, thus increasing fuel consumption and decreasing range and endurance; impaired control response; and reduced engine power. If a buildup takes place on the nose section it may create erratic effects at the static ports and cause unreliable airspeed indications, even though the ports themselves are not iced.

WARNING

Do not fly into known or forecast moderate or heavy icing conditions.

Altitude should be changed, when possible, to altitudes where icing conditions are not encountered. The aircraft is equipped with wing and tail deicers, propeller anti-icing, carburetor heat, pitot heaters, windshield anti-icers, and heater intake anti-icers. If icing conditions cannot be avoided, the following procedure should be followed:


1. Select the least severe icing altitude, consistent with mission objectives, traffic, or combat conditions. Consideration should be given to outside air temperature, nature of clouds, type of icing (rime, clear) anticipated or being encountered, and duration of icing.

2. The wing and tail deicers should be used with care. In heavy icing conditions, use of the system at the first sign of ice may allow an ice buildup to begin at the inflated contour of the boots. The boots are then unable to reach and break the accumulated ice and they become useless. The system is designed for deicing, not anti-icing. A moderate accumulation of ice should be allowed to develop before the system is operated. The slow boot cycle is effective in all but the most severe icing conditions, i.e., ice buildup greater than 1/4 inch per minute.

3. Pitot heat, and heater intake anti-icing, should be on when visible moisture is present or when icing conditions are anticipated. The circuit for each stall warning lift-transducer vane anti-icer is routed via the pitot heater switch. Windshield heat should be on for the duration of the flight. Windshield wipers will keep the windshields clear. Propeller anti-icing should be used continually at any time icing is encountered. Appreciable accumulation of ice on the propeller can cause engine vibration. If ice has accumulated, exercising the propeller levers will assist in throwing off the ice. Propeller icing is more likely to occur at the lower rpm settings.

4. Carburetor icing may occur in moisture or precipitation at ambient temperatures above the icing range. When carburetor icing is suspected, carburetor heat should be applied as necessary to

radar or ils approach-typical




NOTE

This is a typical diagram not meant to show the intended flight path. It does indicate a chronological order for the items to be performed. These items may be performed before, but in no case later than the point indicated on the diagram.

Figure 9-1

radio range, adf, vor or tacan approach-typical



NOTE

This is a typical diagram, not meant to show the intended flight path. It does indicate a chronological order for the items to be performed. These items may be performed before, but in no case later than the point indicated on the diagram.

Figure 9-2

TALAR approach-typical




Figure 9-3

maintain +15°C carburetor air temperature. If icing conditions are anticipated, apply carburetor heat 15 minutes before entering the icing area.

5. Delay extension of flaps and landing gear until absolutely necessary to avoid excessive ice accumulation on the flaps and landing gear.

CAUTION

If possible avoid flight in freezing rain. If freezing rain is unavoidable, do not operate the aircraft at low airspeeds with corresponding higher angles of attack, as there is a possibility of ice accretion on areas that are not anti-iced.

TURBULENCE AND THUNDERSTORMS.

Thunderstorms and areas of moderate turbulence should be avoided where possible and should only be penetrated intentionally if it is impossible to go around them. When flying under conditions of low visibility, clear passage around or between thunderstorms can usually be identified with radar. The aircraft has adequate control response in turbulent conditions. The optimum thunderstorm penetration speed of 110 knots IAS should be set up prior to entering the storm zone and the aircraft should be flown with regard to the VG limitations.

WARNING

When flying in heavy rain, the alternate air induction system may be required to avoid engines drowning out.

APPROACHING THE STORM.

Select an altitude below 10,000 feet above ground level and proceed as follows:

1. Check that all passengers and crew are seated, check security of cargo, and that all safety belts and harnesses are correctly fastened and tight.
2. Turn pitot heater switch on.
3. Turn heater intake anti-icing switches on.
4. Turn windshield heat switch to normal.

5. Boost pumps — Normal
6. Mixture Auto Rich
7. Set propeller levers — 2250 rpm.
8. Select alternate air source.
9. Set throttles to maintain 110 knots IAS (optimum penetration speed).
10. Set communications equipment as required and reduce volume of any radio equipment badly affected by static.
11. Turn flight compartment lights full bright to minimize blinding effect of lightning.

WARNING

Do not lower landing gear or wing flaps.

IN THE STORM.

Proceed as follows:

1. Maintain the original power setting and pitch attitude throughout the storm. If these are maintained, airspeed indicator fluctuations can be disregarded. Maintain level attitude by reference to the attitude indicator.
2. Maintain the original heading. Do not make any turns unless absolutely necessary.
3. Do not correct for airspeed indicator fluctuations, since doing so may result in extreme aircraft attitudes, with a danger of stalling.
4. Use as little elevator control as possible to minimize the stresses imposed on the aircraft.

WARNING

The altimeter may be unreliable due to differential barometric pressure within a thunderstorm. An indicated gain or loss of several hundred feet is not uncommon, and should be allowed for in determining minimum safe altitude.

NOTE

Altitudes between 10,000 and 20,000 feet are usually the most turbulent areas in a thunderstorm.

NIGHT FLYING.

Conduct night operations in accordance with normal operating procedures given in Section II. Set exterior and interior lights as required. For night take-offs, either taxi or landing lights may be used.

NOTE

To avoid spatial disorientation, it is recommended that the anti-collision light be turned off during flight in clouds.

COLD WEATHER PROCEDURES.

Extreme cold can have adverse effects on aircraft materials. Rubber, plastic, and fabric materials stiffen and may crack, craze, or even shatter when loads are applied. Oils and lubricants congeal. Adjoining metals contract differentially, and could result in adverse variations in tolerances. Moisture, usually from condensation or melted ice, freezes in critical areas. Tire, landing gear strut, fire extinguisher bottle, and accumulator air pressures decrease with a temperature decrease. Extreme diligence on the part of both ground and flight crews is required to insure successful cold-weather operation. The procedures and precautions outlined here pertain to operating unhangared aircraft in cold weather and are in addition to the normal procedures given in Section II.

NOTE

Cold weather is generally considered 0°C (32°F) and below.

BEFORE ENTERING THE AIRCRAFT.

Perform a normal preflight inspection of the aircraft as outlined in Section II. In particular, check the following:

1. Check for removal of snow, ice, and frost on the wings, fuselage, stabilizer, all flight control surfaces, hinges, fuel and oil vents and

drains, static ports, pitot heads, heater vents, carburetor, and oil cooler air intakes.

CAUTION

Do not attempt to scrape or chip ice from flight surfaces or fuselage. Exercise care to prevent personnel injury from slipping and falling.

2. Preheat engines, if required. Preheat is required if temperatures are below 0°F (-18°C) even though oil dilution was accomplished at shutdown. Preheat should not be considered adequate unless oil will flow from the oil tank sump drains.

NOTE

If an engine is too stiff to start, the starter clutch will slip.

CAUTION

Insure that moisture from melted ice is not allowed to remain in critical areas where it may refreeze.

3. After removal of wheel covers, check the landing gear struts, actuating cylinders, locking mechanism, wheels, and brakes for freedom from ice, snow or slush.

4. Check that the tires are not frozen to the ground.

BEFORE STARTING ENGINES.

1. Check that heat has been applied to the cargo compartment and the flight compartment.
2. Check passenger doors, cargo door, emergency exits, and flight compartment windows to see that they open easily.

WARNING

If isopropyl alcohol has been used to remove frost from the aircraft, check the interior of the aircraft for alcohol leaks and fumes. This condition may create a fire hazard.

3. Check that the parking brake handle is in the OFF position. If the handle is found to have been left ON, the brakes may be frozen. Notify the ground crew and, if necessary, direct that heat be applied to the brake discs and cylinders.

4. Prior to starting engines remove all protective covers.

STARTING ENGINES.

Except as noted in the following paragraphs, make cold weather starts using the procedures described in Section II.

NOTE

If sufficient heat has been applied to the engine, and the starter clutch slips during starting, a hydraulic lock probably exists. Remove spark plugs from the bottom cylinders, let cylinders drain and pull propeller through by hand. Reinstall plugs and attempt another start.

It may be necessary to run the engine on prime alone for longer periods than normal if it will not run smoothly in auto-rich initially.

If possible, the engine should be kept running on the first starting attempt. Ice may form on the spark plugs within a few seconds if the engine fires and then stops. If the engine has not started after two or three attempts, several spark plugs should be removed and examined for ice. If icing has occurred, the front plugs should be removed and heated to dry the electrodes before making another starting attempt.

If the oil pressure does not register within 30 seconds after starting, the engine should be shut down and the cause investigated.

NOTE

The oil pressure may be abnormally high immediately upon starting. As the oil temperature increases, the pressure should drop to normal. Do not increase engine speed above 1000 rpm until oil temperature and pressure are within limits.

Carburetor heat may be used as soon as the engine is firing regularly to improve vaporization and combustion. Return the lever to COLD when the engine is operating normally.

WARM-UP.

If the weather is extremely cold, oil may congeal in the oil cooler. The first indication of this will be a very high oil temperature with a decrease in oil pressure. As the congealed oil is forced into the system, a sudden drop in temperature and a large increase in pressure will occur. A careful check should be maintained on oil pressure and temperature and sufficient time allowed for a thorough engine warm up. If oil pressure registers and then drops below normal after a few minutes of operation, the engine should be shut down and checked.

The wing flaps should be operated through one complete cycle while being observed by a ground

oil dilution and boil-off table

ANTICIPATED TEMPERATURE °F °C	DILUTION PERCENT	MINUTES TO DILUTE AT 1400 RPM	MINUTES TO BOIL- OFF-OIL TEMP 55 TO 75° C	HOT FUEL PRIME	PREHEAT (UNTIL CYL HD TEMP IS ABOVE 0°C)
32 TO 0 0 TO -18	6	1	NONE	YES	NONE
0 TO -20 -18 TO -29	17	2	25	YES	YES+
-20 TO -35 -29 TO -37	20	2 1/4	30	YES	YES+
-35 TO -50 -37 TO -46	25	2 1/4	35	YES	YES+
-50 TO -65 -46 TO -53	30	3	40	YES	YES+

+ INCLUDING AIR PUMP

Figure 9-4

crew member. Check the flap position indicators to make certain the flaps reach their extreme positions without hindrance from undetected snow or ice. Stop the flaps at various positions to determine if the control and position indicators are in operating condition.

OIL DILUTION SYSTEM.

The oil dilution system provides a method for introducing a controlled quantity of fuel into the engine oil system. The purpose of oil dilution is to lower the viscosity of the oil during cold weather. This makes starting easier, provides an immediate supply of lubricating oil to all moving parts, and also minimizes the risk of bursting flexible hose lines and oil coolers.

OIL DILUTION BOIL-OFF.

Boil-off is the action of raising the engine operating temperature, and maintaining it at a sufficiently high level, to vaporize the fuel that was introduced into the oil during the oil dilution procedure. The vapor leaves the engine through the engine drain and breather box vent. Adequate boil-off is essential to avoid the possibility of oil venting from the engine or oil tank breather. If insufficient boil-off has been allowed, insufficient engine lubrication will result. In addition the high engine temperatures associated with take-off will rapidly vaporize the fuel in the oil and, if this action is too rapid, the vapor may not separate from the oil fast enough and froth will form in the engine crankcase. This results in an over-pressurization of the system, forcing oil out of the engine drain and breather box vent, and can only be stopped by reducing engine power. Should this occur, the oil level should be checked and a complete boil-off procedure should be carried out. Figure 9-4 lists the time required to boil-off the excess fuel, commencing when the oil temperature reaches 45°C. The oil temperature should, and normally will, continue to increase from this temperature, but must not exceed 75°C. If the previous oil dilution period was for less than one minute, no boil-off procedure is required. If the dilution period was for more than one minute, carry out the following procedure:

1. Fit the restrictors to the augmentor tubes to decrease the cooling effect of the tubes.
2. Start the engines in accordance with Section II.

3. Warm-up at 1000 rpm; maintain this setting for at least 10 minutes. Continue running if necessary, until the oil temperature reaches 5°C.

4. Advance throttles to 1200 rpm; maintain this setting for at least 5 minutes, or until the oil temperature reaches 20°C.

5. Advance throttles to 1400 rpm; maintain this setting for at least 5 minutes, or until oil temperature reaches 40°C. Increase manifold pressure to 28 in. Hg while maintaining 1400 rpm with the propeller levers.

6. Advance propellers to 1600 rpm and maintain 28 in. Hg until the oil temperature reaches 45°C, and commence boil-off time check.

NOTE

A cylinder head temperature of 200°C, and an oil temperature of 75°C, must not be exceeded during the warm-up and boil-off procedure.

TAXIING.

1. Turn pitot heater switch ON.
2. Direct the ground crew to check that the tires are not frozen to the ground prior to taxiing.
3. Check That wheels are rotating. Use nose wheel steering, differential braking, and differential power for best directional control.
4. Insure all instruments have warmed up sufficiently. Check for sluggish operations during taxiing.
5. Taxiing will cause the engines to cool, a sudden increase in power may result in engine back firing. On reaching the take-off position, insure that engines are warm and that power is increased gradually.

ENGINE RUNUP.

Select an area that has the best available surface for braking and conduct the engine and propeller checks outlined in Section II. Avoid parking aircraft close together or near obstructions when performing engine runup.

NOTE

Surfaces covered with loose snow generally provide better braking than surfaces covered with compact snow.

When runup must be conducted on snow-covered surfaces, do not attempt to make power checks until the aircraft is lined up on the runway and ready for take-off.

BEFORE TAKE-OFF.

1. Turn windshield heat switch to normal.
2. Set carburetor air induction switch as required.
3. Set carburetor hot air levers as required.

NOTE

Carburetor heat may be used during the take-off to assist in the vaporization of fuel, to reduce rough running and to avoid loss of power. Do not allow the temperature to exceed the maximum permissible of +38°C, to prevent detonation; otherwise, a loss of power will result during the climb.

TAKE-OFF.**WARNING**

Do not attempt a take-off with snow, ice, or frost accumulations on the wing and tail surfaces.

Runway conditions permitting, slowly advance power to 30 in. Hg and assure that the engines are running smoothly prior to releasing brakes. If a crosswind take-off is necessary on an ice surface, use asymmetric engine power to maintain direction, remembering that the take-off distance will be increased.

CAUTION

For take-off in colder than standard conditions, avoid over-powering the engine beyond its rating. Reduce maximum manifold pressure 1 in. Hg for each 10°C below standard carburetor air temperature.

AFTER TAKE-OFF.

After take-off from a slush-covered surface and after reaching a safe altitude, the landing gear and flaps should be exercised through a few complete cycles to prevent their freezing in the retracted position.

DURING FLIGHT.

At very low temperatures, low cylinder head and carburetor air temperatures may cause rough running. This condition may be corrected by applying carburetor heat; if this is not sufficient the mixture lever should be placed in AUTO RICH.

DESCENT.

If a temperature inversion is expected during a descent, a close watch must be kept on engine temperatures, even when using a high power setting. If necessary, the landing gear may be lowered, so that higher power settings may be used. Carburetor heat should be used as necessary.

APPROACH AND LANDING.

Glide approaches should not be made under cold weather conditions. Normal powered approaches are recommended to maintain normal engine temperatures. Use carburetor heat as necessary. If the landing surface is slush covered, the flaps should be retracted as soon as possible after touchdown. Maintain directional control by use of rudder and differential brakes and if the surface is icy or a crosswind exists, maintain directional control by use of asymmetric engine reverse power. If reverse thrust is used at slow speeds on snow or slush-covered surfaces, complete loss of visibility may occur. Use windshield heat and pitot heat during landing. Turn on windshield wipers if needed. Make the turn-off slowly to avoid skidding.

CAUTION

Careful use of the brakes is required when landing on an ice covered surface.

ENGINE SHUTDOWN.

If a subsequent cold weather start is anticipated, oil dilution should be completed prior to engine shutdown. the extent of dilution depends entirely on the anticipated temperature during the period

of shutdown. (Refer to figure 9-4.) A check must be made to insure that the oil tank level is 3 gallons below the full mark. The engines must be idled until the oil temperature is below 40°C (or stopped and cooled, then restarted) before the dilution procedure is commenced.

NOTE

Do not attempt oil dilution at oil temperatures above 45°C.

OIL DILUTION.

Proceed as follows for each engine.

1. Turn fuel tank selector switch to normal.
2. Turn fuel boost pump switches off.
3. Turn autofeathering switch off.
4. Adjust the throttle to 1400 rpm. Propeller levers should be at full increase rpm and oil temperature at 40°C.
5. Turn the appropriate engine oil dilution switch on for the required time (refer to figure 9-4).

NOTE

The time quoted is the elapsed time from selecting dilution to selecting idle cut-off. After selecting idle cut-off, the propeller will continue to rotate for approximately 10 seconds, during which time the dilution switch should be retained in the ON position.

6. Position the mixture lever to IDLE CUT-OFF when the required time has elapsed.

NOTE

Do not start the engines or add oil to the system after dilution is completed. Do not allow the oil pressure to drop below 45 psi during the dilution procedure.

BEFORE LEAVING THE AIRCRAFT.

Insure that a postflight inspection is accomplished, giving special attention to the following:

1. Drain condensation from fuel and oil system sumps and drains.
2. Remove all ice from vents, drains, and breathers.
3. Clean landing gear shock struts of dirt and ice with a clean cloth soaked with hydraulic fluid.
4. Install all exterior protective covers and shields.
5. If the aircraft is to remain outside for a period of more than four hours at below-freezing temperatures, remove the battery and store it in a heated room.
6. Close all doors and hatches.
7. Insure that the aircraft is tied down and chocked.

HOT WEATHER PROCEDURES.

Hot weather operation as distinguished from desert operation generally means operation in a hot, humid atmosphere. High humidity usually results in the condensation of moisture throughout the aircraft. Possible results include malfunctioning of electrical equipment, fogging of instruments, rusting of steel parts, and the growth of fungi in vital areas of the aircraft. Further results may be pollution of lubricants and hydraulic fluids, and deterioration of nonmetallic materials. The procedures essential to operations under such conditions are given in the following paragraphs.

BEFORE ENTERING THE AIRCRAFT.

Perform a normal preflight inspection, as outlined in Section II. Give special attention to the following:

1. Plan the flight thoroughly. Include the determination of range, take-off distance, and other data for existing conditions, using performance data charts in T.O. 1C-7A-1-1.

2. Cool the flight compartment and cargo compartment with portable coolers, if available.

3. Check for freedom of corrosion or fungus at joints, hinge points, and similar locations.

4. Check for hydraulic leaks, as heat and moisture may cause seals and packings to swell.

5. Inspect the shock struts and actuators for cleanliness. Use a cloth moistened in hydraulic fluid to clean. Inspect the tires for proper inflation.

6. Remove all protective covers and shields.

BEFORE STARTING ENGINES.

Perform the normal preflight inspection, as outlined in Section II; giving special attention to instruments, equipment, and controls. If they are moisture coated, wipe dry with a clean soft cloth.

TAXIING INSTRUCTIONS.

Taxi the aircraft as directed in Section II. Use brakes as little as possible, to avoid overheating.

NOTE

If temperatures approach the maximum limit during prolonged ground operation, the throttle should be advanced to increase airflow through the coolers and engine.

TAKE-OFF.

Execute normal take-off and climb, as outlined in Section II.

NOTE

Take-off run is considerably increased, and rate of climb decreased, in high temperatures. Refer to the appropriate charts in T.O. 1C-7A-1-1.

CRUISE.

Follow normal procedures for the operation of the aircraft, as outlined in Section II.

LANDING.

Execute normal approach and landing, as outlined in Section II.

NOTE

For a given indicated airspeed, the true airspeed increases as atmospheric temperature rises. Therefore, on very hot days, anticipate a longer landing roll.

STOPPING ENGINES.

Make a normal engine shutdown as outlined in Section II. As soon as the aircraft is parked, chock wheels and release brakes to avoid possible damage to brake components from excessive heat generated while taxiing.

BEFORE LEAVING THE AIRCRAFT.

Make a normal postflight inspection as outlined in Section II, and:

1. Install appropriate protective covers for protection from the sun.

2. When weather conditions permit, leave flight compartment windows and cargo compartment doors open to ventilate the aircraft.

DESERT PROCEDURES.

Desert operation generally means operation in a very hot, dry, dusty, and often windy atmosphere. Under such conditions, sand and dust will accumulate in vital areas of the aircraft, such as hinge points, bearings, landing gear shock struts, and engine cowlings and air intakes. Severe damage to the affected parts may be caused by the dust and sand. Position the aircraft so that propwash will not subject other aircraft, personnel, and ground equipment to blowing sand or dust. The necessary operations under such conditions are given in the following paragraph.

BEFORE ENTERING THE AIRCRAFT.

Perform a normal preflight inspection as outlined in Section II. Give special attention to the following:

1. Plan the flight thoroughly. Include the determination or range, take-off distance, and

T.O. 1C-7A-1

other data for the existing conditions, using the charts in T.O. 1C-7A-1-1.

2. Cool the flight compartment and cargo compartment with portable coolers, if available.

3. Inspect all control surface hinges and actuating linkage for freedom of sand and dust.

4. Inspect tires for proper inflation.

5. Inspect shock strut extensions and actuators for freedom of sand or dust, particularly in the area next to the cylinder seals. Insure that the shock strut extensions are clean.

6. Remove all protective covers and shields.

BEFORE STARTING ENGINES.

Continue the normal preflight inspection of the aircraft, as outlined in Section II. Give special attention to the following:

1. Inspect for sand or dust deposits on instrument panels and switches, and on and around flight and engine controls.

2. Operate all controls through at least two full cycles to insure unrestricted operation.

TAXIING INSTRUCTIONS.

Taxi the aircraft as directed in Section II, using care to avoid blowing sand or dust on other aircraft, personnel, or equipment. Use the brakes as little as possible, to avoid overheating. The use of reverse thrust may blow sand and dust into the air directly in front of the engine/air intakes. In deep sand, use differential power, rather than nose wheel steering, for directional control. Minimize ground operation to avoid excessive engine temperatures and gravel erosion of the propellers. Use carburetor air filtering as required.

TAKE-OFF.

Execute normal take-off and climb, as outlined in Section II. Avoid take-off during sand or dust storms, if possible. Take-off run is considerably increased and rate of climb decreased in high atmospheric temperatures. Refer to the appropriate charts in T.O. 1C-7A-1-1.

CRUISE.

Follow normal procedures for the operation of the aircraft, as outlined in Section II. Avoid flying through dust or sand storms, when possible. Use carburetor air filtering as required.

LANDING.

Execute a normal approach and landing, as outlined in Section II. For a given indicated airspeed, the true airspeed increases as atmospheric temperature rises. Therefore, on very hot days, anticipate a longer landing roll. Use carburetor air filtering as required.

STOPPING ENGINES.

Park the aircraft as soon as possible to prevent excessive cylinder head temperatures. Make a normal engine shutdown as outlined in Section II. As soon as the aircraft is parked, chock the wheels and release the brakes to avoid damage to brake components due to excessive heat generated while taxiing.

BEFORE LEAVING THE AIRCRAFT.

Make a normal before leaving the aircraft inspection, as outlined in Section II, giving special attention to the following:

1. Install all protective covers and shields.

2. Except when sand and dust are blowing, leave flight compartment windows and cargo compartment doors open to ventilate the aircraft.

ALPHABETICAL INDEX

Asterisk indicates illustration

A

AAU-21/A Altitude Encoder/Pneumatic	
Altimeter	4-30D
AAU-27/A Pressure Altimeter	4-30F
Abandoning Aircraft	3-38
Abort Procedures	3-3
Accessory Compartment Cooling System	
Selector Switch	1-7
Acceleration Limitations	5-6
AC — DC Power Panels	1-22*
AC Electrical System — Schematic	1-18*
AC Failure Light	1-20
AC Instrument Transformers	1-20
AC Power Supply System	1-19
AC Standby Inverter Light	1-20
ADF Receiver	4-29
After Landing	2-46
After Loading	8-4
After Take-off/Go-Around	2-36, 4-5, 8-4, 9-8
AIMS/IFF Transponder System	
(AN/APX-72)	4-30A
AIMS/IFF AC Power Distribution	4-30B*
AIMS/IFF Altimeters	4-30F*
AIMS/IFF DC Power Distribution	4-30B*
AIMS/IFF Receiver-Transmitter	4-30E*
AIMS/IFF Transponder Control Panel	4-30C*
Altimeter, AAU-21/A Altitude Encoder/	
Pneumatic	4-30D
Altimeter, AAU-27/A Pressure	4-30F
Antenna AT-741/A	4-30D
Antenna Switching Unit SA-1474/A	4-30D
IFF Antenna Switch	4-30D
IFF Caution Light	4-30G
Receiver-Transmitter RT-859/APX-72	4-30D
Mount MT-3949()A/U	4-30G
Operation	4-30G
Transponder Control C-6280(P)/APX	4-30C
Transponder Set Test Set TS-1843/APX ...	4-30F
After Take-off Climb	2-36
Aileron Trim, Runaway	3-23
Aileron Trim Switch	1-26
Aileron Trim Tab Position Indicator	1-26
Aircraft, Abandoning	3-38
Aircraft, The	iii*
Airdrop Limitations	5-7
Airdrop System	4-47
Aircraft, Before Entering The	9-8, 9-12, 9-13
Aircraft Dimensions	1-1
Aircraft, The	1-1
Aircraft Weight	1-2
Air Pressure Control	7-5, 7-10
Airspeed Indicators	1-36
Airspeed, Landing Gear Operating	5-6
Airspeed Limitations	5-2, 5-6
Airspeed, Maneuvering	5-6
Airspeed, Maximum	5-6
Airspeed, Normal Operating	5-6
Air Temperature, Carburetor	7-1
Alarm Bell System	4-48
All Weather Operations	9-1
Alternate Grade Fuel	5-6
Altimeter, AAU-21/A Altitude Encoder/	
Pneumatic	4-30D
Altimeter, AAU-27/A Pressure	4-30F
Altimeters	1-36
Ammeter Failure	3-23
Analyzer, Ignition	4-49
Antenna AT-741/A	4-30D
Antenna Switching Unit SA-1474/A	4-30D
Anti-Collision Lights	4-33
Anti-Collision Lights Switch	4-33
Anti-Icing and Deicing Systems	4-11
Anti-Icing	
Heater Intake	4-11
Pitot Head	4-11
Windshield	4-11
Approach and Landing	9-11
Approach and Landing, Normal	2-40
Approach, Circling	9-3
Approach, Radar or ILS — Typical	9-4*
Approach, Radio Range, ADF, VOR	
or Tacan — Typical	9-5*
Approach Speed Indicator, Short-Field	1-34
Approach Talar	9-3, 9-6*
Approaches, Missed	9-3
Approaching the Storm	9-7
Arrangement, General	1-3*
Attitude Indicators	1-36
Autofeathering Indicator Light	1-10
Autofeathering Switch	1-10
Auxiliary Equipment	1-43
Auxiliary Tanks	
Fuel	7-4
Oil	7-4
Refueling the	7-8
Axe, Crash	1-42

B

Battery	1-14
Battery Bus	1-15
Battery Master Switch	1-15
Bailout Procedures	3-24
Before Entering the Aircraft.....	9-8, 9-12, 9-13
Before Interior Inspection	2-3
Before Landing.....	2-40, 2-45, 8-5
Before Leaving the Aircraft	2-49, 8-5, 9-12, 9-13, 9-14
Before Starting Engines.....	2-17, 9-8, 9-13, 9-14
Before Take-off	2-31, 8-4, 9-11
Before Taxiing.....	2-21
Bell System, Alarm.....	4-48
Blackout Curtains.....	4-47, 4-48
Boil-Off, Oil Dilution	9-10
Brake Accumulator Handpump	
Charging Selector	1-32
Brake Handle, Parking	1-31
Brake Hydraulic Pressure Gage	1-32
Brake Pedals	1-31
Brakes, Efficiency of	7-12
Brake System Failure	3-29
Brake, Wheel System	1-31, 7-12
Bus	
Battery	1-15
Emergency	1-15
Main	1-15
Secondary	1-15
Secondary Rest Switch.....	1-15

C

Carburetor	
Air Induction System	1-2
Air Temperature.....	7-1
Air Temperature Gage	1-8
Hot Air Levers.....	1-2
Icing.....	7-1
Cargo	
Compartment.....	8-2
Compartment Check	2-10
Door and Ramp System	4-43
Door and Ramp Switches.....	4-45*
Door Operation	4-43, 4-44
Jettison and Jettison Technique	3-24
Loading Equipment.....	4-41
Loading Light and Switch	4-37
Tie-Down Rings.....	4-42
Cargo Compartment Dome Lights and Switch	4-36
Cargo Compartment Heater Fire	3-16
Cargo Compartment Heating System.....	4-5

Cargo Compartment Ventilating System	4-10
Cargo Compartment Heating and Ventilating System	4-7
Center of Gravity	7-10
Center of Gravity Limitations	5-7
CG Limits.....	5-9*
Chart Color Code	5-1
Checklist, Loadmaster's.....	8-2
Checklist, Passenger Briefing	8-5
Checklists	2-1
Check, Cargo Compartment	2-10
Checks, Preflight	2-2, 7-8
Checks, Pre-Flight and Ground.....	9-1
Checks, Top of Aircraft.....	2-9
Chopping Area	3-35
Circling Approach	9-3
Circuit Breaker and Fuse Panels — Typical	1-21*
Circuit Breakers.....	1-15
Climb, After Take-off.....	2-36
Climb, Single-Engine Best Speed	3-5*
Climb, Instrument.....	9-1
Climb, Maximum.....	2-37
Climb, Normal.....	2-36
Clocks	1-37
Cold Weather Procedures.....	9-8
Color Code Chart	5-1
Combustion Heater Fire	3-16
Comfort Provisions.....	4-48
Communication and Associated Electronic Equipment	4-18, 4-19*
Compass, Magnetic	1-37
Completion of Fuel Transfer	7-9
Controls, Engine.....	1-2
Controls, Flight.....	1-24, 6-2
Control Column	1-24
Console (Typical) Overhead	1-6*
Controls, Engine.....	1-2
Controls Gust Lock Handle	1-26
Controls, Heater	4-2, 4-6
Constant Flow System, Oxygen System	4-38
Copilot.....	8-1
Copilot's Attitude Indicator	1-36
Copilot's Panel Lights Switch	4-38
Copilot's Instrument Panel	1-34*
Course Indicator (VOR/ILS Only)	4-25*
Course Indicators	4-25
Covers, Winterization	4-15
Crane Provision, Monorail	4-43
Crash Axe.....	1-42
Crew.....	1-2
Crew Duties.....	3-39, 8-1
Crew Requirements, Minimum	5-1
Crossfeed, Fuel.....	7-9

C (Cont)

Crosswind Ditching	3-40
Crosswind Landing	2-43
Crosswind Take-off	2-34
Cruise	2-37, 9-2, 9-13, 9-14
Curtains, Blackout	4-47, 4-48
Cylinder Head Temperature Gage	1-8
Cylinder Filler Valve and Pressure Gage, Oxygen	4-40A, 4-41

D

DC Electrical System-Schematic	1-18*
DC Power Supply System	1-14
DC Utility Receptacle	1-19
Defouling (Cleanout) Procedure	7-3
Deicing and Anti-Icing System	4-11

D (Cont)

Deicing, Propeller	4-11
Deicing Switch Panel	4-14*
Deicing System, Wing and Tail	4-12, 4-13*
Descent	2-38, 8-4, 9-11
Desert Procedures	9-13
Detection of Inoperative Engine	3-10
Detonation	7-1
Diluter Demand Oxygen System	4-40*, 4-41A*
Diluter Demand System, Oxygen System	4-38, 4-40A
Dilution, Oil	9-10, 9-12
Ditching	3-35
Characteristics	3-35
Chart	3-37*, 3-38*
Crosswind	3-40
Emergency Equipment	3-36
Exits	3-39*
Exits, Emergency (Flight Crew)	3-36
Exits, Emergency (Passenger)	3-36
Night	3-40
Normal	3-40
Preparation for	3-36
Procedures	3-36
Technique	3-40
Upwind	3-40
Diving	6-3
Door, Draftproof	1-42, 4-48
Doors, Entrance	1-42
Cargo Compartment/Flight Compartment	
Door	1-42
Flight Compartment Bottom Hatch	1-42
Passenger Doors	1-42
Doors Unlocked Light	4-36
Draftproof Door	1-42, 4-48
Restraining Strap	4-48
During Flight	9-11

E

Electrical Fire	3-17
Electrical Power Supply System	1-14
Electrical Switch Panels — Typical	1-19*
Electrical Systems Failure	3-20
Electrical System Schematic, DC	1-18*
Elevator Trim Tab Handwheel	1-26
Elimination, Smoke/Fumes	3-19
Emergencies	
Ground	3-2
Inflight	3-37
Landing	3-25
Take-off	3-3
Emergency and Side Panels	1-39*
Emergency Bus	1-15

Emergency Bus Switch	1-15
Emergency Ditching Equipment	3-36
Emergency Ditching Exits (Flight Crew)	3-36
Emergency Ditching Exits (Passengers)	3-36
Emergency Entrances	3-35, 3-35*
Chopping Area	3-35
External Releases	3-35
Emergency Equipment	1-38
Emergency Escape Routes, Exits and Equipment	3-34*
Emergency Exits	1-41
Cargo Compartment	1-41
Flight Compartment	1-41
Emergency Extension Handle, Main Gear	1-30
Emergency Extension Handle, Nose Gear	1-30
Emergency Extension, Landing Gear	3-26
Emergency Hydraulic Selector Panel	1-29*
Emergency Hydraulic Selector Panel Lights	4-37
Emergency Hydraulic System	1-24
Emergency Landing Gear Down Selector Handle	1-28
Emergency Operation Heating System	4-9
Emergency Operational Long Range Ferry Fuel System	7-11
Emergency Operation, Wing Flap	3-29
Emergency Procedures	3-1
Emergency Shutoff Switches, Oil	1-11
Emergency Steering Switches	1-31
Emergency Wheel Brakes Lever	1-31
Encoder/Pneumatic Altimeter, AAU-21/A Altitude	4-30D
Engines	1-2
Engine Accessory Compartment Preheat System	4-18
Engine and Propeller Limitations	5-1
Engine Checks, Post Flight	2-46A
Engine Control Speeds, Single	3-4*
Engine Cooling and Exhaust System	7-1
Engine, Detection of Inoperative	3-10
Engines, Before Starting	2-17, 9-8, 9-13, 9-14
Engine Controls	1-2
Engine Failure During Take-Off	3-3
Engine Fire	3-14
Engine Fire Detection Test Switch	1-40
Engine Fire Extinguisher Handles	1-38
Engine Fire Extinguisher Indicating Discs	1-40
Engine Fire on Ground	3-2
Engine Fire Warning Lights	1-40
Engine Idling	5-4A
Engine Inoperative, Landing with one	3-30
Engine Inoperative, Practice Maneuvers With one	3-10

E (Cont)

Engine Instruments	1-7
Engine Overboost	5-4A
Engine Overspeed	3-13, 5-1, 5-4A
Engine Panel Lights and Switch	4-38
Engine Preheat System Operation	4-14
Engine Preheat System (Using APU Exhaust Heat)	4-14
Engine Priming	1-7
Engine Restart in Flight	3-10
Engine Runup	2-28, 9-10
Engine RPM Restriction	5-4A
Engine Shutdown	2-47, 8-5, 9-11
Conditions	3-1
Engine Fire/Shutdown Procedures, Inflight	3-7
Engine Start, Taxi and Engine Runup	8-4
Engine, Starting	2-18, 9-9
Engines, Stopping	9-13, 9-14
Entering, Prior to	8-2
Entrance	2-2
Engine Smoke and Flame Identification Chart	3A-15*
Entrance Doors	1-42
Cargo Compartment/Flight Compartment Door	1-42
Flight Compartment Bottom Hatch	1-42
Passenger Doors	1-42
Entrance Light Rear	4-37
Entrances, Emergency	3-35, 3-35*
Chopping Area	3-35
External Releases	3-35
Equipment, Emergency Ditching	3-36
Equipment, Miscellaneous	1-42, 4-47
Excess Manifold Pressure (Overboosting)	5-4A
Exhaust System and Engine Cooling	7-1
Exits, Ditching	3-39*
Exits, Emergency	1-41
Cargo Compartment	1-41
Flight Compartment	1-41
Extension Ramp	4-43
Exterior Inspection	2-11
Exterior Inspection Diagram	2-12*
Exterior Lighting System	4-33
External Power Receptacle	1-15
External Releases	3-35
Extinguisher, Fire	7-8

F

Factors, Margin of Safety and Load	5-10
Failure, Ammeter	3-23
Failure, Brake System	3-29
Failure, Electrical System	3-20
Failure, Engine During Take-Off	3-3

Failure, Instrument Transformer Main	3-24
Failure, Main Landing Gear Tire	3-32
Failure, Nose Landing Gear Tire	3-32
Failure, Nosewheel Steering	3-34
Failure of Gear to Retract	3-28
Failure of Main Inverter	3-23
Failure of One Generator	3-20
Failure of Standby Inverter	3-23
Failure of Two Generators	3-21
Failures, Fuel System	3-19
Failures, Hydraulic System	3-25
Failures, Inverter	3-23
Failures, Propeller	3-13
Feathering Buttons, Propeller	1-10
Ferry Tank Operation	7-8
Ferrying System Control Panel — Typical	7-6*
Fire, Cargo Compartment Heater	3-16
Fire, Combustion Heater	3-16
Fire Detecting and Extinguishing Systems	1-38
Fire Detecting and Extinguishing Systems, Heater	1-38
Fire Detection Test Switch, Engine	1-40
Fire, Electrical	3-17
Fire, Engine	3-14
Fire, Engine on Ground	3-2
Fire, Extinguisher	7-8
Fire, Extinguisher Handles, Engine	1-38
Fire Extinguisher Indicating Discs, Engine	1-40
Fire Extinguisher Indicating Discs, Heater	1-40
Fire Extinguishers, Portable	1-41
Fire Extinguishing and Detecting Systems	1-38
Fire, Flight Compartment Heater	3-16
Fire, Fuselage	3-16
Fires	3-14
Fire Warning Lights, Engine	1-40
Fire, Wing	3-17
First Aid Kits	1-42
Flap Lowering Speed Limitations	5-6
Flaps, Wing	1-26
Flap Settings	2-2
Flight, Level Characteristics	6-3
Flight Characteristics, Single Engine	3-9
Flight Compartment	1-4*
Flight Compartment Bottom Hatch Light	4-36
Flight Compartment Dome Light	4-34
Flight Compartment Dome Light Switch	4-34
Flight Compartment Heater Fire	3-16

F (Cont)

Flight Compartment Heating System	4-1
Flight Compartment Heating and Ventilating System	4-4*
Flight Compartment Ventilating System	4-9
Flight Controls	1-24, 6-2
Flight, During	9-11
Flight Maneuvering	6-3
Flight Mechanic	8-1
Flight Planning	2-1
Flight, Preparation for	2-1
Flight Procedures, Instrument	9-1
Flying, Night	9-8
FM Liaison Radio	4-23, 4-24
Formation Lights	4-34
Fuel Pressure Gage	1-8
Fuel, Alternate Grade	5-5
Fuel and Oil System, Long Range Ferry	7-4
Fuel Booster Pump Switches	1-13
Fuel, Completion of Transfer	7-9
Fuel Control, Inflight	7-9
Fuel Crossfeed	7-9
Fuel Emergency Shutoff Switches	1-14
Fuel Hot Prime System	4-49
Fuel Hot Prime Switch	4-50
Fuel Level Control Valve	7-8
Fuel Low Pressure Warning Light	1-8
Fuel Low Level Warning Lights	1-14
Fuel Management	7-4
Fuel Management Panel	7-5
Fuel Management Panel, Ferrying System — Typical	7-6*
Fuel Panel — Typical	1-13*
Fuel Pressure-Drop-Engine Operates Normal	3-19
Fuel Pressure-Drop-Engine Stops	3-19
Fuel Pressure-Drop-Ground Operation	3-19
Fuel Pressure Limitations	5-3*
Fuel Quantity Gages	1-13
Fuel Quantity Indicating System Test Switches	1-14
Fuel System	1-11
Fuel System Failures	3-19
Fuel System, Long Range Ferry — Schematic	7-7*
Fuel System — Schematic — (Typical)	1-12*
Fuel Tanks, Auxiliary	7-4
Fuel Tank Selector Switch	1-13
Fuel Weight Zero	5-11
Fuselage Fire	3-16
Fuselage Steady Strut	4-49

G

Gage, Brake Hydraulic Pressure	1-32
Gage, Carburetor Air Temperature	1-8
Gage, Cylinder Head Temperature	1-8
Gage, Fuel Pressure	1-8
Gage, Hydraulic System Pressure	1-22
Gage, Manifold Pressure	1-7
Gage, Oil Pressure	1-8
Gage, Oil Temperature	1-8
Gage, Outside Air Temperature	1-37
Gage, Fuel Quantity	1-13
Gear, Landing	1-27
Gear Retracted, Landing With	3-32
General Arrangement	1-3*
Generator, Failure of One	3-20
Generator Switches	1-14
Generator, Failure of Two	3-21
Generator Warning Lights	1-14
Go-Around	2-44
Glide, Maximum	3-6*
Glide Slope Receiver	4-28
Go-Around, Single Engine	3-30
Gross Weight	5-10
Ground Emergencies	3-2
Ground Engine Fire Shutdown Procedure	3-2
Ground Pressure	5-11
Ground Pressure Data	5-10*
Gust Lock Handle, Controls	1-26

H

Handpump and Handle, Hydraulic	1-24
Handwheel, Elevator Trim Tab	1-26
Handwheel, Rudder Trim Tab	1-26
Heater and Fan Circuit Breakers	4-3, 4-8
Heater Caution Light	4-8
Heater Control Selector	4-8
Heater Controls	4-2, 4-6
Heater Fire Combustion	3-16
Heater Fire Detecting and Extinguishing System	1-38
Heater Fire Extinguisher Indicating Discs	1-41
Heater Fire Extinguisher Switches	1-40
Heater Fire Warning Lights	1-41
Heater Fuel Pump Switch	4-2
Heater Ignition Switch	4-2
Heater Intake Anti-Icing	4-11
Heater Master Switch	4-2
Heater Operation (Flight Compartment)	4-3
Heater Operation (Cargo Compartment)	4-8

H (Cont)

Heater Start Switch	4-2
Heater Temperature Selector	4-2
Heating and Ventilating System	4-1
Heating and Ventilating System, Cargo Compartment	4-7*
Heating and Ventilating System, Flight Compartment	4-4*
Heating Control Panel	4-5*
Heating System, Cargo Compartment	4-5
Heating System, Flight Compartment	4-1
HF Liaison Radio	4-29
HF-SSB Liaison Radio	4-30
Holding	9-2
Horizontal Adjust Levers, Seats	1-42
Horn and Warning Light, Landing Gear Warning	1-28
Hot Air Levers, Carburetor	1-2
Hot Fuel Primer Switch	4-50
Hot Fuel Prime System	4-49
Hot Weather Procedures	9-12
Hydraulic Handpump and Handle	1-24
Hydraulic Handpump Selector	1-24
Hydraulic Low Pressure Warning Lights	1-24
Hydraulic Power Supply Systems	1-20
Hydraulic Pressure Limitations	5-4*
Hydraulic Pressure Shutoff Valve Lever	1-22
Hydraulic Reservoir and Sight Gage	1-22
Hydraulic System, Emergency	1-24
Hydraulic System, Normal	1-22
Hydraulic System Pressure Gage	1-22
Hydraulic System-Schematic	1-23
Hydraulic Systems Failures	3-25
Icing, Carburetor	7-1
Icing Conditions	9-3
Idling, Engine	5-4A
IFF (AN/APX-44)	4-30
IFF Antenna Switch, AIMS	4-30D
IFF Caution Light, AIMS	4-30G
IFF Operation	4-30G
Ignition Analyzer	4-49
Ignition Switches	1-7
Ignition System	1-7
In Flight	8-4
Index Marks, Landing Gear	1-28
Indicator, Aileron Trim Tab Position	1-26
Indicator, Attitude	1-36
Indicators, Radio Magnetic	4-26
Indicator, Short-Field Approach Speed	1-38

I

Indicator, Vertical Velocity	1-36
Indicator, Wing Flap Position	1-27
Indicators, Airspeed	1-36
Indicators — Course	4-25
Indicators, Thrust	1-32
Indicator Course (VOR/ILS only)	4-25*
Indicators, Turn and Slip	1-37
Induction Vibrator Switch	1-7
Inflight Emergencies	3-7
Inflight Engine Fire/Shutdown Procedure	3-7
Inflight Fuel Control	7-9
In-Flight Oil Supply	7-10
Initial Preflight	8-2
Inoperative Engine, Detection of	3-10
Inspection, Before Interior	2-3
Inspection Diagram, Exterior	2-12*
Inspection, Exterior	2-11
Inspection, Interior	2-3
Inspection, Thru-Flight	2-3
Instrument Approaches	9-2
Instrument Take-off and Climb	9-1
Instrument Flight Procedures	9-1
Instrument Markings	5-1, 5-2*
Instrument Panel (Engine) — Typical	1-9*
Instrument Panels (Flight) — Typical	1-33*, 1-34*
Instruments	1-32
Instruments, Engine	1-7
Instrument Take-Off and Climb	9-1
Instrument Transformer Failure	3-24
Instrument Transformer Failure Light	1-20
Instrument Transformer Selector Switch	1-20
Intercommunication System Control Panel	4-21
Interior Inspection	2-3
Interior Inspection, Before	2-3
Interior Lighting System	4-34
In The Storm	9-7
Inverter Main/Standby	1-19
Inverter Failures	3-23
Inverter Failure Lights	1-23
Inverter Switches	1-20
Inverter TACAN/RADAR ALTIMETER	1-19

J

J-2 Compass System	4-32
Jettison, Cargo	3-24
Jettisoning Cargo Not on Rollers	3-24
Jettisoning Palletized Cargo on Rollers	3-24

K

Kits, First Aid1-42

L

Landing2-40, 9-13, 9-14
 Landing and Go-Around3-10
 Landing Pattern — Typical2-42*
 Landing, After2-46
 Landing, Approach and9-11
 Landing, Before2-40, 2-45, 8-5
 Landing, Crosswind2-43
 Landing Data Card, Take-off and2-1
 Landing Emergencies3-25
 Landing Gear1-27
 Landing Gear Down Selector Handle,
 Emergency1-28
 Landing Gear Emergency Extension3-26
 Landing Gear Index Marks1-28
 Landing Gear Indicator Lights1-28
 Landing Gear Malfunction3-25
 Landing Gear Operating Airspeed5-6
 Landing Gear Selector Lever1-28
 Landing Gear Warning Horn and
 Warning Light1-28
 Landing Gear Warning Horn and Warning
 Light Test Switch1-28
 Landing Lights4-34
 Landing Lights Switches4-34
 Landing, Maximum Allowable Sink
 Rate on5-7
 Landing, Nosewheel Steering Failure3-34
 Landing, No Flap2-44
 Landing on Soft Ground or Unprepared
 Runways3-33
 Landing Short Field2-43
 Landing with Gear Retracted3-32
 Landing with One Engine Inoperative3-30
 Landing with Tire Failure3-32
 Leaving the Aircraft,
 Before2-49, 8-5, 9-12, 9-13, 9-14
 Level Flight Characteristics6-3
 Lever, Landing Gear Selector1-28
 Levers, Carburetor Hot Air1-2
 Levers, Propeller1-10
 Light
 AC Failure1-20
 AC Standby Inverter1-20
 Autofeathering Indicator1-10
 Doors Unlocked4-36
 Flight Compartment Bottom Hatch4-36
 Flight Compartment Dome4-34
 Fuel Low Pressure Warning1-8

Instrument Transformer Failure1-20
 Low Oil Level Warning1-8
 Magnetic Compass4-36
 Oil Low Pressure Warning1-8
 Propeller Reverse Indicator1-11
 Rear Entrance4-37
 Light and Switch, Cargo Loading4-37
 Light and Warning Horn, Landing
 Gear Warning1-28
 Lights
 Anti-Collision4-33
 Cargo Compartment Dome4-36
 Emergency Hydraulic Selector Panel4-37
 Engine Fire Warning1-40
 Formation4-34
 Fuel Low Level Warning1-14
 Generator Warning1-14
 Heater Fire Warning1-41
 Hydraulic Low Pressure Warning1-24
 Landing4-34, 9-13, 9-14
 Landing Gear Indicator1-28
 Navigation4-33
 Panel4-37
 Propeller Fluid Low Level1-10
 Taxiing4-34
 Troop Jump4-47
 Utility4-36
 Wing Inspection4-33
 Lighting Systems4-33
 Lighting System
 Emergency4-37
 Exterior4-33
 Interior4-34
 Limitations
 Acceleration5-6
 Airdrop5-7
 Airspeed5-6
 Center of Gravity5-7, 5-9*
 Engine and Starter5-4A
 Flap Lowering Speed5-6
 Maximum Allowable Sink Rate on
 Landing5-7
 Operating5-1
 Ramp Loading5-7
 Reverse5-6
 Limitations, Weight5-7
 Limits, Operating7-10
 Line Up2-33
 Loading8-3
 Loading, After8-4
 Loading Equipment, Cargo4-41
 Loading, Prior to8-3
 Loadmaster8-2
 Loadmaster's Checklist8-2

L (Cont)

Long Range Ferry Fuel and Oil System	7-4
Long Range Ferry Fuel System — Schematic.....	7-7*
Low Oil Level Warning Light.....	1-8

M

Magnetic Compass	1-37
Magnetic Standby Compass Light.....	4-36
Magnetic Standby Compass Light Switch.....	4-36
Main Bus	1-15
Main Gear Emergency Extension Handle.....	1-30
Main Gear Extension	3-28
Main Inverter.....	1-19
Main Inverter, Failure of	3-23
Main Landing Gear Tire Failure.....	3-32
Maneuvering Airspeed	5-6
Maneuvering Flight.....	6-3
Maneuvers, Prohibited	5-6
Manifold Pressure Gage	1-7
Margin of Safety and Load Factors	5-10
Marker Beacon Receiver.....	4-28
Markings, Instrument	5-1, 5-2*, 5-3*, 5-4*
Maximum Airspeed	5-6
Maximum Allowable Sink Rate on Landing.....	5-7
Maximum Climb.....	2-37
Maximum Glide.....	3-6*
Maximum Glide and Landing with Both Engines Inoperative	3-33
Minimum Crew Requirements	5-1
Minimum Turning Radius and Ground Clearance.....	2-27*
Miscellaneous Equipment	1-42, 4-47
Missed Approaches	9-3
Mixture Levers	1-2
Monorail Crane Provision	4-43
Mooring Points	4-49
Mount MT-3949()A/U, AIMS.....	4-30G

N

Navigation Lights	4-33
Navigation Lights Switch.....	4-33
Night Ditching.....	3-40
Night Flying.....	9-8
No Flap Landing	2-44
No Flap Take-off.....	2-35
Normal Landing	2-40
Normal Hydraulic System	1-22
Normal Operating Airspeed	5-6
Normal Procedures	2-1

Normal Take-off.....	2-34
Normal Landing	2-40
Nose Gear Down Handpump Selector	1-30
Nose Gear Extension	3-26
Nose Gear Emergency Extension Handle.....	1-30
Nose Gear Observation Window	1-30
Nose Landing Gear Tire Failure.....	3-32
Nosewheel Cocked	3-27
Nosewheel Shimmy	3-35
Nosewheel Steering	1-30
Nosewheel Steering Failure	3-34
Nosewheel Steering Switch.....	1-31
Nosewheel Steering Wheel	1-31
Nosewheel Universal Joint and Housing	3-27*

O

Off-Loading.....	8-5
Oil and Fuel System, Long Range Ferry	7-4
Oil Dilution and Boil-Off Table	9-9*
Oil	
Auxiliary Tank	7-4
Dilution.....	9-10, 9-12
Dilution Boil-Off.....	9-10
Dilution Switches.....	1-11
Emergency Shutoff Switches.....	1-11
Low Level Warning Light	1-8
Low Pressure Warning Light.....	1-8
Pressure Gage	1-8
Supply, In-Flight.....	7-10
System	1-11
Temperature Gage.....	1-8
Operating	
Limitations.....	5-3
Limits.....	7-10
Restrictions.....	2-1
Weight	5-7, 7-10
Outside Air Temperature Gage	1-37
Over Water Briefing	8-6
Overboost Chart.....	5-5
Overhead Console (Typical)	1-6*
Overspeed, Engine	3-13, 5-1
Oxygen, Diluter Demand System	4-40*
Oxygen Duration Chart (Constant Flow System).....	4-39*
Oxygen Duration Chart (Diluter Demand System).....	4-40*
Oxygen Equipment, Portable	4-48
Oxygen Regulator Panels.....	4-39, 4-40B
Oxygen Shutoff Valve	4-40A, 4-41
Oxygen System	4-38
Oxygen System, Constant Flow System	4-38
Oxygen System, Diluter Demand System.....	4-38, 4-40A

P

Panel	
Emergency Hydraulic Selector	1-29*
Fuel	1-13*
Heating Control	4-5*
Instrument (Engine) — Typical	1-9*
Troop Jump — Pendulum Release	4-48*
Panel Lights	4-37
Panel Lights Intensity Switches	4-38
Panels	
Circuit Breaker and Fuse — Typical	1-21*
Electrical Switch — Typical	1-19*
Emergency and Side	1-39*
Ferrying System Control — Typical	7-6*
Instrument Pilot's — Typical	1-33*
Instrument Copilot's — Typical	1-34*
Parking Brake Handle	1-31
Passenger Briefing Checklist	8-5
Passenger Warning Sign Switches	4-37
Passenger Warning Signs	4-37
Pedals, Brake	1-31
Pedals, Rudder	1-26
Pedestals, Pilot and Copilot	1-25*
Pendulum System	4-47
Performance Limitations	5-10
Pilot	8-1
Pilot and Copilot Pedestals	1-25*
Pilot's and Engine Panel Lights Switch	4-38
Pilot's Instrument Panel	1-33*
Pitot Head Anti-Icing	4-11
Pitot-Static System	1-32
Pitot-Static System — Schematic	1-35*
Planning, Flight	2-1
Pneumatic Altimeter, AAU-21/A Alti- tude Encoder	4-30D
Portable Fire Extinguishers	1-41
Portable Oxygen Equipment	4-48
Post Flight Engine Checks	2-46A
Power On	8-3
Power Plant and Related Systems	7-1
Power Receptacle, External	1-15
Power Settings	7-1
Power Supply System, AC	1-19
Power Supply System, DC	1-14
Power Supply System, Electrical	1-14
Power Supply Systems, Hydraulic	1-20
Practice Maneuvers with One Engine	
Inoperative	3-10
Practice Stalls	6-1
Pre Departure	8-5
Preflight and Ground Checks	9-1
Preflight Checks	2-2, 7-8
Preflight, Initial	8-2
Preheat System, Engine (Using APU Exhaust Heat)	4-14

Preheat System, Engine	4-14
Operation	4-14
Preheat System, Engine Accessory Compartment	4-18
Preparation for Ditching	3-36
Preparation for Flight	2-1
Pressure Altimeter, AAU-27/A	4-30F
Pressure, Ground	5-11
Primer Switch	1-7
Priming, Engine	1-7
Prior to Entering	8-2
Prior to Loading	8-3
Prohibited Maneuvers	5-6
Propeller Check for Reverse Pitch Operation	7-3
Propeller Deicing	4-11
Propeller Failures	3-13
Propeller Feathering Buttons	1-10
Propeller Fluid Low Level Lights	1-10
Propeller Fluctuation	3-14
Propeller Levers	1-10
Propeller Limitations	5-1
Propeller Linkage Control Failure	3-14
Propeller Oil Low Level Warning Light	3-13
Propeller Reverse Indicator Light	1-11
Propeller Reversing	7-3
Propeller, Runaway	3-13
Propellers	1-8

R

Radar Altimeter	4-24
Radar Gyro Power Failure Indicator	1-37
Radar or ILS Approach — Typical	9-4*
Radar Weather	4-31
Inverter	1-19
Operation	4-31
Radio Range, ADF, or TACAN Approach — Typical	9-5*
Radio	
UHF Command	4-22
VHF Command	4-23
VHF Command Standby Transmitter	4-23
FM Liaison	4-23
TACAN	4-26
VOR/ILS Localizer Receiver	4-27
Glide Slope Receiver	4-28
Marker Beacon Receiver	4-29
ADF Receiver	4-29
HF Liaison Radio	4-29
HF — SSB Liaison Radio	4-30
IFF *AN/ARC-102)	4-30
IFF Operation	4-30
Ramp Extension	4-43

R (Cont)

Ramp Extensions Stowage	4-43
Ramp Loading Limitations	5-7
Ramp Operation	4-44, 4-46
Rear Entrance Light	4-37
Rear Entrance Light Switch	4-37
Refueling the Auxiliary Tanks	7-8
Restart in Flight, Engine	3-10
Restraining Strap, Draftproof Door	4-48
Restrictions, Operating	2-1
Restriction, RPM	5-4A
Reverse Limitations	5-6
Reversing, Propeller	7-3
RPM Restriction	5-4A
Rudder Pedals	1-26
Rudder Trim Tab Handwheel	1-26
Runaway Aileron Trim	3-23
Runaway Propeller	3-13
Runup, Engine	2-28

S

Seats	1-42
Horizontal Adjustment Lever	1-42
Vertical Adjustment Lever	1-43
Secondary Bus	1-15
Secondary Bus Reset Switch	1-15
Servicing Data	1-44*
Servicing Diagram	1-45*
Short-field Approach Speed Indicator	1-38
Short-field Landing	2-43
Short-field Take-Off	2-34
Shoulder Harness Reel Lock Lever	1-43
Shutdown Conditions, Engine	3-1
Shutdown, Engine	2-47
Single-Engine Best Climb Speed	3-5*
Single Engine Control Speeds	3-4*
Single Engine Flight Characteristics	3-9
Single Engine Go-Around	3-30
Single Engine Landing and Go-Around Diagram	3-31*
Sink Rate on Landing, Maximum Allowed	5-7
Sliding Console	4-35*
Smoke/Fumes Elimination	3-19
Spark-Plug Fouling	7-2
Speed, Single-Engine Best Climb	3-5*
Spins	6-2
Stalls	6-1
Stall Characteristics	6-2
Stalls Practice	6-1
Stall Speed Chart	6-4*
Stall Warning System	1-27

Stall Warning Test Switch	1-27
Standard Power Terminology	2-2
Standard Terminology	2-2
Standby Inverter	1-24
Standby Inverter Failure	3-23
Starter	1-7
Starter Limitations	5-4A
Starter Switch	1-7
Starting Engines	2-18, 9-9
Steady Strut, Fuselage	4-49
Stopping Engines	9-13, 9-14
Storm, In The	9-7
Switch, Anti-Collision Lights	4-33
Cargo Compartment Dome Light	4-36
Cargo Loading Light	4-37
Engine Panel Lights	4-38
Flight Compartment Dome Light	4-34
Formation Lights	4-34
Hot Fuel Prime	4-50
Landing Lights	4-34
Magnetic Standby Compass Light	4-36
Navigation Lights	4-33
Panel Lights Copilots	4-37
Panel Lights Pilots	4-37
Rear Entrance Light	4-37
Taxiing Light	4-34
Warning Lights Intensity	4-38
Windshield Wiper	4-49
Wing Inspection	4-34

T

TACAN	4-26
Inverter	1-19
Range Indicator	4-27
Tachometer	1-8
Take-Off	2-33, 7-8, 7-12, 9-11, 9-13, 9-14
Take-Off, After	2-36, 9-11
And Landing Data Card	2-1
Before	2-40, 9-11
Crosswind	2-43
Emergencies	3-3
Engine Failure, During	3-3
No Flaps	2-35
Normal	2-40
Short-field	2-43
TALAR	4-27
Taxiing	2-25, 9-10
Before	2-21
Instructions	9-13, 9-14
Light	4-34
Light Switch	4-34

T (Cont)

Temperature Control System	4-2, 4-6
Throttle Levers.....	1-2
Thrust Indicating System Selector.....	1-32
Thrust Indicators.....	1-32
Tie-Down Device Stowage.....	4-47
Tire Failure, Landing With	3-32
Top of Aircraft Check	2-9
Thunderstorms and Turbulence.....	9-7
Touch and Go/Closed Traffic Pattern	2-45
Transponder Control C-6280(P)/APX, AIMS.....	4-30C
Transponder Set Test Set TS-1843/APX, AIMS.....	4-30F
Troop Jump Lights.....	4-47
Troop Jump Panel	4-47
Troop Jump Pendulum Release Panel	4-48A*
Turbulence and Thunderstorms.....	9-7
Turns.....	3-10
Turn and Slip Indicators.....	1-37

U

UHF Command Radio.....	4-22
Unlocked Doors Light.....	4-36
Utility Lights.....	4-36

V

Valve, Fuel Level Control.....	7-8
VG Diagram	5-8*
Ventilating and Heating Systems.....	4-1
Ventilating System, Cargo Compartment	4-10
Ventilating System, Flight Compartment.....	4-9
Vertical Adjustment Lever, Seats	1-43
Vertical Velocity Indicators	1-36
VHF Command Radio.....	4-23
VHF Command Standby Transmitter.....	4-23
Voltmeters.....	1-14
VOR/ILS Localizer Receiver.....	4-27
VOR/ILS Procedure	4-27

W

Warm Up.....	9-9
Warning Lights Intensity Switch.....	4-38
Warning Signs, Passenger	4-37
Weather Radar Inverter	1-19, 4-31
Weather Radar Set Controls, Operating Procedures.....	4-31
Weight and Balance	2-2
Weight, Gross	5-10
Weight Limitations	5-7, 7-10
Weight Limitations Chart	5-12*
Weight Limitations Chart Examples	5-10
Weight, Operating.....	5-7
Weight, Zero Fuel.....	5-11
Wheel Brakes.....	7-12
Wheel Brakes Lever, Emergency	1-31
Wheel Brakes System.....	1-31
Wheel, Nosewheel Steering	1-31
Window, Nose Gear Observation	1-30
Windshield Anti-Icing.....	4-11
Windshield Wiper Switch	4-49
Windshield Wiper System	4-49
Wing and Tail Deicing Switches.....	4-12
Wing and Tail Deicing System	4-12, 4-13*
Wing Fire.....	3-17
Wing Flap Emergency Operation	3-29
Wing Flap Position Indicator	1-27
Wing Flaps.....	1-26
Wing Flap Selector Lever.....	1-26
Wing Inspection Lights.....	4-33
Wing Inspection Lights Switch	4-34
Winterization Covers	4-15
Winterization Equipment — General Arrangement	4-16*

Z

Zero Fuel Weight.....	5-11
-----------------------	------

T (Cont)

Temperature Control System	4-2, 4-6
Throttle Levers.....	1-2
Thrust Indicating System Selector.....	1-32
Thrust Indicators.....	1-32
Tie-Down Device Stowage.....	4-47
Tire Failure, Landing With	3-32
Top of Aircraft Check	2-9
Thunderstorms and Turbulence.....	9-7
Touch and Go/Closed Traffic Pattern	2-45
Transponder Control C-6280(P)/APX, AIMS.....	4-30C
Transponder Set Test Set TS-1843/APX, AIMS.....	4-30F
Troop Jump Lights.....	4-47
Troop Jump Panel	4-47
Troop Jump Pendulum Release Panel	4-48A*
Turbulence and Thunderstorms.....	9-7
Turns.....	3-10
Turn and Slip Indicators.....	1-37

U

UHF Command Radio.....	4-22
Unlocked Doors Light	4-36
Utility Lights.....	4-36

V

Valve, Fuel Level Control.....	7-8
VG Diagram	5-8*
Ventilating and Heating Systems.....	4-1
Ventilating System, Cargo Compartment	4-10
Ventilating System, Flight Compartment.....	4-9
Vertical Adjustment Lever, Seats	1-43
Vertical Velocity Indicators	1-36
VHF Command Radio.....	4-23
VHF Command Standby Transmitter.....	4-23
Voltammeters.....	1-14
VOR/ILS Localizer Receiver	4-27
VOR/ILS Procedure	4-27

W

Warm Up.....	9-9
Warning Lights Intensity Switch.....	4-38
Warning Signs, Passenger	4-37
Weather Radar Inverter	1-19, 4-31
Weather Radar Set Controls, Operating Procedures.....	4-31
Weight and Balance	2-2
Weight, Gross	5-10
Weight Limitations.....	5-7, 7-10
Weight Limitations Chart	5-12*
Weight Limitations Chart Examples	5-10
Weight, Operating.....	5-7
Weight, Zero Fuel.....	5-11
Wheel Brakes.....	7-12
Wheel Brakes Lever, Emergency	1-31
Wheel Brakes System.....	1-31
Wheel, Nosewheel Steering	1-31
Window, Nose Gear Observation	1-30
Windshield Anti-Icing.....	4-11
Windshield Wiper Switch	4-49
Windshield Wiper System	4-49
Wing and Tail Deicing Switches.....	4-12
Wing and Tail Deicing System	4-12, 4-13*
Wing Fire.....	3-17
Wing Flap Emergency Operation	3-29
Wing Flap Position Indicator	1-27
Wing Flaps.....	1-26
Wing Flap Selector Lever.....	1-26
Wing Inspection Lights.....	4-33
Wing Inspection Lights Switch	4-34
Winterization Covers	4-15
Winterization Equipment — General Arrangement	4-16*

Z

Zero Fuel Weight.....	5-11
-----------------------	------